Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- MOFII /
- MOFII Wired Retro Typewriter Keyboard User Manual

MOFII MOFII Wired Keyboard (B0CDWQCVGG)

MOFII Wired Retro Typewriter Keyboard User Manual

Model: MOFII Wired Keyboard (B0CDWQCVGG)

1. Introduction

Thank you for choosing the MOFII Wired Retro Typewriter Keyboard. This manual provides essential information for the proper setup, operation, and maintenance of your new keyboard. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Do not expose the keyboard to liquids or excessive moisture.
- · Avoid extreme temperatures.
- Do not attempt to disassemble or repair the keyboard yourself. Contact qualified service personnel if needed.
- · Keep out of reach of children.

3. PACKAGE CONTENTS

Ensure all items are present in your package:

- MOFII Wired Retro Typewriter Keyboard
- · Cleaning Brush

4. SETUP

4.1 Connecting the Keyboard

The MOFII Wired Keyboard features a simple plug-and-play design, requiring no additional drivers for most operating systems.

1. Locate an available USB-A port on your computer (PC, Laptop, Desktop, Chromebook).

- 2. Plug the USB-A cable from the keyboard into the USB-A port on your computer.
- 3. The keyboard should be automatically recognized and ready for use within a few seconds.




Image: The keyboard connected to a laptop via its USB cable, demonstrating the plug-and-play functionality.

4.2 Adjusting Keyboard Angle

For enhanced typing comfort, the keyboard includes foldable feet to adjust its tilt angle.

- To raise the keyboard, gently pull out the two foldable feet located on the underside of the keyboard.
- To return the keyboard to a flat position, fold the feet back into their recessed slots.



Image: A side view of the keyboard demonstrating the adjustable tilt angle provided by its foldable feet.

4.3 Compatibility

The MOFII Wired Keyboard is compatible with a wide range of operating systems:

- Windows XP/Vista/7/8/10/11
- Mac OS (Note: Some multimedia functions may not be available with Mac OS)

5. OPERATING INSTRUCTIONS

5.1 Basic Typing

The keyboard features a standard 104-key full-size layout with round, retro-style keycaps. Simply begin typing after connecting the keyboard to your computer.

5.2 Multimedia Functions

The keyboard includes 11 multimedia shortcut combinations accessible via the **Fn** key. Press and hold the **Fn** key, then press the corresponding F-key (F1-F12) to activate the desired function.

Multimedia Key Combinations

| Combination | Function |
|-------------|-------------------------------------|
| Fn + F1 | Media Player |
| Fn + F2 | Volume Down |
| Fn + F3 | Volume Up |
| Fn + F4 | Mute |
| Fn + F5 | Play / Suspend |
| Fn + F6 | Previous Track |
| Fn + F7 | Play / Pause |
| Fn + F8 | Next Track |
| Fn + F9 | Email |
| Fn + F10 | Web Home |
| Fn + F11 | Screen Lock |
| Fn + W | WASD and Arrow Key Swapping |
| Fn + Win | Lock/Unlock Windows Key and APP Key |



Image: Visual representation of the multimedia function keys and their corresponding actions.

5.3 Indicator Lights

The keyboard features indicator lights for various statuses:

- Keypad Lock Indicator: Illuminates when the numeric keypad is active.
- Caps Lock Indicator: Illuminates when Caps Lock is active.
- Win Lock Indicator: Illuminates when the Windows key is locked.



Image: A detailed view highlighting the three indicator lights on the keyboard.

6. MAINTENANCE

6.1 Cleaning the Keyboard

To maintain optimal performance and appearance, regularly clean your keyboard.

- Use the included cleaning brush to remove dust, crumbs, and other debris from between the keycaps.
- For surface cleaning, gently wipe the keycaps and keyboard body with a soft, damp cloth. Avoid harsh chemicals.



Image: The keyboard with a few keycaps detached, illustrating the removable keycap design and the cleaning brush for maintenance.

7. TROUBLESHOOTING

7.1 Keyboard Not Responding

- Ensure the USB cable is securely plugged into both the keyboard and the computer's USB port.
- Try plugging the keyboard into a different USB port on your computer.
- · Restart your computer.

7.2 Multimedia Keys Not Functioning on Mac OS

As noted in the compatibility section, some multimedia functions may not be fully supported on Mac OS due to system differences. This is expected behavior.

7.3 Erratic Key Input

If you experience incorrect key input or keys getting stuck internally, especially after reconnecting the cable:

- Disconnect the keyboard's USB cable from the computer.
- Wait a few seconds, then reconnect the USB cable firmly. This often resolves temporary

8. SPECIFICATIONS

| Feature | Detail |
|-------------------------|---|
| Brand | MOFII |
| Model | Wired Keyboard (B0CDWQCVGG) |
| Connectivity Technology | USB-A |
| Keyboard Description | Multimedia, Full-Size with Numeric Keypad |
| Special Feature | Round Key, Retro Style |
| Color | Pink Colorful |
| Material | Silicone |
| Compatible Devices | PC, Laptop, Desktop, Chromebook |
| Item Weight | 1.85 pounds |
| Package Dimensions | 17.95 x 6.38 x 1.81 inches |
| USB Cable Length | 65 inches (approx. 5.4 ft) |



9. WARRANTY AND SUPPORT

MOFII products are designed for reliability and performance. For specific warranty details and support inquiries, please refer to the product packaging or contact MOFII customer service directly through their official website or the retailer where the product was purchased.

Please have your product model (B0CDWQCVGG) and purchase information ready when contacting support.

Related Documents - MOFII Wired Keyboard (B0CDWQCVGG)



SK-623 Wired Keyboard Instruction Manual

Instruction manual for the SK-623 Wired Keyboard, detailing hardware basics, multimedia hotkeys, safety instructions, and package contents.



SMK-676367AG RF2.4GHz Auto-Link Keyboard & Mouse Instruction Manual

Instruction manual for the SMK-676367AG RF2.4GHz Auto-Link Keyboard and Optical Mouse, covering battery installation, receiver connection, power-saving features, FN+ functions, and troubleshooting.



Bezprzewodowy zestaw klawiatura + myszka MOFII 666 2.4G - Instrukcja obsługi

Instrukcja obsługi dla bezprzewodowego zestawu klawiatury i myszy MOFII 666 2.4G. Zawiera informacje o instalacji baterii, podłączaniu odbiornika, funkcjach oszczędzania energii, skrótach klawiszowych, rozwiązywaniu problemów i deklaracji zgodności.



MOFII 666 2.4G Vezeték nélküli Billentyűzet és Egér Kombó Felhasználói Kézikönyv

Részletes felhasználói útmutató a MOFII 666 2.4G vezeték nélküli billentyűzet és egér kombóhoz. Tartalmazza a telepítési útmutatót, akkumulátor-behelyezést, energiatakarékossági funkciókat, multimédia gyorsbillentyűket, hibaelhárítást és garanciális információkat.



MOFii Wireless Keyboard and Mouse User Manual

User manual for the MOFii 2.4G wireless keyboard and mouse combo, detailing setup, operation, and troubleshooting steps for optimal performance and connectivity.



MOFII SMK-623387AG RF2.4GHz Auto-Link Keyboard & Optical Mouse Instruction Manual

This manual provides instructions for the MOFII SMK-623387AG wireless keyboard and optical mouse combo, detailing battery installation, receiver connection, multimedia hotkeys, power-saving features, and troubleshooting for optimal use.