

Aucanla AC-28

Aucanla AC-28 Air Conditioner Mesh Cover (28"x28") Instruction Manual

1. PRODUCT OVERVIEW

The Aucanla AC-28 Air Conditioner Mesh Cover is designed to protect your outdoor air conditioning unit from environmental elements such as leaves, branches, dust, and debris. Its mesh construction allows for proper ventilation, preventing moisture buildup and extending the lifespan of your AC unit. This manual provides instructions for proper installation, operation, and maintenance.



Figure 1: Aucanla AC-28 Air Conditioner Mesh Cover on an outdoor unit.

2. SAFETY INFORMATION

Please read and understand all instructions before installing or using the product. Keep this manual for future reference.

- Ensure the air conditioning unit is turned **OFF** before installation to prevent accidental activation of the fan.
- Do not attempt to modify the cover or its components.
- Keep children and pets away from the AC unit during installation.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Aucanla AC-28 Air Conditioner Mesh Cover (28"x28")
- 4 x Bungee Cords with Hooks

4. SPECIFICATIONS

Feature	Specification
Model Number	AC-28
Dimensions	28 inches x 28 inches
Material	Polyester Mesh, Metal (hooks)
Closure Type	Bungee Cord & Hook
Color	Black Mesh
Water Resistance Level	Water Resistant

5. INSTALLATION GUIDE

Follow these steps to properly install the Aucanla AC-28 Mesh Cover on your outdoor air conditioning unit:

- 1. Measure Your AC Unit:** Before installation, ensure your AC unit's top dimensions are approximately 28 inches by 28 inches to ensure a proper fit.
- 2. Position the Cover:** Carefully place the mesh cover over the top of your outdoor AC unit. Ensure the four corners of the cover align with the corners of the unit.
- 3. Attach Bungee Cords:** Locate the metal grommets at each corner of the mesh cover. Attach one end of a bungee cord to each grommet.
- 4. Secure the Hooks:** Extend each bungee cord down the side of the AC unit and hook the other end onto the bottom grille or a secure point on the unit's side. Ensure the cover is taut and securely fastened to prevent it from being dislodged by wind.

Universal fit



Durable cover fits most standard-sized AC units. Please carefully measure your AC unit before choosing right cover size.

Figure 2: Cover dimensions and bungee cords.

Easy for installation



Figure 3: Mesh cover installed on various AC unit types.

Installation Video:

Your browser does not support the video tag.

Video 1: Demonstrates the installation process of the air conditioner mesh cover using bungee cords.


6. OPERATION AND BENEFITS

The Aucanla AC-28 Mesh Cover is designed for year-round protection while allowing your AC unit to function efficiently. The breathable mesh material prevents debris accumulation without impeding airflow.

- **Debris Protection:** Effectively blocks leaves, twigs, grass clippings, and other foreign objects from

entering the AC unit's internal components.

- **Ventilation:** The mesh design ensures adequate airflow, preventing moisture buildup and corrosion, which can occur with solid covers. This also allows the unit to operate safely while the cover is in place.
- **All-Season Use:** Provides protection against various weather conditions, including dust in spring, sun exposure in summer, fallen leaves in autumn, and snow in winter.




Stainless steel hole & Reinforced edge

Breathable mesh
Designed for maximum durability

Figure 4: Detail of the breathable mesh and reinforced grommet.

Well-ventilated



NOTE:

When the fan starts turning, there is a lot of air blowing upward, which will cause the cover to puff upward a little. That is normal, please don't worry.

Figure 5: Illustration of proper ventilation through the mesh cover.



Figure 6: Seasonal protection provided by the mesh cover.

Operation Video:

Your browser does not support the video tag.

Video 2: Shows the mesh cover effectively preventing leaves and debris from entering the AC unit.

7. MAINTENANCE

Regular maintenance will ensure the longevity and effectiveness of your mesh cover:

- **Cleaning:** Periodically remove any accumulated leaves or debris from the top of the cover. The cover can be rinsed with water and mild soap if necessary, then air-dried.

- **Inspection:** Routinely check the bungee cords and grommets for any signs of wear or damage. Replace any damaged components to maintain secure fastening.

8. TROUBLESHOOTING

- **Cover Puffs Up When Fan is On:** It is normal for the cover to puff upward slightly when the AC unit's fan is operating due to the upward airflow. The mesh design is intended to allow this airflow while still blocking debris. Ensure the bungee cords are securely fastened to keep the cover in place.
- **Cover Does Not Fit:** Verify the dimensions of your AC unit against the cover's specifications (28"x28"). If the unit is a different size, a different cover size may be required.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Aucanla customer service directly. Contact details are typically provided with the product or on the manufacturer's official website.