

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Inalsa](#) /
- › [Inalsa Mini Steam Iron Voyager 1200W - Instruction Manual](#)

Inalsa Voyager

Inalsa Mini Steam Iron Voyager 1200W - Instruction Manual

Model: Voyager | 1200 Watts

1. PRODUCT OVERVIEW

The Inalsa Mini Steam Iron Voyager is a versatile 2-in-1 appliance designed for both steaming and flat ironing. Its compact and lightweight design makes it ideal for travel and everyday use, offering quick wrinkle removal for various fabrics.



Image 1: The Inalsa Mini Steam Iron Voyager in its compact form, ready for use.

Key Features:

- **2-in-1 Functionality:** Operates as both a steam iron and a garment steamer.
- **High Power:** 1200W for efficient heating and consistent steam.
- **Rapid Heat-up:** Reaches operating temperature in approximately 40 seconds.
- **Scratch-Resistant Sole Plate:** Titanium coated plate ensures smooth gliding and fabric protection.
- **Portable & Lightweight:** Weighs 640 grams with a foldable handle for easy storage and travel.
- **Versatile Use:** Suitable for flat ironing and vertical steaming on various fabrics.

What's in the Box:

- 1 N Main Unit (Inalsa Mini Steam Iron Voyager)
- 1 N Garment Steamer Stand
- 1 N Water Pouring Mug
- 1 N Instruction Manual Cum Warranty Card

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Always ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Never leave the iron unattended while it is switched on or connected to power.
- Use the appliance only for its intended purpose as described in this manual.
- Avoid touching the hot sole plate or steam nozzle during operation.
- Always unplug the iron from the power outlet before filling or emptying the water tank, cleaning, or when not in use.
- Do not operate the iron with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner.
- Use distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.

3. SETUP

3.1 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank cap.
3. Using the provided water pouring mug, carefully fill the water tank with distilled or demineralized water up to the MAX fill line (100 ml capacity). Do not overfill.
4. Close the water tank cap securely.



Image 2: Illustration of filling the water tank for the Inalsa Mini Steam Iron.

3.2 Power Connection

Plug the power cord into a suitable electrical outlet. The indicator light will illuminate, signaling that the iron is heating up.

4. OPERATING INSTRUCTIONS

The Inalsa Mini Steam Iron Voyager offers both vertical steaming and flat ironing capabilities.

4.1 Vertical Steaming Mode

1. Ensure the water tank is filled.
2. Plug in the iron and allow it to heat up for approximately 40 seconds until the indicator light changes or stops blinking (refer to specific model indicator behavior).
3. Hold the garment vertically, taut, and away from your body.
4. Press and hold the steam button to release steam. Move the iron slowly over the fabric, maintaining a slight distance.
5. Release the steam button to stop steaming.




Image 3: Demonstrating vertical steaming for quick wrinkle removal.



Image 4: The iron can be used for both vertical steaming and flat ironing.

4.2 Flat Ironing Mode

1. Ensure the water tank is filled (for steam ironing) or empty (for dry ironing).
2. Plug in the iron and allow it to heat up.
3. Place the garment on a heat-resistant surface or ironing board.
4. For steam ironing, press the steam button as you glide the iron over the fabric. For dry ironing, simply glide the hot sole plate over the fabric without pressing the steam button.
5. The foldable handle allows for comfortable grip during flat ironing.

Designed to iron even hard to reach area like, collars & around buttons etc.



Image 5: The compact design is ideal for ironing hard-to-reach areas like collars and around buttons.

4.3 Fabric Compatibility

The titanium-coated sole plate is safe for all types of fabrics, including organic fabrics, nylon blend, wool, cotton, and linen. Always check the garment's care label for specific ironing instructions.



Image 6: Visual comparison of a wrinkled shirt before and after using the Inalsa Mini Steam Iron.

5. MAINTENANCE

5.1 Cleaning the Sole Plate

1. Ensure the iron is unplugged and completely cool.
2. Wipe the sole plate with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner specifically designed for iron sole plates.
3. Never use abrasive scouring pads or harsh chemicals, as these can damage the titanium coating.

5.2 Draining Water

After each use, or before storing, ensure the water tank is empty to prevent water stagnation and mineral buildup.

1. Unplug the iron and allow it to cool down.
2. Open the water tank cap and carefully invert the iron over a sink to drain any remaining water.
3. Close the cap once all water is drained.

5.3 Storage

Store the iron in a cool, dry place. The foldable handle allows for compact storage. Ensure the iron is completely cool and dry before storing.



compact in size and lightweight

Travel-Friendly Steamer

Non Detachable water tank, no leaking no spitting, compact in size and lightweight(1.1lbs), effective in eliminating wrinkles and leave no water stain on your clothes, ideal partner for your journeys & trips

Image 7: The compact and travel-friendly design allows for easy storage in bags.

6. TROUBLESHOOTING

If you encounter any issues with your Inalsa Mini Steam Iron Voyager, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam output	Water tank is empty; Iron not hot enough; Steam button not pressed.	Fill water tank; Allow iron to heat up fully (approx. 40 seconds); Press and hold the steam button.
Water leaking from sole plate	Water tank overfilled; Iron not hot enough for steam; Mineral buildup.	Do not overfill; Allow iron to heat up completely before steaming; Descale the iron (refer to maintenance).
Iron not heating up	Not plugged in; Power outlet malfunction; Appliance fault.	Check power connection; Try a different outlet; Contact customer support if problem persists.

Problem	Possible Cause	Solution
Poor wrinkle removal	Insufficient heat/steam; Fabric type.	Ensure iron is fully heated; Use steam for stubborn wrinkles; Check fabric care label for suitability.

7. SPECIFICATIONS

- **Brand:** Inalsa
- **Model:** Voyager
- **Wattage:** 1200 Watts
- **Voltage:** 220 Volts
- **Heat Time:** 40 Seconds
- **Water Tank Capacity:** 100 Milliliters
- **Item Weight:** 640 Grams
- **Product Dimensions:** 21.1L x 7.5W x 10.5H Centimeters
- **Sole Plate:** Titanium Coated
- **Color:** Pearl White
- **Country of Origin:** China

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This Inalsa Mini Steam Iron Voyager comes with a standard brand warranty. Please refer to the 'Instruction Manual Cum Warranty Card' included in your product packaging for detailed terms and conditions. Extended warranty options may be available from third-party providers.

- **1 Year Extended Warranty by Onsitego:** Available for purchase.
- **2 Years Extended Warranty by Onsitego:** Available for purchase.

8.2 Customer Support

For any product-related queries, technical assistance, or warranty claims, please contact Inalsa customer support. Contact details can be found on your warranty card or the official Inalsa website.

Manufacturer Contact: Tuareg Marketing Pvt. Ltd. Khasra No- 1189, Bhalswa, New Delhi-110033, IND.
Contact- 9773982065.

9. PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: An official product overview showcasing the Inalsa Mini Steam Iron's features, including its quick heat-up, foldable handle, and scratch-resistant plate. This video demonstrates its portability and ease of use for both steaming and ironing.