

[Manuals.plus](#) /

> [Brookstone](#) /

> BROOKSTONE Slim Laundry Hamper with Handles Instruction Manual - Model BKH1698

Brookstone BKH1698

BROOKSTONE Slim Laundry Hamper with Handles Instruction Manual

Model: BKH1698

INTRODUCTION

The BROOKSTONE Slim Laundry Hamper is designed for convenient and stylish laundry organization. This foldable hamper offers a space-saving solution for collecting dirty clothes in various settings, including bedrooms, dorms, and bathrooms. Its slim profile allows it to fit into narrow spaces, while its durable construction ensures long-lasting use.

Key features include:

- **Elegant Functionality:** Modern artistic design to complement any room.
- **Premium Quality:** Crafted from high-quality, durable materials.
- **Contemporary Design:** Unique pattern for enhanced home decor.
- **Slim Yet Spacious:** Ample room for laundry with a space-efficient design and comfortable handles for easy transport.
- **Versatile Style:** Suitable for various home decor styles and practical laundry needs.

SETUP INSTRUCTIONS

Your BROOKSTONE Slim Laundry Hamper arrives folded for compact storage. Follow these steps to set it up for use:

1. **Unfold the Hamper:** Carefully unfold the fabric hamper from its collapsed state.
2. **Prepare Support Rods:** The hamper includes four support rods. These rods are typically foldable or come in sections. Straighten each rod if necessary.
3. **Insert Rods into Sleeves:** Locate the internal sleeves or pockets along the four vertical corners of the hamper. Insert one support rod into each sleeve, pushing it down until it reaches the bottom. Ensure the rods are fully seated to provide maximum stability.
4. **Shape the Hamper:** Once all rods are in place, gently push down on the bottom of the hamper and pull up on the sides to fully expand and shape it. The mesh closure at the top will help maintain its form.

IDEAL FOR BEDROOMS

A stylish way to keep dirty clothes off the floor



Image: Visual guide for assembling the laundry hamper. Step 1 shows the folded hamper and rods. Step 2 illustrates straightening a rod. Step 3 demonstrates inserting a rod into the corner sleeve. Step 4 shows the fully assembled hamper.

OPERATING INSTRUCTIONS

Using your BROOKSTONE Slim Laundry Hamper is straightforward.

Collecting Laundry

Place the hamper in your desired location, such as a bedroom, dorm room, or bathroom. Its slim design allows it to fit into tight spaces. Simply place dirty clothes into the hamper. The large capacity (approximately 45 liters) can hold a significant amount of laundry.



Image: The laundry hamper positioned beside a washing machine, illustrating its capacity to hold clothes.

LARGE CAPACITY

Compact, yet fits all of your clothes



* ITEM ARRIVES FOLDED. IRONING IS RECOMMENDED

Image: A detailed view of the hamper highlighting its dimensions (14" x 7" x 22"), sturdy opening, convenient tote handles, and mesh closure for securing contents.

Transporting Laundry

The hamper is equipped with sturdy tote handles for easy carrying. You can carry it using the handles on the shorter sides or the longer sides, depending on your preference and the load. This makes transporting laundry to the washing machine or laundry room effortless.

LAUNDRY

Add convenience & style to any laundry room



STURDY OPENING
Maintains shape



TOTE HANDLES
For easy moving



MESH CLOSURE
Helps secure overfill



Image: Demonstrates two methods of carrying the hamper: holding the handles on the narrow ends and holding the handles on the wider ends.

Folding for Storage

When not in use, the hamper can be easily folded flat for compact storage. Remove the support rods, then collapse the fabric body. It can be stored in a closet, drawer, or under a bed, taking up minimal space.

MAINTENANCE

To ensure the longevity and cleanliness of your BROOKSTONE Slim Laundry Hamper, follow these maintenance guidelines:

- **Cleaning:** The hamper is made from linen material, which can typically be washed. For best results, hand wash with mild soap and cold water, or spot clean with a damp cloth. Avoid harsh detergents or bleach.
- **Drying:** Air dry the hamper completely before reassembling or storing to prevent mildew. Do not tumble dry.
- **Ironing:** The item arrives folded, and ironing is recommended to remove creases for a smoother appearance. Use a

low heat setting.

- **Rod Care:** Periodically check the support rods for any damage or bending. Ensure they are clean and dry before reinserting them.

TROUBLESHOOTING

If you encounter any issues with your laundry hamper, consider the following:

- **Hamper Does Not Stand Upright:** Ensure all four support rods are fully inserted into their respective sleeves and are not bent. The rods provide the structural integrity for the hamper to stand.
- **Rods Slip Out:** If the rods frequently slip out, verify they are correctly seated at the bottom of the sleeves. If the issue persists, ensure the hamper fabric is taut and properly expanded.
- **Creases from Folding:** As the hamper arrives folded, creases are normal. Ironing on a low heat setting can help smooth out the fabric.
- **Missing Parts:** If any components, such as support rods, are missing upon arrival, please contact customer support for assistance.

SPECIFICATIONS

Model Number	BKH1698
Brand	Brookstone
Material	Linen
Dimensions (L x W x H)	35.6L x 17.8W x 55.9H Centimeters (approximately 14" L x 7" W x 22" H)
Capacity	45 litres
Special Feature	Slim, Foldable
Included Components	Hamper, Support Rods
UPC	843620146280

WARRANTY INFORMATION

Specific warranty details for the BROOKSTONE Slim Laundry Hamper are not provided in the product information. Please refer to the retailer's return policy or contact Brookstone customer support for any warranty-related inquiries.

CUSTOMER SUPPORT

For further assistance, questions, or to report missing parts, please contact Brookstone customer support or the retailer from whom you purchased the product.

You may find contact information on the product packaging or the official Brookstone website.



