

Smile S666

Smile S666 Multimedia Speaker User Manual

Model: S666

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Smile S666 Multimedia Speaker. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.

2. SAFETY INFORMATION

To ensure safe operation and prolong the lifespan of your speaker, please observe the following precautions:

- Do not expose the speaker to water or excessive moisture. This product is **not** water-resistant.
- Avoid placing the speaker in direct sunlight or near heat sources.
- Do not disassemble or attempt to repair the speaker yourself. Refer all servicing to qualified personnel.
- Use only the power adapter and cables provided or recommended by the manufacturer.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Smile S666 Multimedia Speaker
- USB Power Cable
- Audio Cable (3.5mm Jack)
- User Manual



Figure 3.1: The Smile S666 Multimedia Speaker as packaged in its retail box.

4. PRODUCT OVERVIEW

The Smile S666 is a compact multimedia speaker designed for desktop use, offering clear audio output for your computer or other compatible devices.

4.1 Components

- **Main Speaker Unit:** Houses the audio drivers and control circuitry.
- **Volume Knob:** Located on the top surface, used to adjust audio output level.
- **USB Power Port:** For connecting the speaker to a power source.
- **Audio Input Port (3.5mm):** For connecting to audio sources like computers, phones, etc.



Figure 4.1: Front and top view of the Smile S666 Multimedia Speaker, showing the speaker grille and volume knob. The speaker is available in different finishes, including wood grain and black.

5. SETUP

Follow these steps to set up your Smile S666 Multimedia Speaker:

1. **Placement:** Place the speaker on a stable, flat surface near your computer or audio source. Ensure there is adequate ventilation around the speaker.
2. **Connect Power:** Insert the USB power cable into the speaker's USB power port. Connect the other end of the USB cable to a powered USB port on your computer or a USB wall adapter (5V/1A recommended).
3. **Connect Audio:** Insert one end of the 3.5mm audio cable into the audio input port on the speaker. Connect the other end of the 3.5mm audio cable to the headphone jack or audio output port of your computer, laptop, or other audio device.
4. **Power On:** The speaker will typically power on automatically once connected to a power source. Some models may have a power switch integrated with the volume knob; turn the knob clockwise until you hear a click to power on.

6. OPERATING INSTRUCTIONS

6.1 Adjusting Volume

Rotate the volume knob on the top of the speaker clockwise to increase the volume and counter-clockwise to decrease it. You can also adjust the volume from your connected device.

6.2 Audio Playback

Once connected, play audio from your computer or device. The sound will be output through the Smile S666 speaker.

7. MAINTENANCE

To keep your speaker in optimal condition:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use liquid cleaners or abrasive chemicals.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the power and audio cables excessively.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	Speaker not powered on; Cables not connected properly; Volume too low; Incorrect audio output selected on device.	Ensure speaker is powered on; Check all cable connections; Increase speaker and device volume; Select the correct audio output on your computer/device.
Distorted sound	Volume too high; Poor audio source quality; Damaged cable.	Lower the volume; Try a different audio source; Replace the audio cable.
Speaker not recognized by computer	Driver issue (rare for plug-and-play speakers); USB port issue.	Try a different USB port; Restart your computer.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	40 x 5 x 5 cm
First Available Date	August 7, 2023
Manufacturer	smail

Feature	Detail
ASIN	B0CDZBFRQ5
Brand Name (as listed)	General
Connectivity Technology	Wired (3.5mm Audio Jack), Bluetooth
Mounting Type	Tabletop Mount
Model Name	S666
Speaker Type	Multimedia
Compatible Devices	Personal Computer
Subwoofer Diameter	12 inches
Color	Vibrant Color
Water Resistance	No

10. WARRANTY AND SUPPORT


This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in the package or contact your point of purchase. For technical support or service inquiries, please contact the retailer or manufacturer directly. For further assistance, you may visit the manufacturer's website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Smile. All rights reserved.

Related Documents

	<p>Smile Strawberry Pattern Shopping Bag A white plastic shopping bag featuring a repeating pattern of red strawberries and the word 'Smile', suitable for retail or gift packaging.</p>
---	---

[\[pdf\]](#) Confidentiality Request Letter




GE Corometrics 115 Repair Help Learn How to Fix It YourselfCorometrics Model Service Manual Part 14documents cdn ifixit JKioBJ3imQRsPih3 thumbnailUrl guide images igi sLFoY2oQtrLELBPS standard type title |||

AN REVIDESCRIPPIIONIDESCAIPIION 66665 DC0DO0GGm5SS5e21 t
FGFJSERRAEPU DAEPRASRONPAMNNOMCAN ... S=C= REGET = FINISH A
UNE115 RECORDRE BED.ASEY DUAL EAEDIOTA CA == DRAMNG NUMBER REY
C **S666** TAB SALE 1.28 :4 9 303 12-51 MEDICLAOLROBYSTEMS INC i ITEM DWG
PART NUMBER „SIZE T...

lang:nl **score:24** filesize: 2.13 M page_count: 51 document date: 2020-05-18


[\[pdf\]](#) Confidentiality Request Letter



GE Corometrics 115 Repair Help Learn How to Fix It YourselfCorometrics Part 14 1documents cdn ifixit fqVqkm22VZGMqSRZ thumbnailUrl guide images igi 4U1g2EmCwUCajIEE standard type title |||

AN REVIDESCRIPPIIONIDESCAIPIION 66665 DC0DO0GGm5SS5e21 t
FGFJSERRAEPU DAEPRASRONPAMNNOMCAN ... S=C= REGET = FINISH A
UNE115 RECORDRE BED.ASEY DUAL EAEDIOTA CA == DRAMNG NUMBER REY
C **S666** TAB SALE 1.28 :4 9 303 12-51 MEDICLAOLROBYSTEMS INC i ITEM DWG
PART NUMBER „SIZE T...

lang:nl **score:17** filesize: 2.13 M page_count: 51 document date: 2020-05-18



[\[pdf\]](#) Guide

Ibn 3Ashir Guiding Helper privat bahnhof se 80 wb449823 00 DATA Kutub English |||

The Guiding Helper Main Text Explanatory Notes A Guidebook for Life 1st Edition
The Guiding Hel ... ground the sun lies. Maghrib s664 and Isha s665 second time
stretches till dawn. The second time **s666** for those whose intellect667 was gone,
11:398 11:399 11:400 11:401 11:402 660 The first time ...

lang:en **score:15** filesize: 2.24 M page_count: 353 document date: 2002-01-31