

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PeroBuno](#) /

› [PeroBuno Electric Air Duster & Mini Vacuum Cleaner User Manual](#)

PeroBuno HL-117-ZJ

PeroBuno Electric Air Duster & Mini Vacuum Cleaner

Model: HL-117-ZJ

INTRODUCTION

Thank you for choosing the PeroBuno Electric Air Duster and Mini Vacuum Cleaner. This 2-in-1 device is designed to provide powerful and versatile cleaning for a wide range of applications, from delicate electronics to car interiors. Featuring a high-performance brushless motor and multiple speed settings, it offers both strong air blowing and efficient vacuum suction. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your device.

PRODUCT OVERVIEW & CONTENTS

Your PeroBuno 2-in-1 cleaner comes with a comprehensive set of accessories to maximize its utility. Please ensure all items are present upon unboxing.



Image: The PeroBuno 2-in-1 cleaner shown with its full set of accessories, including various nozzles, brushes, charging cable, filters, and a carrying case.

Package Contents:

- PeroBuno Main Unit (Air Duster/Vacuum)
- Carrying Case
- USB Type-C Charging Cable
- Wide Sucking Nozzle
- Flat Sucking Nozzle
- Short Blowing Nozzle
- Long Blowing Nozzle
- Inflation Nozzle 1
- Inflation Nozzle 2
- Cleaning Brushes (various types)
- Steel Filter (1 pre-installed)
- HEPA Filters (2 rewashable)

SETUP

1. Initial Charging

Before first use, fully charge the device. A 5V/2A adapter is recommended (not included). The indicator light will be red during charging and turn green when fully charged.




Image: The device connected via USB-C for charging, illustrating the charging port and indicator light status.

2. Assembling for Air Duster Mode

1. Disassemble the dust cup by twisting it counter-clockwise and pulling it off.
2. Assemble the anti-suck cover onto the main unit.
3. Attach the desired blowing nozzle (short or long) to the air outlet.

Why choose PeroBuno 2in1 Mini Vacuum Cleaner?

Brushless Motor



Type-C Cable



Portable Bag



Fine Steel Filter



Image: A visual guide demonstrating the conversion process from vacuum to air duster mode, including disassembling the dust cup and attaching the blowing nozzle.

3. Assembling for Mini Vacuum Mode

1. Ensure the dust cup is securely attached to the main unit by twisting it clockwise until it locks.
2. Insert the desired vacuuming nozzle (wide or flat) into the dust cup opening.

OPERATING INSTRUCTIONS

1. Power ON/OFF & Gear Selection

To turn the device ON, press and hold the power button for 3 seconds. The device will start in Gear-1. Short press the power button to cycle through the gears: Gear-1 → Gear-2 → Gear-3. Press again after Gear-3 to turn the device OFF.



Image: The device highlighting the power button and its compact dimensions for easy handling.

2. Using the Air Duster

Attach the appropriate blowing nozzle. Select the desired gear based on the cleaning task. Gear-1 provides a gentler airflow suitable for delicate items, while Gear-3 offers maximum power for stubborn dust.

UPGRADED BRUSHLESS MOTOR

Gear-1: **7000**pa
Runtime: **35**mins

Gear-2: **12000**pa
Runtime: **20**mins

Gear-3: **18000**pa
Runtime: **15**mins



Image: The air duster effectively removing dust from the internal components of a desktop computer.

SUITABLE FOR WIDE APPLICATION



Image: The air duster cleaning dust and debris from between the keys of a laptop keyboard.

3. Using the Mini Vacuum

Attach the appropriate vacuuming nozzle. Select the desired gear for suction power. Gear-1 is suitable for light debris, while Gear-3 provides strong suction for more significant messes.



Image: The mini vacuum effectively collecting crumbs and dust from a computer keyboard surface.



Image: The mini vacuum being used to clean dust and small debris from the intricate areas of a car dashboard.

4. Inflation Function

Utilize the inflation nozzles to inflate various items such as air mattresses or pool floats. Attach the appropriate inflation nozzle to the blowing outlet and activate the device.



Image: The PeroBuno cleaner demonstrating its inflation capability by quickly filling an air mattress.

MAINTENANCE

1. Filter Cleaning

The device features a steel filter and two rewashable HEPA filters. For optimal performance, clean the filters regularly. Remove the dust cup, take out the filters, and rinse them under running water. Ensure filters are completely dry before reinserting them into the device.

PRODUCT DIMENSION



Image: A visual representation of the steel and HEPA filters, along with instructions for cleaning them under water to maintain device efficiency.

2. Battery Preservation

To preserve the lifespan of the lithium-ion battery, it is recommended to charge the device once per month, even when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted; Power button not pressed long enough.	Fully charge the device. Press and hold the power button for 3 seconds.
Low suction/blowing power.	Filters are clogged; Battery is low; Nozzle is obstructed.	Clean the steel and HEPA filters. Recharge the device. Check and clear any obstructions in the nozzle or air path.

Problem	Possible Cause	Solution
Battery runtime is shorter than expected.	Using higher gear settings; Battery degradation over time.	Lower the gear setting for extended runtime. Ensure regular monthly charging to preserve battery health.
Device is louder than expected.	Operating at higher gear settings.	The powerful brushless motor can produce noise at higher speeds. Consider using a lower gear if noise is a concern and sufficient for the task.

SPECIFICATIONS

Brand	PeroBuno
Model Number	HL-117-ZJ
Item Weight	1 pound (approx. 0.45 kg)
Product Dimensions	2.75 x 2.75 x 7.87 inches (approx. 7 x 7 x 20 cm)
Battery Type	1 Lithium Ion battery (included)
Color	Purple and Golden
Cover Material	ABS
Motor Type	Brushless Motor with 3 Gears
Max Air Duster RPM	200,000 RPM
Max Vacuum Suction	18,000 PA
Approximate Runtime (Air Duster/Vacuum)	Gear-1: 35 minutes Gear-2: 20 minutes Gear-3: 15 minutes

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact PeroBuno customer service directly through the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.