

IWEGGO CP20GOLD

IWEGGO CP20GOLD 10-inch Android Tablet User Manual

Model: CP20GOLD

1. PRODUCT OVERVIEW

The IWEGGO CP20GOLD is a versatile 10-inch Android tablet designed for both productivity and entertainment. It features a high-definition touchscreen, a quad-core processor, and comes with a suite of accessories including a keyboard, mouse, case, and stylus, transforming it into a 2-in-1 device. This manual provides instructions for setting up, operating, maintaining, and troubleshooting your tablet.



Image 1.1: The IWEGGO CP20GOLD tablet shown with its included accessories: a Bluetooth keyboard, wireless mouse, protective case, and stylus.

2. WHAT'S IN THE BOX

Please verify that all items are present in the package:

- IWEGGO CP20GOLD 10-inch Android Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Protective Case
- Type-C Charging Cable
- Stylus
- User Manual (this document)

3. SETUP GUIDE

3.1 Initial Charging

Before first use, fully charge the tablet. Connect the provided Type-C cable to the tablet's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will illuminate.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the screen lights up.
- **To Power Off:** Press and hold the Power button until a menu appears. Select "Power off" from the options.
- **To Restart:** Press and hold the Power button until a menu appears. Select "Restart" from the options.

3.3 Initial Configuration

Upon first power-on, follow the on-screen prompts to set up your tablet:

1. Select your preferred language.
2. Connect to a Wi-Fi network. This is essential for downloading apps and updates.
3. Sign in with your Google Account or create a new one. This allows access to the Google Play Store and other Google services.
4. Review and accept the terms and conditions.
5. Set up screen lock (PIN, pattern, or password) for security.

3.4 Connecting Accessories

The tablet comes with a Bluetooth keyboard, wireless mouse, and stylus for enhanced functionality.

- **Bluetooth Keyboard:** Turn on the keyboard and activate its Bluetooth pairing mode (refer to the keyboard's specific instructions). On the tablet, go to **Settings > Connected devices > Pair new device** and select the keyboard from the list.
- **Wireless Mouse:** Insert the USB receiver (usually found in the mouse's battery compartment) into the tablet's USB-C port via an adapter if necessary, or pair via Bluetooth if it's a Bluetooth mouse.
- **Stylus:** The stylus is typically passive and does not require pairing. Simply use it on the touchscreen.



Image 3.4: A user interacting with the tablet using the Bluetooth keyboard and stylus, demonstrating its 2-in-1 capability.

3.5 Inserting a TF Card

To expand storage, locate the TF card slot on the tablet. Gently insert a TF (microSD) card, ensuring the correct orientation, until it clicks into place. The tablet supports up to 1TB of external storage.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The tablet operates on the Android operating system, utilizing touch gestures for navigation:

- **Tap:** Select an item or open an app.
- **Tap and Hold:** Access contextual menus or move icons.
- **Swipe:** Scroll through pages, menus, or switch between home screens.
- **Pinch-to-Zoom:** Enlarge or reduce content on the screen.

Max 6GB RAM + 128GB ROM

6GB RAM(4+2 Expand)+128GB ROM+1TB Mirco SD




Image 4.1: The tablet's display showing the Android interface with various applications, demonstrating its user-friendly design.

4.2 Display Settings

The 10.1-inch IPS HD display offers a resolution of 1280x800. You can adjust display settings such as brightness, wallpaper, and sleep duration via **Settings > Display**.

Smoothly Connected, Empowering Work



2.4G/5G

Dual Band Wifi



Image 4.2: The tablet's 10.1-inch IPS HD screen showcasing vibrant visuals and its 1280x800 resolution.

4.3 Connectivity

The tablet supports advanced wireless connectivity:

- **Wi-Fi:** Supports 2.4G and 5G dual-band Wi-Fi 6 for fast and stable internet access. Connect via **Settings > Network & internet > Wi-Fi**.
- **Bluetooth 5.0:** For connecting wireless headphones, speakers, keyboards, mice, and other compatible devices. Access via **Settings > Connected devices > Bluetooth**.
- **3.5mm Headphone Jack:** For wired audio connections.

Massive Battery for All-Day Use

Internet access for up to 6-8 hours



Image 4.3: The tablet's dual-band Wi-Fi 6 capability ensures fast and reliable internet connectivity.



Image 4.4: The tablet offers fast connectivity options including 2.4G/5G Wi-Fi 6, Bluetooth 5.0, and a 3.5mm headphone jack.

4.4 App Management

The tablet is Google GMS certified, providing access to the Google Play Store. You can download and install a wide

range of applications.

- **Install Apps:** Open the **Play Store** app, search for your desired application, and tap "Install".
- **Uninstall Apps:** Tap and hold an app icon on the home screen or app drawer, then drag it to "Uninstall" or go to **Settings > Apps > See all apps** select the app, and tap "Uninstall".

4.5 Camera Usage

The tablet features an 8MP dual camera. Open the **Camera** app to take photos or record videos. You can switch between the front and rear cameras within the app.



Image 4.5: The tablet's camera can be used for capturing moments or video calls.

4.6 Battery Management

The tablet is equipped with a 6000mAh battery, providing approximately 8 hours of average use. To optimize battery life:

- Reduce screen brightness.
- Turn off Wi-Fi and Bluetooth when not in use.
- Close unused applications running in the background.
- Enable battery saver mode via **Settings > Battery**.

4.7 Using as a 2-in-1 Device

With the included keyboard and mouse, the tablet can function as a compact laptop. The protective case often doubles as a stand, allowing for comfortable viewing and typing angles.



Image 4.6: The tablet paired with its Bluetooth keyboard for a laptop-like experience.

5. MAINTENANCE

5.1 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surfaces.

5.2 Software Updates

Periodically check for system updates to ensure optimal performance and security. Go to **Settings > System > System update** to check for and install available updates.

5.3 Storage Management

The tablet has 128GB of internal storage, expandable up to 1TB with a TF card. To manage storage, go to **Settings > Storage**. You can free up space by uninstalling unused apps, deleting old files, or moving files to the TF card.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your IWEGGO CP20GOLD tablet.

- **Tablet not powering on:** Ensure the tablet is sufficiently charged. Connect it to a power source and try again after a few minutes. If it still doesn't power on, perform a force restart by holding the power button for 10-15 seconds.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Ensure you are entering the correct Wi-Fi password.
- **Bluetooth accessory not connecting:** Ensure the accessory is in pairing mode and fully charged. On the tablet, turn Bluetooth off and then on again, then try pairing.
- **Slow performance:** Close unnecessary background applications. Clear cache for frequently used apps. Consider freeing up storage space.
- **Screen not responding:** Restart the tablet. If the issue persists, ensure the screen is clean and free of debris.
- **Factory Reset:** As a last resort for persistent software issues, you can perform a factory reset. **Warning: This will erase all data on your tablet. Back up important data before proceeding.** Go to **Settings > System > Reset options > Erase all data (factory reset)**.

7. SPECIFICATIONS

Below are the technical specifications for the IWEGGO CP20GOLD tablet:

Feature	Specification
Model Name	CP20GOLD
Operating System	Android
Screen Size	10.1 Inches
Screen Resolution	1280x800 IPS
Processor	2 GHz Quad-core (ARM Chipset)

Feature	Specification
RAM	6 GB
Internal Storage	128 GB Flash Memory
Expandable Storage	Up to 1 TB (TF Card)
Wireless Connectivity	2.4G/5G Dual Band Wi-Fi 6 (802.11ax)
Bluetooth	Bluetooth 5.0
Rear Camera	8 MP
Battery	6000mAh Lithium Polymer (Average 8 hours)
Dimensions (LxWxH)	9.84 x 6.3 x 0.39 inches
Item Weight	2.2 pounds

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact IWECCGO customer service through the retailer where the product was purchased. Keep your proof of purchase for warranty claims.

© 2024 IWECCGO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question