

## SODSEA B0GJDF2W48

# SODSEA 60 Inch White Ceiling Fan with Light and Remote Instruction Manual

Model: B0GJDF2W48

## 1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the safe installation, operation, and maintenance of your SODSEA 60 Inch White Ceiling Fan with Light and Remote. Please read all instructions carefully before beginning installation and retain this manual for future reference.

### Key Features:

- **Spacious 60-Inch Design:** Provides powerful air circulation for large rooms and outdoor areas.
- **Integrated Lighting System:** Features built-in LED lights with 3 selectable color temperatures (3CCT) and dimmable functionality (10%-100%).
- **Convenient Remote Control:** Offers full command over fan speed, light brightness, and color temperature.
- **Reversible Motor Function:** Allows for seasonal adjustment of airflow direction (downdraft for summer, updraft for winter).
- **Whisper-Quiet Operation:** Engineered with noiseless technology for silent performance, operating at approximately 30 decibels.

## Find the Ideal Light for Your Home




Image: The SODSEA 60 Inch White Ceiling Fan, showcasing its modern design and integrated light.

## 2. SAFETY INFORMATION

**WARNING:** To reduce the risk of fire, electric shock, or personal injury, always follow these safety guidelines:

- Before installation, disconnect power at the circuit breaker or fuse box.
- All electrical wiring must be performed by a qualified electrician and comply with all local and national electrical codes.
- The mounting structure must be capable of supporting the weight of the fan (approximately 14 pounds).
- Ensure the fan blades are at least 7 feet (2.1 meters) from the floor and have at least 18 inches (45 cm) clearance from walls or other obstructions.
- Do not operate the fan if any part is damaged. Contact customer support for replacement parts.
- Avoid placing objects in the path of the fan blades.
- This fan is suitable for indoor and outdoor use, but avoid direct exposure to rain for outdoor installations.

## 3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer service.

- Ceiling Fan Motor Assembly
- Fan Blades (5 pieces)
- Downrods (5 inches, typically two lengths provided)
- Mounting Bracket
- Remote Control with Wall Mount
- Receiver for Remote Control
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

## 4. SETUP AND INSTALLATION

Follow these steps for proper installation. It is recommended to have two people for installation.

### 4.1 Pre-Installation Checks

- Ensure power is OFF at the circuit breaker.
- Confirm your electrical box is rated for ceiling fan support.
- Identify neutral, hot, and ground wires in your ceiling wiring.

## 4.2 Mounting the Fan

1. Attach the mounting bracket to the ceiling electrical box. Ensure it is securely fastened. Note that the fan bracket may require specific alignment with standard octagon boxes.
2. Assemble the downrod to the motor assembly. This fan supports direct ceiling mounting and inclining roofs up to 10 degrees.
3. Carefully lift the fan assembly and hang it from the mounting bracket.
4. Connect the electrical wires from the ceiling to the fan's receiver and then to the fan motor, following the wiring diagram provided in the separate wiring guide. Ensure all connections are secure with wire nuts.
5. Carefully tuck the remote control receiver and wiring into the canopy. This step may require patience to fit all components neatly.
6. Secure the canopy to the mounting bracket.
7. Attach the fan blades to the motor hub. The blades are double-sided, offering a white or walnut color option.
8. Install the light kit and diffuser.



Image: Diagram showing product dimensions (60 inch diameter, 8.5 inch height with 5 inch downrod) and recommended applicable space (18 ft x 18 ft).

### Double-sided Fan Blade

Choose your favorite blade color according to the style of your home



5 Fan Blades

2 Colors Available



Side A:  
White Color



Side B:  
Walnut Color



Image: Illustration of the double-sided fan blades, showing white and walnut color options.

## 5. OPERATING INSTRUCTIONS

Your SODSEA ceiling fan is controlled via the included remote control or a compatible smartphone application.

### 5.1 Remote Control Functions

The remote control allows you to manage all fan and light settings:

- **Fan ON/OFF:** Powers the fan on or off.
- **Fan Speed (1-6):** Adjusts fan speed from gentle (1-2) for sleeping, medium (3-4) for daily use, to high (5-6) for exercise or hot weather.
- **Light ON/OFF:** Turns the integrated LED light on or off.

- **Color Temperature (3CCT):** Cycles through 3000K Warm White, 4000K Natural White, and 6500K Cool White.
- **Dimmable Brightness (10%-100%):** Adjusts light intensity.
- **Forward/Reverse:** Changes the fan's rotation direction for seasonal comfort.
- **Timer Setting (1H/3H/6H):** Sets the fan to turn off automatically after 1, 3, or 6 hours.
- **Memory Function:** The fan remembers the last light and fan settings when turned off and on.

## Smart Remote Control

No More Getting Up—Control Your Ceiling Fans with Lights Anytime, Anywhere





Image: Diagram illustrating the functions of the remote control for the ceiling fan.

# Reverse Airflow for Year-Round Comfort

Ceiling fan provides 6 fan speeds, enhance air circulation.



## Double Side Blades

white color

walnut color

Image: Illustration demonstrating the reversible airflow feature for summer (downdraft) and winter (updraft) comfort.

# 6 Speeds Adjustable

Meet the wind demand in different scenarios



Image: Visual guide to the 6 adjustable fan speeds, categorized into low, medium, and high for different scenarios.

## 3 Color Adjustable



### Stepless Dimmable Light(10%-100%)



10%

50%

100%

Image: Depiction of the 3 adjustable color temperatures (3000K Warm White, 4000K Natural White, 6500K Cool White) and stepless dimming from 10% to 100%.

## 5.2 Smart App Control

This fan is compatible with the Tuya App for smartphone control and can be integrated with Alexa for voice commands. Refer to the separate smart control setup guide for detailed pairing instructions.

- The app allows control over fan speed, light on/off, and brightness.
- Alexa integration typically supports light on/off and basic fan control.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.

- **Blade Screws:** Check all blade screws for tightness at least twice a year. Loose screws can cause wobbling and noise.
- **Light Kit:** The LED light source is integrated and generally does not require replacement. If the light malfunctions, contact customer support.
- **Electrical Connections:** Periodically inspect all electrical connections for any signs of wear or looseness.

## 7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

| Problem                    | Possible Cause                                                                                  | Solution                                                                                                                                  |
|----------------------------|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Fan does not start         | No power; Loose wiring; Remote not paired; Faulty receiver.                                     | Check circuit breaker. Ensure all wiring connections are secure. Re-pair remote control. Contact support if receiver is suspected faulty. |
| Fan makes excessive noise  | Loose blade screws; Loose mounting bracket; Improper installation of receiver/wiring in canopy. | Tighten all blade screws. Ensure mounting bracket is secure. Re-check canopy for proper fit and wire placement.                           |
| Light does not work        | Loose wiring; Faulty LED driver or light kit.                                                   | Check light kit wiring connections. If issue persists, contact customer support for light kit replacement.                                |
| Remote control not working | Dead batteries; Remote not paired; Obstruction.                                                 | Replace remote batteries. Re-pair remote with fan. Ensure no obstructions between remote and fan.                                         |
| Fan wobbles                | Loose blades; Uneven blade weight; Loose mounting.                                              | Ensure all blade screws are tight. Check if blades are bent or damaged. Verify secure mounting.                                           |

## 8. SPECIFICATIONS

| Feature             | Specification                                                                          |
|---------------------|----------------------------------------------------------------------------------------|
| Brand               | SODSEA                                                                                 |
| Model               | B0GJDF2W48                                                                             |
| Color               | White                                                                                  |
| Electric Fan Design | Ceiling Fan                                                                            |
| Power Source        | DC                                                                                     |
| Style               | Modern                                                                                 |
| Product Dimensions  | 60"D x 60"W x 8.5"H                                                                    |
| Room Type           | Bedroom, Garage, Home Office, Living Room, Patio                                       |
| Special Features    | LED Light, Quiet Operation, Remote Controlled, Timer, Reversible Motor, 3CCT, Dimmable |
| Recommended Uses    | Air Circulation, Cooling                                                               |

| Feature              | Specification                           |
|----------------------|-----------------------------------------|
| Noise Level          | 30 Decibels                             |
| Wattage              | 35 watts                                |
| Air Flow Capacity    | 6000 Cubic Feet Per Minute (CFM)        |
| Max Speed            | 155 RPM                                 |
| Voltage              | 120 Volts                               |
| Included Components  | Ceiling fan, Remote                     |
| Indoor/Outdoor Usage | Indoor, Outdoor (avoid direct rain)     |
| Control Method       | Remote, Smart App (Tuya), Voice (Alexa) |
| Downrod Length       | 5 Inches                                |
| Item Weight          | 14 pounds                               |
| Mounting Type        | Downrod Mount                           |



Image: Detailed product specifications including voltage, wattage, color, speeds, timing, color temperature, and dimming range.

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. SODSEA is committed to customer satisfaction and provides support for product inquiries and issues.

If you encounter any problems or require assistance, please contact the seller through your purchase platform. Provide your order number and a detailed description of the issue for prompt service.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question