

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VGR](#) /

› [VGR V-705 Cordless Epilator User Manual](#)

## VGR V-705

# VGR V-705 Cordless Epilator User Manual

Model: V-705

## 1. INTRODUCTION

---

Thank you for choosing the VGR V-705 Cordless Epilator. This manual provides essential information for the safe and effective use, maintenance, and care of your device. Please read these instructions carefully before first use and retain them for future reference.

## 2. SAFETY INSTRUCTIONS

---

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the epilator on irritated skin, varicose veins, moles, birthmarks, or open wounds. Consult a doctor if you have a skin condition or other medical concerns.
- The main body of the epilator is **not water resistant**. While the epilator head is washable, do not submerge the entire device in water or use it in the shower/bath to avoid electric shock.
- Only use the provided USB charging cable.
- Keep the appliance away from heat sources and direct sunlight.
- Do not attempt to repair or disassemble the device yourself. Contact qualified service personnel for repairs.

## 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your VGR V-705 Epilator:

1. Epilator Head (with 32 tweezers)
2. Release Button (for detaching the epilator head)
3. ON/OFF Switch (with 2 speed settings: 0-1-2)
4. Charging Indicator Light

5. Protection Cap
6. USB Charging Cable
7. Cleaning Brush
8. User Manual (this document)



Image 3.1: Overview of the VGR V-705 Epilator showing the epilator head, ON/OFF switch with 2 speeds, built-in light, and USB charging port.



Image 3.2: The VGR V-705 Epilator with its accessories, including the cleaning brush, USB charging cable, and bikini cap.

## 4. CHARGING THE DEVICE

---

Before first use, fully charge your epilator. The device is USB rechargeable for convenience.

1. Ensure the epilator is switched off (position '0').
2. Connect the USB charging cable to the charging port on the epilator.
3. Plug the other end of the USB cable into a suitable USB power source (e.g., computer, USB wall adapter).

4. The charging indicator light will illuminate during charging.
5. A full charge takes approximately **2 hours** and provides up to **120 minutes** of cordless operation.
6. Once fully charged, disconnect the charging cable.



Image 4.1: Close-up of the VGR V-705 Epilator's USB charging port and indicator light, showing the charging cable.

Brand <b>VGR</b>	Place of Origin <b>Ningbo of China</b>
Charging time <b>2 H</b>	Working time <b>120 min</b>
ON/OFF switch <b>2 Speeds(0-1-2)</b>	Power supply <b>5V = 1A</b>
Battery <b>600 mAh</b>	Charging <b>USB</b>



Image 4.2: Information on the VGR V-705 Epilator's endurance, indicating 2 hours for a full charge, 120 minutes working time, and a 600 mAh battery.

## 5. OPERATING INSTRUCTIONS

### 5.1 Preparation for Epilation

- Ensure your skin is clean and dry before epilation. For optimal results, exfoliate your skin a day prior to remove dead skin cells.
- The VGR V-705 is designed for use on various body areas including legs, arms, underarms, bikini line, upper lip, and face.

### 5.2 Epilation Process

1. Remove the protection cap from the epilator head.
2. Turn on the device using the ON/OFF switch. Select your desired speed setting (Speed 1 for sensitive areas or finer hair, Speed 2 for larger areas or coarser hair).
3. Hold the epilator at a 90-degree angle to your skin, ensuring the epilator head is flat against the skin.
4. Gently glide the epilator against the direction of hair growth. Stretch your skin taut with your free hand to make the process more comfortable and efficient.

5. The built-in light helps illuminate fine hairs for thorough removal.
6. After epilation, switch off the device (position '0').



Image 5.1: Visual guide indicating the recommended application areas for the VGR V-705 Epilator, including legs, armpit, arms, and back.

### 5.3 Wet & Dry Use Clarification

The VGR V-705 is advertised for Wet & Dry use. This means it can be used on both dry skin and skin that has been prepared with water (e.g., after a warm shower to open pores). However, please note that the **main body of the epilator is not water resistant**. Only the epilator head is designed to be washable under running water. Do not submerge the entire device.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your epilator.

1. Ensure the epilator is switched off and disconnected from the charging cable before cleaning.
2. Press the release button to detach the epilator head from the main body.
3. Use the provided cleaning brush to remove any trapped hairs from the tweezers and the epilator head.

4. The epilator head is waterproof and can be rinsed under running water for thorough cleaning. Ensure it is completely dry before reattaching.
5. Do not rinse the main body of the epilator under water. Use a dry cloth to wipe it clean.
6. Once clean and dry, reattach the epilator head and place the protection cap back on.
7. Store the epilator in a cool, dry place.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Epilator does not turn on.	Battery is depleted.	Charge the epilator for 2 hours.
Poor hair removal performance.	Epilator head is dirty or damaged. Incorrect usage angle.	Clean the epilator head thoroughly. Ensure the epilator is held at a 90-degree angle against the skin and moved against hair growth.
Charging indicator light does not turn on.	Charging cable not properly connected. Faulty USB power source.	Ensure the USB cable is securely connected to both the epilator and the power source. Try a different USB port or adapter.
Device stops working during use.	Battery is low.	Recharge the epilator.

## 8. SPECIFICATIONS

- **Model:** VGR V-705
- **Voltage:** 5 Volts
- **Battery:** 500 mAh Lithium Ion (included)
- **Charging Time:** Approximately 2 hours
- **Operating Time:** Up to 120 minutes
- **Tweezers System:** 32 Tweezers
- **Speed Settings:** 2 speeds (0-1-2 switch)
- **Product Dimensions:** 18.2 x 11.5 x 5.3 cm
- **Item Weight:** 240 g
- **Water Resistance Level:** Not Water Resistant (main body); Epilator head is washable.
- **Recommended Uses:** Hair removal on legs, arms, underarms, bikini line, upper lip, and face.

## 9. WARRANTY AND SUPPORT

Your VGR V-705 Epilator comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact your retailer or the VGR customer service department. Please retain your proof of purchase for warranty

validation.

## 10. PRODUCT VIDEO

---

Watch this official product video for a visual guide on the VGR V-705 Epilator:

Your browser does not support the video tag.

Video 10.1: An official product video demonstrating the features and use of the VGR V-705 Epilator.