Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LSD176X01

VASAGLE Sit-Stand Electric Adjustable Desk User Manual

Brand: VASAGLE

Model: LSD176X01

1. Introduction

Thank you for choosing the VASAGLE Sit-Stand Electric Adjustable Desk. This manual provides essential information for the safe and efficient use of your new desk. Please read it thoroughly before assembly and operation, and keep it for future reference.

Important Safety Warnings:

- Do not place heavy objects on the desk that exceed the maximum load capacity of 80 kg.
- Do not place the table directly against a wall during lifting and lowering to avoid scratches.
- The table is designed for indoor use only.
- Keep all electrical components away from liquids.
- If the table is raised or lowered continuously for 2 minutes, the overheating protection will activate. Wait at least 18 minutes before resuming height adjustment.
- To protect the tabletop from impacts and scratches, set the integrated sensor to a higher value to detect solid objects during height adjustment.
- Do not disassemble any parts of this product without professional advice.
- Do not use power outlets or adapters with excessively high voltage.

2. Product Overview

The VASAGLE Electric Adjustable Desk is designed to provide a flexible and ergonomic workspace, allowing you to easily switch between sitting and standing positions. Its robust construction ensures stability and durability.

Key Features:

- **Multifunctional Control Panel:** Adjust height between 72 and 120 cm, memorize 4 height settings, and charge devices via the integrated USB port.
- **Storage Pouch & Hook:** A fabric pouch can be attached to either side for books and supplies. A reversible double hook provides space for headphones or bags.
- **Anti-Collision Protection:** For safety, the mechanism stops and slightly retracts the tabletop if it encounters an obstacle during adjustment.
- **Stable & Quiet Operation:** Features double support bars and steel legs with adjustable feet (or optional casters), supporting up to 80 kg with minimal noise during adjustment.

Included Components:

- 1 x Electric Desk
- 1 x Adapter
- 1 x Control Panel
- 1 x Storage Pouch
- 1 x Double Hook
- 1 x Assembly Kit
- 1 x Instruction Manual



Image: The VASAGLE Sit-Stand Electric Adjustable Desk, showcasing its spacious rustic brown tabletop, black steel legs, and

integrated accessories like a headphone hook and storage pouch.



Image: A closer view of the VASAGLE desk, highlighting the included storage pouch and headphone hook, along with the control panel.

3. Setup

The desk comes with an assembly kit and illustrated instructions to guide you through the setup process. Ensure all components are present before beginning assembly.

Assembly Guidelines:

- Follow the step-by-step instructions provided in the included manual.
- Use the numbered parts to ensure correct assembly.
- Ensure all screws and fasteners are securely tightened before use.

Placement Considerations:

- Place the desk on a flat, stable surface.
- Ensure there is sufficient clearance around the desk, especially when adjusting height, to prevent scratching walls or damaging other objects.
- Keep the desk away from direct sunlight, heat sources, and moisture.





Image: A diagram illustrating the dimensions of the desk: 160 cm length, 70 cm depth, and adjustable height from 72-120 cm.



Image: This image demonstrates the two options for the desk's base: swivel casters for mobility (Option A) and adjustable leveling feet for stability (Option B).

4. Operating Instructions

Your VASAGLE electric desk is equipped with an intuitive control panel for easy height adjustment and other functions.

Height Adjustment:

- Use the **Up (▲)** and **Down (▼)** buttons on the control panel to smoothly adjust the desk height between 72 cm (sitting) and 120 cm (standing).

Memory Function:

- The desk allows you to save up to 4 preferred height settings.
- To save a height: Adjust the desk to your desired height, then press one of the memory buttons (**M1, M2, M3, M4**) until the display flashes or a beep is heard.
- To recall a saved height: Simply press the corresponding memory button (**M1, M2, M3, M4**), and the desk will automatically move to that position.

USB Charging Port:

- A convenient USB port is integrated into the control panel for charging your phone or other small electronic devices.

Anti-Collision Mechanism:

- The desk is equipped with an anti-collision sensor. If the tabletop encounters a hard obstacle during height adjustment, the mechanism will stop and slightly retract the desk to prevent damage.
- You can adjust the sensitivity of this sensor (refer to troubleshooting for details).



Image: A detailed view of the multifunctional control panel, showing the USB port, height adjustment buttons, memory buttons (M1-M4), and LED display.

Design facile da usare

La regolazione dell'altezza si arresta e si ritrae leggermente quando il piano incontra un ostacolo duro




Image: This diagram visually explains the anti-collision feature, showing how the desk stops and retracts when an obstacle is detected during height adjustment.



Image: This image demonstrates the desk's height adjustability, showing a user comfortably working in both sitting and standing positions.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your electric desk.

General Cleaning:

- Wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage

the finish.

- Ensure all electrical components remain dry. Do not spray liquids directly onto the control panel or motor.

Motor Usage Guidelines:

- To prevent motor damage, avoid continuous height adjustment for more than 2 minutes. If operated continuously for this duration, the motor's overheating protection will activate.
- Allow the motor to rest for at least 18 minutes after 2 minutes of continuous operation before resuming height adjustments.

6. Troubleshooting

This section addresses common issues you might encounter with your electric desk.

Common Issues & Solutions:

- **Desk not moving:**
  - Check if the power adapter is securely plugged into both the desk and a working power outlet.
  - Ensure no cables are tangled or obstructing the motor mechanism.
  - If the desk was operated continuously for 2 minutes, the overheating protection might be active. Wait 18 minutes for the motor to cool down.
- **Anti-collision feature too sensitive/not sensitive enough:**
  - The integrated sensor's sensitivity can be adjusted. Refer to the detailed instructions in your assembly manual for specific steps on how to modify this setting. Increasing the value makes it more sensitive to detect obstacles.
- **Desk making unusual noises:**
  - While the desk is designed for quiet operation, minor sounds during adjustment are normal. If you hear loud or grinding noises, stop operation immediately.
  - Check for any obstructions in the lifting mechanism.
  - Ensure all assembly screws are tight.
- **Desk not reaching desired height:**
  - Verify that the desk is not overloaded beyond its 80 kg static load capacity.
  - Ensure there are no physical obstructions preventing the desk from reaching its full range of motion.

If you encounter issues not covered here or if troubleshooting steps do not resolve the problem, please contact customer support.

7. Specifications

Detailed technical specifications for the VASAGLE Sit-Stand Electric Adjustable Desk.

Attribute	Value
Brand	VASAGLE

Attribute	Value
Model Number	LSD176X01
Color	Rustic Brown
Product Dimensions (L x W x H)	160 x 60 x (72-120) cm
Material	Particle Board, Steel, Oxford Fabric
Features	Reversible, Electric Adjustable, 4-Height Memory, USB Port, Anti-Collision
Item Weight	35 Kilograms
Maximum Static Load Capacity	80 kg
Noise Level (during adjustment)	< 50 dB
Height Adjustment Speed	35 mm/s
Desk Design	Standing Desk
Style	Rustic
Room Type	Office





Image: This image highlights the flexible organization options, including the fabric organizer for notebooks and pens, and three practical hooks for headphones, bags, and charging cables.



Image: A wide shot of the desk, demonstrating its ample surface area capable of accommodating multiple monitors, laptops, and other work essentials.

8. Warranty and Support

For any questions, concerns, or issues not covered in this manual, please contact VASAGLE customer support.

Spare Parts Availability:

Information regarding the availability of spare parts for this product is currently unavailable.

Customer Support:

Please refer to the contact information provided at the point of purchase or on the official VASAGLE website for support. When contacting support, please have your model number (LSD176X01) and purchase details ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF29CLCP

More documents and user manuals: **https://manuals.plus/**