

PEXMOR B0CF2D1PSM

PEXMOR Foldable Indoor Basketball Arcade Game Set

Model: B0CF2D1PSM

INTRODUCTION

Thank you for purchasing the PEXMOR Foldable Indoor Basketball Arcade Game Set. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your new game set. Please read these instructions carefully before initial use to ensure safe and enjoyable play.

IMPORTANT SAFETY INFORMATION

To reduce the risk of serious injury, please observe the following safety precautions:

- Adult supervision is recommended, especially for younger users.
- This product is recommended for ages 12 years and up.
- Ensure all parts are correctly assembled and securely fastened before each use. Regularly check for loose bolts or damaged components.
- Do not hang on the basketball rim or frame.
- Keep hands and fingers clear of moving parts during folding and unfolding.
- Use only the provided basketballs or balls of similar size and weight.
- Do not modify the product in any way.
- Keep the product away from water and excessive moisture.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- 1 x Foldable Basketball Arcade Frame
- 1 x Electronic Scoreboard
- 3 x Mini Basketballs
- 1 x Air Pump
- Assembly Hardware (bolts, nuts, washers, etc.)

HOURS OF FAMILY FUN



Image: Included accessories - mini basketballs, air pump, and electronic scoreboard detail.

ASSEMBLY AND SETUP

Assembly typically requires two adults. Follow the numbered steps in the included detailed installation manual. Ensure you identify each part correctly using the numbers taped on the iron tubes.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify all parts against the package contents list.
2. **Assemble Frame:** Begin by connecting the main frame pieces. Pay close attention to the orientation of each bar, especially curved or angled pieces, to ensure proper alignment. Secure connections with the provided bolts and washers. *(Note: Some users have reported issues with hole alignment; ensure parts are not forced and check for any internal obstructions like metal shavings before assembly.)*
3. **Attach Backboard and Rim:** Secure the premium MDF backboard to the frame, followed by the steel rim and net.
4. **Install Ball Return Ramp:** Attach the waterproof Oxford cloth ball return ramp to the frame.
5. **Mount Electronic Scoreboard:** Install the electronic scoreboard in its designated position. Ensure it is securely attached and that the infrared sensors are unobstructed.

6. **Inflate Basketballs:** Use the provided air pump to inflate the mini basketballs to the recommended pressure.
7. **Final Check:** Before first use, double-check all bolts and connections to ensure they are tight and secure.





Image: The PEXMOR basketball arcade game fully assembled.

SPACE-SAVING DESIGN



Image: Assembled and storage dimensions of the game set.

OPERATION

The PEXMOR Foldable Indoor Basketball Arcade Game Set is designed for single-player use, offering an engaging arcade experience.

- **Power On:** Locate the power switch on the electronic scoreboard and turn it on.

- **Start Game:** The scoreboard will typically display a countdown or be ready for play.
- **Shoot Baskets:** Throw the mini basketballs towards the hoop. The proprietary infrared sensors will detect successful shots and automatically update the score on the digital display.
- **Sound Effects:** The game features integrated sound effects to enhance the playing experience.
- **Ball Return:** Missed shots and successful baskets will roll down the Oxford cloth ramp, returning the balls to the player for continuous play.
- **End Game:** The game typically has a timed mode. Once the timer runs out, the final score will be displayed. Turn off the scoreboard when not in use to conserve battery life.



Image: Users enjoying the PEXMOR basketball arcade game.



Image: A child playing the PEXMOR basketball arcade game.

MAINTENANCE

Regular maintenance will extend the life and performance of your PEXMOR basketball arcade game.

- **Cleaning:** Wipe down the frame, backboard, and ball return ramp with a damp cloth. Avoid abrasive cleaners or solvents.
- **Check Connections:** Periodically inspect all bolts, nuts, and connections to ensure they remain tight. Tighten any loose hardware.
- **Ball Inflation:** Check the inflation of the mini basketballs regularly and re-inflate with the air pump as needed.
- **Storage:** The game features a quick-folding design for compact storage. To fold, pull out the pin beneath the frame to collapse it. This saves up to 60% of space. Store in a dry place away from direct sunlight and extreme temperatures.

EASY & COMPACT STORAGE



Image: The game set folded for compact storage.

EASY & COMPACT STORAGE




Image: Slim profile of the game set in folded position.

TROUBLESHOOTING

If you encounter issues with your PEXMOR basketball arcade game, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Electronic scoreboard not turning on.	Batteries are dead or incorrectly installed.	Check battery compartment for correct polarity and replace batteries if necessary.
Scoreboard not registering shots accurately.	Infrared sensors are obstructed or dirty.	Ensure nothing is blocking the sensors. Gently clean sensors with a soft, dry cloth.
Game feels unstable or wobbly.	Loose assembly bolts or uneven surface.	Tighten all assembly bolts. Ensure the game is placed on a flat, level surface. Check that anti-slip pads are intact.

Problem	Possible Cause	Solution
Balls do not return smoothly.	Obstruction in the ball return ramp or ramp is not properly aligned.	Check the Oxford cloth ramp for any debris or wrinkles. Ensure the ramp is securely attached and properly angled.
Missing or damaged parts during assembly.	Manufacturing defect or shipping damage.	Do not attempt to force parts. Contact PEXMOR customer support immediately for replacement parts.



Image: Rear view of the electronic scoreboard, indicating sound output.

SPECIFICATIONS

- **Model:** B0CF2D1PSM
- **Brand:** PEXMOR
- **Assembled Dimensions (L x W x H):** Approximately 82" x 24.5" x 82" (Length x Width x Height)
- **Folded Dimensions (L x W x H):** Approximately 24.5" x 35" x 82" (Length x Width x Height)
- **Frame Material:** Durable Steel
- **Backboard Material:** Premium MDF (Medium-Density Fiberboard)
- **Ball Return Material:** Waterproof Oxford Cloth
- **Scoring System:** Electronic with Proprietary Infrared Sensors
- **Included Accessories:** 3 x Mini Basketballs, 1 x Air Pump
- **Recommended Age:** 12 years and up

Sturdy Construction

- ✓ Stable Triangle
- ✓ Steel Frame
- ✓ Rubber Feet



Shatterproof MDF Backboard



Stable Steel Rim



Waterproof Oxford Cloth



Anti-slip Foot Pad

Image: Features highlighting sturdy construction and materials.

WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, please refer to the warranty card included with your purchase or contact PEXMOR customer service directly. PEXMOR is committed to providing quality products and support.

If you have any questions, require assistance with assembly, or need replacement parts, please contact PEXMOR customer support through their official channels. Please have your product model number (B0CF2D1PSM) and purchase date available when contacting support.

Contact information for PEXMOR can typically be found on their official website or through the retailer where the product was purchased.

© 2023 PEXMOR. All rights reserved.
This manual is subject to change without notice.

Related Documents - B0CF2D1PSM








ELECTRIC BICYCLE USER MANUAL



Thank you for your purchase.
Please contact us if you have difficulty with assembly or need replacement parts.
Please Contact Service to learn to use you.
Email: support@pexmor.com Website: www.pexmor.com
Please attach your Order number or Order ID so that we can assist you better.

[Pexmor Electric Bicycle User Manual](#)

Comprehensive user manual for the Pexmor Electric Bicycle, covering safety information, specifications, assembly instructions, maintenance, LCD instrument usage, warranty, and troubleshooting.

 <p>Thank you for your purchase. Please contact us if you have difficulty with assembly or need replacement parts. Pexmor Customer Service is here to assist you. Email: support@pexmor.com Website: www.pexmor.com Please attach your Order number or Order ID so that we can assist you better.</p>	<p>Pexmor Electric Bicycle User Manual</p> <p>User manual for the Pexmor Electric Bicycle, covering assembly, specifications, maintenance, LCD instrument usage, warranty, and FAQs.</p>
 <p>Thank you for your purchase. Please contact us if you have difficulty with assembly or need replacement parts. Pexmor Customer Service is here to assist you. Email: support@pexmor.com Website: www.pexmor.com Please attach your Order number or Order ID so that we can assist you better.</p>	<p>Pexmor Electric Bicycle User Manual: Assembly, Operation, and Maintenance Guide</p> <p>Comprehensive user manual for the Pexmor electric bicycle, covering assembly instructions, detailed operation modes, maintenance tips, specifications, warranty information, and frequently asked questions.</p>
 <p>Thank you for your purchase. Please contact us if you have difficulty with assembly or need replacement parts. Pexmor Customer Service is here to assist you. Email: support@pexmor.com Website: www.pexmor.com Please attach your Order number or Order ID so that we can assist you better.</p>	<p>PEXMOR Electric Bicycle User Manual</p> <p>Comprehensive user manual for the PEXMOR electric bicycle, covering safety guidelines, specifications, parts list, assembly instructions, maintenance procedures, LCD instrument operation, warranty information, and frequently asked questions.</p>
 <p>Thank you for your purchase. Please contact us if you have difficulty with assembly or need replacement parts. Pexmor Customer Service is here to assist you. Email: support@pexmor.com Website: www.pexmor.com Please attach your Order number or Order ID so that we can assist you better.</p>	<p>Pexmor Electric Bicycle User Manual and Assembly Guide</p> <p>Comprehensive user manual for the Pexmor electric bicycle, covering assembly, specifications, maintenance, LCD instrument usage, warranty, and troubleshooting. Learn how to set up and operate your 750W, 48V e-bike.</p>
 <p>Thank you for your purchase. Please contact us if you have difficulty with assembly or need replacement parts. Pexmor Customer Service is here to assist you. Email: support@pexmor.com Website: www.pexmor.com Please attach your Order number or Order ID so that we can assist you better.</p>	<p>Pexmor Electric Bicycle User Manual: Assembly, Operation, and Maintenance</p> <p>Comprehensive user manual for the Pexmor electric bicycle, covering assembly instructions, LCD instrument operation, maintenance tips, warranty information, and troubleshooting FAQs.</p>