

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-150 Baby Hair Clippers Instruction Manual](#)

## VGR V-150

# VGR V-150 Baby Hair Clippers Instruction Manual

Model: V-150

## INTRODUCTION

---

Welcome to the VGR V-150 Baby Hair Clippers instruction manual. This guide provides essential information for the safe and effective use, maintenance, and care of your new hair clipper. Please read thoroughly before first use to ensure optimal performance and safety.

## SAFETY INFORMATION

---

For the safety of the user and the child, please observe the following precautions:

- Avoid use on infants without proper adult supervision.
- Keep the device away from water sources when not actively being cleaned or if the charging port cover is not securely closed.
- Follow all recommended cleaning and maintenance procedures to prevent injury or malfunction.
- Do not attempt to disassemble or repair the clipper yourself. Contact customer support for assistance.

## PACKAGE CONTENTS

---

Please verify that all items are present in your VGR V-150 Baby Hair Clippers package:

- 1 x VGR V-150 Hair Clipper
- 3 x Guide Combs (1mm, 3-6mm, 9-12mm)
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle
- 1 x USB Charging Cable



Image: The VGR V-150 Hair Clipper shown with its complete set of accessories, including guide combs, cleaning brush, oil bottle, and USB charging cable.

## PRODUCT FEATURES


The VGR V-150 Baby Hair Clippers are designed with specific features for safe and comfortable use on infants and toddlers:

- **Professional Hair Clippers with Safe Combs:** Equipped with a sharp and safe ceramic blade. Each tooth of the blade is rounded to prevent pulling hair and protect sensitive skin. Includes three guide combs for various hair lengths (1mm, 3-6mm, 9-12mm). The 1mm comb offers an additional layer of protection for very young children.
- **IPX-7 Waterproof:** The entire body of the clipper is waterproof, allowing for easy cleaning under running water. This feature simplifies maintenance and ensures hygiene.
- **Ultra Quiet Operation:** Utilizes advanced noise reduction technology and a high-quality brass movement motor to operate at approximately 48dB. This low noise level helps keep children relaxed during haircuts.
- **Safe and Comfortable Design:** Features an R-shaped blade design with widened rounded tips and a ceramic blade. With a 0.5mm gap to the skin, the ceramic blade is specifically designed for babies aged 0-12 years, preventing harm or scratches to sensitive skin.

**VGR**<sup>®</sup>  
V O Y A G E R



USB  
charging



Length  
adjustable



Fully  
washable



Low  
noise



Image: An illustration of the VGR V-150 Hair Clipper, emphasizing its USB charging capability, adjustable length settings, full washability, and low noise operation.



# PROFESSIONAL CERAMIC BLADE HEAD

SPECIALLY FOR THE BABY'S SOFT HAIR  
DO NOT HURT HAIR




Image: A detailed view of the VGR V-150's professional ceramic blade head, designed for soft baby hair without causing irritation.

## SETUP

### Charging the Clipper

Before initial use, ensure the clipper is fully charged to achieve optimal performance.

1. Connect the USB charging cable to the charging port located at the bottom of the clipper.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. The indicator light on the clipper will illuminate to show charging status. A full charge typically takes approximately 5 hours and provides up to 60 minutes of continuous operating time.

### Attaching Guide Combs

Select the appropriate guide comb based on the desired hair length.

1. Ensure the clipper is turned off before attaching or detaching combs.
2. Align the chosen guide comb (1mm, 3-6mm, or 9-12mm) with the clipper head.

3. Gently push the comb onto the clipper head until it securely clicks into place.
4. To remove, gently pull the comb away from the clipper head.



Image: The VGR V-150 Hair Clipper demonstrating the use of different guide combs for various hair lengths: 0mm (without comb), 3-6mm, and 9-12mm.

## OPERATING INSTRUCTIONS

### Preparing for Haircut

Creating a calm environment is crucial for a successful haircut, especially with young children.

- We recommend first allowing your child to touch the clipper and turning it on briefly to familiarize them with its sound.
- You may distract the child by playing videos or engaging them with toys during the haircut.
- For very sensitive children, consider cutting their hair while they are sleeping due to the clipper's ultra-quiet operation.

### Hair Cutting Procedure

Follow these steps for an effective and safe haircut:

1. Ensure the desired guide comb is securely attached.
2. Turn on the clipper by pressing the power button.
3. Hold the clipper at a slight angle against the hair.
4. Move the clipper slowly and steadily against the direction of hair growth. Avoid pressing too hard against the scalp.
5. For consistent results, make overlapping passes.
6. Regularly clear any accumulated hair from the blade area using the cleaning brush during the haircut to maintain optimal cutting performance.
7. Once finished, turn off the clipper.



Image: A close-up view of the VGR V-150's ceramic blade in action, demonstrating its ability to cut hair smoothly.

## MAINTENANCE

Proper maintenance ensures the longevity and hygiene of your VGR V-150 Hair Clippers.

### Cleaning

The IPX-7 waterproof design makes cleaning simple and thorough.

1. After each use, turn off the clipper and detach the guide comb.
2. Use the provided cleaning brush to remove any loose hairs from the blade and the clipper body.
3. Rinse the clipper head and body under running water. Ensure the charging port cover is securely closed if rinsing the entire unit.
4. Allow the clipper to air dry completely before storing or recharging. Do not use hot air or direct sunlight for drying.



Image: The VGR V-150 Hair Clipper being rinsed under water, illustrating its IPX-7 waterproof capability for easy cleaning.

## Lubrication

Regular lubrication of the blades is essential for smooth operation and to extend the life of your clipper.

1. After cleaning and ensuring the blades are dry, apply a few drops of the provided lubricating oil to the teeth of the blades.
2. Turn on the clipper for approximately 10-15 seconds to allow the oil to distribute evenly across the blades.
3. Wipe off any excess oil with a soft cloth.

## TROUBLESHOOTING

If you encounter any issues with your VGR V-150 Hair Clippers, refer to the following common problems and solutions:

- **Clipper not turning on:**

Ensure the clipper is fully charged. Connect it to the USB charging cable and allow sufficient time for charging. Verify that the power button is being pressed correctly.

- **Poor cutting performance or pulling hair:**

Clean the blades thoroughly to remove any accumulated hair or debris. Lubricate the blades as described in the Maintenance section. Ensure the guide comb is correctly attached and not damaged. The blades may require replacement if they are dull (contact customer support).

- **Excessive noise or vibration:**

Clean and lubricate the blades. Ensure no foreign objects are lodged in the blade mechanism. If the issue persists after cleaning and lubrication, contact customer support.

- **Clipper not holding a charge:**

Ensure the USB charging cable and power adapter are functioning correctly. Try a different charging source. If the battery life has significantly diminished, it may indicate the end of the battery's lifespan.

## SPECIFICATIONS

<b>Brand</b>	VGR
<b>Model</b>	V-150
<b>Blade Material</b>	Ceramic
<b>Power Source</b>	Battery Powered (Rechargeable)
<b>Waterproof Rating</b>	IPX-7
<b>Charging Time</b>	Approximately 5 hours
<b>Operating Time</b>	Approximately 60 minutes
<b>Noise Level</b>	Approximately 48dB
<b>Product Dimensions</b>	18 x 16 x 5 cm
<b>Item Weight</b>	270 Grams
<b>Special Features</b>	Detachable Head, USB Charging

## WARRANTY AND SUPPORT

For detailed warranty information, technical support, or service inquiries regarding your VGR V-150 Baby Hair Clippers, please refer to the product packaging or contact VGR customer service directly. It is recommended to retain your purchase receipt as proof of purchase for any warranty claims.



[VGR V-085 Professional Hair Trimmer Manual and Safety Instructions](#)

This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.



[VGR V-990 Cordless Hair Trimmer User Guide](#)

Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.



[VGR V-085 Professional Hair Trimmer User Manual & Safety Instructions](#)

This document provides comprehensive safety instructions, component descriptions, usage guidelines, charging, cleaning, and maintenance information for the VGR V-085 Professional Hair Trimmer.



[VGR V-9821 Professional Hair Trimmer User Manual](#)

Comprehensive user guide for the VGR V-9821 Professional Hair Trimmer, covering components, safety instructions, usage, USB charging, cleaning, maintenance, and technical specifications.



[VGR V-282 Professional Hair Clipper User Manual and Specifications](#)

Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.



[VGR V-906 Professional Hair Trimmer User Manual](#)

Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.