

- [Manuals.plus](#) /
- › [fullstar](#) /
 - › Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper Instruction Manual

fullstar 2-in-1

Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper

Model: 2-in-1 | Brand: Fullstar

INTRODUCTION

Thank you for choosing the Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper. This manual provides essential information for the safe and efficient use, maintenance, and care of your new kitchen tool. Please read these instructions thoroughly before first use and retain them for future reference.



Image: The Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper, ready for use.

PRODUCT COMPONENTS

The Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper includes the following components:

- Chopper Lid with integrated pushing grid
- Collection Container (1.2 L capacity)
- Fine Dicing Blade (0.6 cm)
- Medium Dicing Blade (1.3 cm)
- Cleaning Brush

2 coupes de précision



Coupe-légumes fin 0,6 cm Coupe-légumes moyen 1,3 cm

Image: The two interchangeable precision cutting blades (0.6 cm and 1.3 cm) for different dicing sizes.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash:** Before first use, wash all parts with warm soapy water. Rinse thoroughly and dry.
3. **Select Blade:** Choose the desired dicing blade (fine or medium) based on your recipe.
4. **Insert Blade:** Place the selected blade securely into the designated slot on the collection container. Ensure it clicks into place.
5. **Attach Lid:** Align the chopper lid with the collection container and press down firmly until it locks.

fullstar

The Original Pro Chopper



Conçu pour une performance durable

Image: Assembling the chopper by inserting a blade and attaching the lid.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut vegetables or fruits into pieces that fit onto the blade grid. For best results, ensure ingredients are firm.
2. **Position Ingredient:** Place the prepared ingredient onto the center of the chosen blade.
3. **Chop:** Firmly and quickly press down the chopper lid. The ingredient will be pushed through the blade and into the collection container.
4. **Repeat:** Continue chopping until all ingredients are processed.

Safety Tip: Always use caution when handling the sharp blades. Use the included cleaning brush for blade maintenance to avoid direct contact with fingers.



fullstar

Vos plats préférés, à
seulement quelques
minutes

Image: Demonstrating the chopping action with bell peppers.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your vegetable chopper.

- **Disassembly:** After use, carefully detach the chopper lid and remove the blade from the collection container.
- **Hand Washing:** Wash all components with warm, soapy water. Use the provided cleaning brush to remove any food particles from the blades and grid. Rinse thoroughly.
- **Dishwasher Safe:** All components are dishwasher safe. Place them on the top rack of your dishwasher for cleaning.
- **Drying:** Ensure all parts are completely dry before reassembling or storing.
- **Storage:** Store the chopper in a safe place, with blades securely stored within the unit or in their protective covers, away from children.



Image: Fullstar chopper parts in a dishwasher, highlighting its dishwasher-safe feature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Difficulty pressing down the lid.	Ingredient is too large or too hard.	Cut ingredients into smaller pieces. For very hard vegetables (e.g., raw carrots), consider pre-boiling slightly or using a different cutting method.
Food gets stuck in the blades.	Insufficient force applied, or sticky ingredients.	Apply firm, quick pressure. Use the cleaning brush to dislodge stuck food.

Problem	Possible Cause	Solution
Chopper slides on the countertop.	Non-slip base is wet or countertop is slippery.	Ensure both the chopper's base and the countertop are dry and clean.

SPECIFICATIONS

- Brand:** Fullstar
- Model:** 2-in-1
- Product Dimensions:** 26.2L x 11.5W x 9.6H cm
- Material:** Stainless Steel, Plastic (BPA-free, PFAS-free)
- Color:** Black
- Special Features:** Removable Blades, Interchangeable Blades, Multifunctional, Highly Durable, Safety Lock
- Recommended Use:** Vegetable Chopping
- Care Instructions:** Dishwasher Safe
- Blade Material:** 420 Stainless Steel
- Operation Mode:** Manual
- Collection Container Capacity:** 1.2 Liters
- Included Components:** Chopper Lid, Collection Container, 2 Dicing Blades, Cleaning Brush

Bac familial de 1,2 L



Image: The 1.2L collection container, demonstrating its capacity for meal prep.

SAFETY INFORMATION

- **Sharp Blades:** Blades are extremely sharp. Always handle with extreme care. Keep fingers away from the cutting surfaces.
- **Children:** Keep the product and its components out of reach of children.
- **Stable Surface:** Always use the chopper on a stable, flat, and dry surface to prevent slipping.
- **Intended Use:** Use this product only for its intended purpose of chopping vegetables and fruits. Do not attempt to chop frozen foods, bones, or other hard items.
- **Material Safety:** The product is made from BPA-free and PFAS-free materials, ensuring food safety.

Construction de qualité supérieure



Sûr par conception. Matériau 100% sans danger pour les aliments



BPA
FREE



PFAS
FREE

Image: Detail of the chopper's construction, emphasizing BPA-free and PFAS-free materials for safety.

WARRANTY AND SUPPORT

Fullstar products are designed for durability and performance. For any questions, concerns, or support needs regarding your Fullstar Pro Original 2-in-1 Multifunction Vegetable Chopper, please contact Fullstar customer service.

While specific warranty details are not provided in this manual, please refer to the product packaging or the official Fullstar website for the most up-to-date warranty information and customer support contacts.

Online Support: Visit the [Fullstar Brand Store on Amazon](#) for additional product information and support resources.

© 2026 Fullstar. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CF2NQ11W>

More documents and user manuals: **<https://manuals.plus/>**