

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Madesa](#) /

› [Madesa 9425CF Gaming Computer Desk Instruction Manual](#)

Madesa 9425CF

Madesa 9425CF Gaming Computer Desk Instruction Manual

Model: 9425CF

1. INTRODUCTION

Thank you for purchasing the Madesa 9425CF Gaming Computer Desk. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- Always follow assembly instructions precisely.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the recommended weight capacities: Tabletop: 44 lbs (20 kg), Each Shelf: 11 lbs (5 kg) for the upper shelf, 18 lbs (8 kg) for the lower shelf.
- Keep small parts and packaging materials away from children.
- Proper anchoring is recommended for enhanced stability.

2. PACKAGE CONTENTS

Before assembly, verify that all components and hardware are present. Refer to the included user-friendly illustrated instructions for a detailed list of parts and hardware.



Figure 2.1: Example of furniture assembly. Ensure all parts are accounted for before starting.

3. SETUP AND ASSEMBLY

Assembly of the Madesa Gaming Computer Desk requires basic tools and can be completed by one person. Detailed illustrated instructions and all necessary hardware are included in the package. For visual guidance, scan the QR Code provided in your physical manual for video instructions.

Assembly Steps:

- Unpack and Identify:** Carefully unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches. Compare with the parts list in the included manual.
- Assemble Frame:** Follow the step-by-step diagrams to connect the main frame components using the provided screws and fasteners.
- Attach Shelves:** Secure the two open shelves to the side structure. Note that the shelves can be positioned on either side of the desk during assembly to suit your preference.
- Install Headphone Hanger:** Attach the headphone hanger to the designated location on the side panel.
- Final Tightening:** Once all parts are assembled, gently tighten all screws to ensure stability. Avoid over-tightening to prevent damage to the engineered wood.

Your browser does not support the video tag.

Video 3.1: An official Madesa video demonstrating the assembly and features of the desk. This video provides a visual guide to the setup process.

4. OPERATING AND USAGE

The Madesa Gaming Computer Desk is designed for versatile use in gaming, home office, or study environments. Its compact design and integrated features enhance functionality.

Key Features:

- Spacious Desktop:** Provides ample space for monitors, keyboards, and other peripherals.
- Two Open Shelves:** Ideal for storing gaming accessories, books, or decorative items. The lower shelf is suitable for a computer tower.
- Headphone Hanger:** Conveniently located for easy access and storage of headphones.
- Cable Management:** Features holes in the back panel to route and organize cables, maintaining a tidy workspace.




Figure 4.1: The Madesa Gaming Computer Desk set up with a monitor, gaming PC, and accessories, demonstrating its functional layout.

5. MAINTENANCE

To ensure the longevity and appearance of your Madesa Gaming Computer Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Heat and Moisture:** Protect the desk from direct heat sources and excessive moisture. Use coasters for drinks.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten if any looseness is detected.

6. TROUBLESHOOTING

If you encounter any issues with your Madesa Gaming Computer Desk, refer to the following common solutions:

Common Issues:

- **Desk feels wobbly:** Ensure all assembly screws are fully tightened. Check that the desk is placed on a level surface.
- **Parts do not fit:** Double-check the assembly instructions to confirm that the correct parts are being used for each step and that they are oriented correctly. Do not force parts together.
- **Missing hardware:** Refer to the parts list in your manual. If hardware is missing, contact Madesa customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	9425CF
Brand	Madesa
Overall Dimensions (D x W x H)	21.25" x 39.37" x 29.52" (54cm x 100cm x 75cm)
Tabletop Weight Capacity	44 lbs (20 kg)
Upper Shelf Weight Capacity	11 lbs (5 kg)
Lower Shelf Weight Capacity	18 lbs (8 kg)
Material	Engineered Wood (High Quality Particle Board)
Finish Type	Painted
Special Features	2 Open Shelves, Headphone Hanger, Cable Management
Assembly Required	Yes
Recommended Number of People for Assembly	1



Figure 7.1: Detailed dimensions of the Madesa 9425CF Gaming Computer Desk.

8. WARRANTY INFORMATION

The Madesa 9425CF Gaming Computer Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your purchase or contact Madesa customer support. This warranty typically covers manufacturing defects under normal use.

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Madesa customer support. Have your model number (9425CF) and purchase information ready when contacting support.

For further assistance, visit the official Madesa website or refer to the contact information provided in your product packaging.