

[Manuals.plus](#) /

› [ele ELEOPTION](#) /

› User Manual for ele ELEOPTION Kids Smart Phone Toy

ele ELEOPTION A16

User Manual for ele ELEOPTION Kids Smart Phone Toy

Model: A16

Brand: ele ELEOPTION

INTRODUCTION

This manual provides comprehensive instructions for the ele ELEOPTION Kids Smart Phone Toy, Model A16. This device is designed as an interactive learning toy for children aged 3 to 10 years, offering various educational and entertainment features, including a call function when a compatible SIM card is inserted. Please read this manual carefully to ensure proper use and maintenance of the product.

WHAT'S IN THE BOX

Upon unboxing, please verify that all components are present:

- 1 x Kids Phone
- 1 x Phone Case
- 1 x Portable Sling
- 1 x USB Charging Cable
- 1 x User Manual (this document)

Note: SIM card is not included and must be purchased separately.



Image: Main product image showing the phone, case, lanyard, and charging cable.

SETUP

1. SIM Card Installation (Optional for Call Function)

To enable the call function, a 2G Nano SIM card is required (not included). The SIM card must support 2G network and have calling functionality (GSM: B2 B3 B5 B8). Tello 2G Nano SIM card is recommended.

1. Locate the SIM card slot on the side of the phone.
2. Use the provided SIM ejector tool (or a small pin) to open the SIM tray.
3. Carefully place the Nano SIM card into the tray, ensuring correct orientation.
4. Insert the SIM tray back into the phone until it clicks into place.
5. After inserting the SIM card, activate it with your chosen carrier if necessary. Some carriers may require you to activate the SIM card using a different device first, as this toy phone does not display an IMEI number directly for activation purposes.



Image: Illustration of SIM card compatibility and a child using the phone.

Your browser does not support the video tag.

Video: Demonstrates how to insert the SIM card and make a call on the toy phone.

2. Charging the Device

The device comes with a built-in Lithium Metal battery. Before first use, fully charge the phone. A full charge provides approximately 4-5 hours of continuous use.

- Connect the provided USB charging cable to the phone's USB port.
- Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
- The charging indicator on the screen will show the charging status.
- Once fully charged, disconnect the cable.

OPERATING INSTRUCTIONS

1. Device Overview and Basic Navigation

Familiarize yourself with the phone's physical features and basic screen navigation:

Kids Phone Key Guide




Image: Diagram showing key components and their labels on the toy phone.

- **Power On/Off:** Press and hold the Home (On/off/back) button.
- **Touch Screen:** Navigate through menus and applications by tapping or swiping on the 2.8-inch ultra-clear touch screen.
- **Home Button:** Press to return to the home screen or to go back in an application.
- **Volume Buttons:** Adjust the device's sound volume.

2. Making and Receiving Calls

The phone allows making and receiving calls from pre-saved numbers. This feature is active only with a properly installed and activated 2G Nano SIM card.

1. From the home screen, tap the "Contacts" icon.
2. Select a pre-saved contact to initiate a call.
3. To receive a call, simply tap the green answer button when the phone rings.


Follow Tiger Lily's way, Activate the phone SIM card and use the calling function of the phone



★★★★★ Makes phone calls!

Size: Black | Verified Purchase

I ordered the phone for Christmas and wanted to find a sim card before it arrived. The phone needs a 2g sim card. T-mobile store didn't sell them but she advised to try the traveler's sim. I looked on Amazon and found the Tello sim card for 2\$ that says in the description that it supports 2g. When I received the card and inserted it in the phone it did not work because I had to insert the IMEI to activate and this phone doesn't have one. So I inserted the sim in my iPhone, activated the card and since i was connected to wifi I was able to go to Tello website and bought the cheapest plan (100 minutes 5\$ per month, no data). The sim didn't make calls from my iPhone because it said I should change settings which I didn't want to do. So I put back the sim in the toy phone and it worked! It does make phone call, it took a few minutes after we turned it on to work but it did and now we have been using it for a week with no problems. Just note that it does not really show signal on the top left of the screen, sometimes just one or 2 lines but most of the time no lines as if there was no signal.



The SIM Card Must Support 2G Network and Have Calling Function

Image: Depiction of a child and an adult communicating using the toy phone's call function.

3. Camera and Video Recording

The phone features front and rear dual cameras for capturing photos and videos.

- Tap the "Camera" icon to open the camera application.
- Switch between front and rear cameras as desired.
- Tap the shutter button to take a photo or the record button to start/stop video recording.
- Access captured media through the "Photos" or "Video" applications.



Image: Features of the dual cameras and fun photo effects.

4. Educational and Entertainment Features

The phone comes with 8GB of pre-installed memory, offering a variety of educational and entertainment applications:

- **Games:** Includes 19 kinds of educational games and 21 funny puzzle games (e.g., Basketball Shoot Master, Bee War, Car Grab Goods, Eliminate Same Animals, 2048, Ultimate Racing, Pinball Hit Bricks, Sweet Together, Can't Washing Hands, Tooth Brushing Fight, Princess Dress Up, Mora).
- **Learning:** Features 26 alphabet learning activities, 22 world landmarks, and audiobook functionality.
- **Tools:** Recorder, pedometer, calculator, and calendar.
- **Music:** Play pre-installed music or downloaded audio files.
- **Customization:** Choose from 27 different themes/topics to personalize the phone's appearance.

KIDS SMART PHONE TOY



Image: Overview of the various applications and features available on the toy phone.

ABC Learning



22 Landmarks



LEARNING THROUGH PLAY



Habit Tracking Alarm



8 Fable Stories

Image: Examples of learning activities available on the phone.



Image: Display of the various puzzle games included on the phone.

MORE STYLE, MORE FUN

27 TOPICS TO CHOOSE FROM



Image: Examples of customizable themes for the phone's interface.

MAINTENANCE

1. Cleaning

To clean the device, use a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the screen or casing. Ensure the device is powered off before cleaning.

2. Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not leave the device uncharged for extended periods.
- Use only the provided charging cable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cannot make calls after SIM card insertion.	SIM card not activated, incorrect SIM card type (not 2G Nano), or SIM card does not support 2G network.	Ensure the SIM card is a 2G Nano SIM and supports GSM: B2 B3 B5 B8. Activate the SIM card with your carrier, potentially using another device if direct activation on the toy phone is not supported.
Phone does not turn on or charge.	Battery fully depleted, faulty charging cable/adaptor, or internal issue.	Connect to a known working USB power source using the original charging cable. Allow a few minutes for the battery to show signs of life. If the issue persists, contact customer support.
Screen is unresponsive.	Temporary software glitch or physical damage.	Restart the device by holding the power button. If unresponsive, allow the battery to fully drain and then recharge. If the problem continues, contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	7.8 x 0.78 x 4.7 inches
Item Weight	7.8 ounces
Country of Origin	China
Item Model Number	A16
Manufacturer Recommended Age	36 months - 8 years
Batteries	1 Lithium Metal battery required (included)
Manufacturer	ELEOPTION
Memory	8GB pre-installed
SIM Card Support	2G Nano SIM (GSM: B2 B3 B5 B8)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the manufacturer, ele ELEOPTION, directly through their official channels or the retailer from whom the product was purchased. Keep your proof of purchase for any warranty claims.