

[Manuals.plus](#) /

> [Anker](#) /

> Anker MagGo 3-in-1 iPhone 16 Charging Station, MagSafe-Compatible Wireless Charger Stand, Qi2 Certified 15W Foldable Charger for iPhone 15/14, AirPods, Apple Watch 9 (40W USB-C Adapter Included) White

Anker A2557

Anker MagGo 3-in-1 Wireless Charging Station User Manual

Model: A2557

Your comprehensive guide to setting up, operating, and maintaining your Anker MagGo 3-in-1 Wireless Charging Station.

1. INTRODUCTION

The Anker MagGo 3-in-1 Wireless Charging Station is designed to provide convenient and efficient charging for your Apple devices, including iPhone, AirPods, and Apple Watch. Its foldable and compact design makes it ideal for both home and travel use.

2. WHAT'S IN THE BOX

Upon unboxing your Anker MagGo 3-in-1 Wireless Charging Station, you will find the following components:

- Anker MagGo Wireless Charging Station (Foldable 3-in-1)
- 40W USB-C charger
- 5 ft (1.5 m) USB-C to USB-C cable
- Welcome guide

3-in-1 Designed for Apple Devices



Note: 1. For watches with inflexible bands, unbuckle and place the watch module flat. 2. If the band cannot be unbuckled, adjust the position of the watch module or elevate the wireless charger for optimal charging.

Figure 2.1: Included components of the Anker MagGo 3-in-1 Wireless Charging Station.

3. SETUP GUIDE


To begin using your charging station, follow these simple steps:

1. Connect the provided 5 ft (1.5 m) USB-C to USB-C cable to the USB-C port on the Anker MagGo Wireless Charging


Station.

2. Plug the other end of the USB-C cable into the provided 40W USB-C charger.
3. Insert the 40W USB-C charger into a wall outlet. Ensure the power adapter is 30W or higher for optimal performance.
4. Unfold the charging station to its desired configuration for charging your devices.

Use a 30W or Higher Charger



30W or Higher Charger
Flashes Once, Then Turns Off



Charger Below 30W
Constant Flashing



Align the Watch Correctly on the Charger



Note: For optimal charging, use the included 40W USB-C PD wall charger.

Figure 3.1: Connecting the power adapter and ensuring sufficient wattage.

4. OPERATING INSTRUCTIONS

The Anker MagGo Wireless Charging Station allows you to charge up to three Apple devices simultaneously.

4.1 Charging Your iPhone

The front magnetic stand is Qi2 certified and MagSafe-compatible, providing 15W ultra-fast charging for your iPhone (iPhone 12 series and newer). Simply align your iPhone with the magnetic charging surface.



Figure 4.1: iPhone charging on the magnetic stand.

ANKER

The World's
NO.1
Mobile Charging Brand

Doubly Fast in a Snap

2X Faster*



Wireless PowerIQ | 15W

*Data based on internal testing,
charging an iPhone 15 Pro from 0 to 20% compared with a 7.5W wireless charger.

Figure 4.2: High-speed 15W charging capability.

4.2 Charging Your Apple Watch

The integrated Apple Watch charger is MFW certified, allowing you to quickly power up your Apple Watch Series 9 to 47% in just 30 minutes. Flip out the watch charging module and place your Apple Watch on it. For watches with non-detachable bands, elevate the watch module. For watches with detachable bands, unbuckle the strap and flatten the watch module for optimal charging.


Ultra-Compact Design

Similar in Size to an
Apple Magic Mouse for Easy Carrying



6.9 oz*

3.5 × 2.36 × 0.98 inches




*Data based on internal testing.
Different testing methods may result in varying weights.

Figure 4.3: Apple Watch fast charging.

4.3 Charging Your AirPods / Wireless Earbuds

The base of the charging station features a dedicated Qi wireless charging pad for your AirPods or other wireless earbuds. Simply place your earbuds in the center of the charging pad.

Use a 30W or Higher Charger




30W or Higher Charger
Flashes Once, Then Turns Off



Charger Below 30W
Constant Flashing



Align the Watch Correctly on the Charger



Note: For optimal charging, use the included 40W USB-C PD wall charger.

Figure 4.4: Overview of 3-in-1 charging capabilities.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Anker MagGo Wireless Charging Station, follow these maintenance guidelines:


- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe down the surfaces. Avoid using abrasive cleaners or solvents.
- **Safety Features:** The charging station is equipped with Anker's MultiProtect Safety System and ActiveShield 2.0 technology, which monitors temperature over 3,000,000 times per day to maintain optimal device temperature during 15W high-speed charging sessions. It also includes Foreign Object Detection, Radiation Shielding, Overcurrent Protection, and Overvoltage Protection for total safety.
- **Storage:** When not in use or for travel, fold the charging station into its compact form to protect the charging surfaces and components.

6. TROUBLESHOOTING

If you encounter any issues with your Anker MagGo Wireless Charging Station, please refer to the following common troubleshooting tips:

- **Blinking Blue Light / Insufficient Power:** If the blue indicator light is blinking, it typically signifies that the power supply to the charger is insufficient. While your phone might still charge, other devices on the base may not. Ensure you are using the provided 40W USB-C PD wall charger or another 35W+ Anker charging block for optimal performance.
- **Device Not Charging:**
 - Verify that the charging station is properly connected to a power source.
 - Ensure your device is correctly aligned on the respective charging surface. For iPhones, ensure it is centered on the MagSafe area. For AirPods, place them in the center of the base pad. For Apple Watch, ensure it is securely placed on the flipped-out module.
 - Remove any thick or non-MagSafe compatible phone cases. Only MagSafe-compatible phone cases with a thickness of 2.5 mm or less are supported.
 - Check for any foreign objects between the device and the charging surface.
- **Slow Charging:** Ensure you are using the recommended 40W USB-C PD wall charger. Lower wattage chargers may result in slower charging speeds.

Use a 30W or Higher Charger



30W or Higher Charger
Flashes Once, Then Turns Off



Charger Below 30W
Constant Flashing



Align the Watch Correctly on the Charger



Note: For optimal charging, use the included 40W USB-C PD wall charger.

Figure 6.1: Proper power input and device alignment are crucial for effective charging.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	A2557
Product Dimensions	3.5 x 2.36 x 0.98 inches
Item Weight	6.9 ounces
Connectivity Technology	Wireless
Connector Type	USB Type C
Compatible Devices	Smartphones (iPhone 12/13/14/15/16 series), AirPods, Apple Watch (Ultra 1/2, Series 1-9, SE)
Input Voltage	240 Volts (AC)
Special Features	Wireless Charging, Foldable Design, Qi2 Certified, MFW Certified
Manufacturer	Anker

8. WARRANTY AND SUPPORT

Anker stands behind the quality of its products. Your Anker MagGo Wireless Charging Station comes with a **24-month warranty**.

For further assistance, technical support, or warranty claims, please contact Anker customer service. You can also refer to the official User Guide for more detailed information:

[Download User Guide \(PDF\)](#)