Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINGBO SYCF5205

WINGBO 52-inch DC Ceiling Fan User Manual

Model: SYCF5205

1. Safety Information

Read all instructions carefully before beginning installation. If you are unfamiliar with electrical wiring, consult a qualified electrician. Ensure all electrical connections comply with local codes and ordinances.

- Always disconnect power at the main circuit breaker before installation or servicing.
- The fan must be mounted with a minimum of 7 feet (2.1 meters) clearance from the floor to the blade trailing edge.
- Ensure the mounting structure can support the weight of the fan (approximately 15.39 lbs).
- Do not operate the fan if any part is damaged.
- This fan is suitable for indoor use and covered outdoor damp locations.

2. Package Contents

Verify that all components are present before proceeding with installation.

- Ceiling Fan Motor Housing
- 3 ABS Blades
- LED Light Kit
- Remote Control with Wall Holder
- Downrods (4.5-inch and 12-inch)
- Mounting Hardware



Image 1: WINGBO 52-inch DC Ceiling Fan and included remote control.

3. Setup and Installation

This section provides general guidance. Refer to the detailed installation manual provided in the product packaging for specific step-by-step instructions.

3.1 Mounting Options

The fan supports both downrod and angled mounting, accommodating various ceiling types. Two downrod lengths (4.5 inches and 12 inches) are included to suit different ceiling heights.



Image 2: Fan dimensions and available mounting configurations (downrod and angled).



Image 3: Visual representation of flat and sloped ceiling mounting with a downrod.

3.2 Room Size Recommendation

This 52-inch ceiling fan is ideal for rooms ranging from 12'x12' to 18'x18' (e.g., living rooms, bedrooms, larger bathrooms).



Image 4: The fan's suitability for various indoor and covered outdoor spaces.

4. Operating Instructions

The WINGBO DC Ceiling Fan is controlled via the included handheld remote.

4.1 Remote Control Functions

The remote control allows for comprehensive operation of the fan and light features.



Image 5: Remote control layout and button functions.

- **Fan Speed:** Adjusts between 6 forward and reverse speeds.
- **Fan Direction (Reversible Motor):** Changes blade rotation for summer (downdraft) or winter (updraft) modes.
- **Light Control:** Turns the integrated LED light on/off and cycles through color temperatures.
- **Timing:** Sets a timer for fan operation.
- **Fan Stop:** Turns the fan off.

4.2 Reversible DC Motor

The energy-efficient DC motor offers 6 speeds and a reversible function to optimize air circulation throughout the year.

- **Summer Mode (Forward Direction):** Forces air down to create a cooling breeze.
- **Winter Mode (Reverse Direction):** Gently draws air up, circulating warm air near the ceiling.



Image 6: Explanation of 6-speed reversible function for seasonal use.

4.3 Integrated LED Light Kit

The fan includes an 18W integrated LED light source with adjustable color temperature, covered by a shatterproof white opal shade.

- **Color Temperatures:** 3000K (Warm White), 4500K (Natural White), 6000K (Day White).
- **Lifespan:** Designed for 50,000+ hours of operation.



Image 7: Demonstrates the three available color temperatures for the LED light.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Check blades for any cracks or damage. Ensure all blade screws are securely fastened.
- **Tighten Connections:** Annually check all screws and connections for tightness.
- **Light Kit:** The integrated LED light source is designed for long life and is not user-replaceable.

6. Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker and wall switch. Ensure all wiring connections are secure. Replace remote batteries or re-pair remote according to the full instruction manual.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws. Use the balancing kit (if included) to balance blades. Ensure mounting bracket is securely attached to the ceiling junction box.
Light does not work	Loose wire connection to light kit; Remote control issue; Integrated LED failure.	Check light kit wiring. Verify remote control functionality. If integrated LED fails, contact customer support.
Remote control not working	Low or dead batteries; Not paired with fan; Obstruction between remote and receiver.	Replace batteries. Ensure remote is paired correctly (refer to full manual). Remove any obstructions.
Fan makes noise	Loose screws; Motor housing rubbing; Blades hitting an obstruction.	Tighten all screws. Ensure no wires are rubbing against the motor housing. Check for any objects obstructing blade rotation.

7. Specifications

Feature	Detail
Brand	WINGBO
Model Name	52" DC Ceiling Fan (SYCF5205)
Color	Matte Black
Product Dimensions	52"D x 52"W x 21"H
Item Weight	15.39 pounds
Number of Blades	3
Blade Material	ABS Polymer
Motor Type	DC Motor (6-speed, reversible)
Light Source	Integrated LED (18W)
Color Temperature	3000K/4500K/6000K (Adjustable)
Control Method	Remote Control
Included Components	Light Kit, Remote, 4.5" & 12" Downrods
Indoor/Outdoor Usage	Indoor, Covered Outdoor (Damp Rated)

Feature	Detail
Certification	ETL Listed

8. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact WINGBO customer service directly. Contact details can typically be found on the manufacturer's official website or through your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF5CHDWL

More documents and user manuals: **https://manuals.plus/**