

HCDZ RC82V

HCDZ Replacement Remote Control RC82V / RC83V User Manual

Model: RC82V

INTRODUCTION

This manual provides instructions for the HCDZ Replacement Remote Control, designed for use with AT&T Directv RC82V, RC83V, C71KW-200, C71KW-400 4K Streaming Midea Player Receivers. This remote operates via both Infrared (IR) and Bluetooth interfaces. The RC83V model specifically utilizes Bluetooth 2-way communication, eliminating the need for a direct line of sight between the remote and the paired device. Voice recognition functionality is available on the RC83V model, but it requires the remote to be paired with a C71KW device.

SETUP

Battery Installation

The remote control requires two AA alkaline batteries (not included). Ensure correct polarity when inserting the batteries.



Image: Back of the remote control with the battery cover removed, illustrating the battery compartment. Insert two AA batteries according to the polarity indicators.



Image: Back of the remote control with the battery cover securely attached after battery installation.

Once batteries are inserted, the remote is ready for use. No programming is typically required for basic functions.

Pairing your Remote to Set Top Box (STB)

To pair the DIRECTV remote control to your Set Top Box, follow these steps:

1. Press and **HOLD** the Rewind and Fast Forward buttons simultaneously for 3 seconds until the visible LED starts flashing.
2. Enter digits 961, followed by the CH up key.
3. Using the number keys, enter the last six digits of the RID number located behind the STB.
4. Press and release the ENTER key (the green light will flash twice).

Note: Voice search functionality is only active when the remote is paired to a C71KW device.

OPERATING INSTRUCTIONS

This replacement remote control is designed to function immediately upon battery insertion for most basic operations. It supports both Infrared (IR) and Bluetooth connectivity, depending on the model (RC82V for IR, RC83V for IR and Bluetooth) and the device it's paired with.

Universal Remote Control Quick Reference Guide

RC83V remote works in IR and Bluetooth interface. The remote uses Bluetooth 2-way communication to C71KW. Bluetooth eliminates the need for the remote and the paired devices to be in line of sight to each other.

Voice Recognition is available in the RC83V Remote. Voice search will only work when the remote is paired to the C71KW.

Pairing your remote to Set top Box

To pair the DIRECTV remote control to the STB, perform the following steps:

1. Press and HOLD **Rewind** and **Fast Forward** at the same time for 3 second until the visible LED's starts flashing.
2. Enter digits 961 follow by CH up key.
3. Using the number keys enter the last six digits of the RID number located behind the STB.
4. Press and release ENTER key (the green light flashes twice).

Clearing Pairing

Press and hold **Dash** and **APPS** at the same time for 3 seconds until the LED's flash. The RCU will unpair from the STB.

RESTORING FACTORY DEFAULT SETTINGS

To reset all the functions of the remote control to the factory default settings following these steps:

1. Press and hold **MUTE** and **Exit** at the same time until the RED LED turns ON.
2. Using the number keys, enter **9-8-1**. (The feedback flashes 4 times).

Image: Front view of the HCDZ remote control, displaying the button layout for various functions.

For specific functions related to your AT&T Directv or 4K Streaming Midea Player Receiver, refer to your device's manual for button assignments.

MAINTENANCE

Battery Care

- Do not mix new batteries with old ones.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage and corrosion.
- Avoid leaving the remote in extremely hot or humid environments.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

General Remote Malfunctions

- **Remote not responding:**
 - Replace the remote control batteries with fresh ones.
 - Check the battery terminals to ensure they are clean and making proper contact.
- **Remote not controlling device:**
 - Ensure the remote is within range of the device (up to 10 meters for IR/Bluetooth).
 - Move closer to the device if it's out of range.
 - Remove any obstructions between the remote and the IR sensor of the device.
 - Verify that the power cord to your device is plugged in and the device is turned on.

Clearing Pairing

To unpair the remote control unit (RCU) from the Set Top Box, perform the following:

- Press and **HOLD** the Dash (-) and APPS buttons simultaneously for 3 seconds until the LED flashes. This action will unpair the RCU from the STB.

Restoring Factory Default Settings

To reset all functions of the remote control to factory default settings, follow these steps:

1. Press and **HOLD** the MUTE and Exit buttons simultaneously until the RED LED turns ON.
2. Using the number keys, enter **9-8-1**. The feedback LED will flash 4 times, indicating the reset is complete.

SPECIFICATIONS

Feature	Detail
Brand	HCDZ
Model Name	RC82V (Compatible with RC83V)
Connectivity Technology	Infrared (IR), Bluetooth (for RC83V variant)

Compatible Devices	4K Streaming Device, Directv Receiver (C71KW-200, C71KW-400)
Max Number of Supported Devices	1
Controller Type	Button Control
Button Quantity	10
Maximum Range	10 Meters
Battery Type	Alkaline
Number of Batteries Required	2 AA batteries
Color	Black

WARRANTY AND SUPPORT

This product comes with a **90-day warranty** from the date of purchase. For warranty claims or technical support, please refer to the seller's contact information provided at the time of purchase. For additional information or assistance, you may also visit the [HCDZ Store on Amazon](#).