Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl FZ-2064A ACP-P2

onerbl AC/DC Adapter Instruction Manual

Compatible with Mitsubishi FZ-2064A and ACP-P2

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically the Mitsubishi FZ-2064A and ACP-P2 models. It features a wide input voltage range, making it suitable for worldwide use, and incorporates multiple protection mechanisms for enhanced safety.



Image 1.1: Front and side view of the onerbl AC/DC Adapter. The front shows the input specifications and regulatory marks, while the side view highlights the compact design and two-prong plug.

Key Features:

- **Universal Input:** AC 100-240V, 50/60Hz, allowing for worldwide compatibility.
- **Safety Protections:** Built-in safeguards against over-voltage, over-heat, and short-circuit conditions.
- **Durable Design:** Constructed with quality materials for long-lasting performance.



Image 1.2: Illustration highlighting the adapter's smart chip technology and multiple protection features, including short-circuit, over-voltage, and over-current protection.

2. Setup Instructions

Follow these steps to properly set up your AC/DC adapter:

1. **Verify Compatibility:** Ensure your device requires an AC/DC adapter with the specified voltage and current output, and that it is compatible with Mitsubishi FZ-2064A or ACP-P2 models. Refer to your device's original power requirements.
2. **Connect to Device:** Plug the DC output connector of the onerbl adapter into the power input port of your Mitsubishi FZ-2064A or ACP-P2 device. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard wall power outlet (100-240V AC). Ensure the outlet is easily accessible and not overloaded.
4. **Power On:** Once connected, your device should receive power. If your device has a power indicator, confirm it illuminates.



Image 2.1: The AC/DC adapter shown plugged into a power strip, illustrating a typical setup environment for powering a device like a laptop.

3. Operating Instructions

The onerbl AC/DC Adapter is designed for straightforward operation:

- Once properly connected as described in the Setup section, the adapter will automatically supply power to your device.
- No additional controls or settings are required for the adapter itself.
- Always ensure the adapter is used in a well-ventilated area to prevent overheating.
- Unplug the adapter from the wall outlet when not in use for extended periods.

4. Maintenance and Care

To ensure the longevity and optimal performance of your adapter, follow these maintenance guidelines:

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter. Avoid exposing it to moisture or liquids.
- **Cable Inspection:** Periodically inspect the power cord for any signs of damage, such as fraying or cuts. If damage is found, discontinue use immediately.



Image 4.1: An illustration detailing the internal construction of the adapter's cable, highlighting the copper wire and PVC jacket for durability and quality control.

5. Troubleshooting

If you encounter issues with your onerbl AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not receiving power.	Loose connection, faulty power outlet, incompatible device.	Ensure all connections are secure. Test the power outlet with another device. Verify adapter compatibility with your device's power requirements.
Adapter feels excessively hot.	Poor ventilation, prolonged heavy load.	Ensure the adapter is in a well-ventilated area. Disconnect for a short period to allow cooling. If overheating persists, discontinue use.
Device charges slowly or intermittently.	Loose connection, device issue, adapter not providing sufficient power (unlikely if compatible).	Check all connections. Test the device with its original adapter if available.

If the problem persists after attempting these solutions, please contact customer support.

6. Specifications

Feature	Detail
Model	FZ-2064A ACP-P2 (Compatible)
Input Voltage	AC 100-240V, 50/60Hz
Protection Features	Over Voltage Protection, Over Heat Protection, Short Circuit Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd
ASIN	B0CF5FH8Z1
Cable Length	Approximately 76 inches (6.3 feet)




Image 6.1: Detailed dimensions of the AC/DC adapter, showing its length, width, height, and the total cable length.




Image 6.2: An illustration demonstrating the benefit of an extended cord design, showing the adapter in different usage scenarios.

7. Warranty Information

Specific warranty details for this onerbl AC/DC Adapter are typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, terms, and conditions.

8. Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the seller from whom you purchased this product. You can typically find seller contact information on your order details page.
Seller: GreatComputerParts
For general inquiries about onerbl products, please visit the official onerbl website or contact their customer service if available.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF5FH8Z1

More documents and user manuals: **https://manuals.plus/**