Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Carlington CT 3388

Carlington CT3388 Analog-Digital Sports Watch User Manual

Model: CT 3388

Introduction

Thank you for choosing the Carlington CT3388 Analog-Digital Sports Watch. This watch combines classic analog timekeeping with modern digital features, designed for durability and functionality. It includes a chronograph, dual time display, alarm, stopwatch, backlight, and is both water and shock-resistant. This manual provides detailed instructions to help you get the most out of your watch.



The Carlington CT3388 Analog-Digital Sports Watch, showcasing its robust design and dual display capabilities.

Watch Components

Familiarize yourself with the buttons and display areas of your Carlington CT3388 watch.



An overview of the Carlington CT3388 watch highlighting key features such as case thickness (18mm), 1-year warranty, case diameter (55mm), backlight display, analog-digital watch type, dual display, water resistance (3 ATM), and weight (67g).



Illustration of the watch face and buttons: 'LIGHT' (top left), 'MODE' (bottom left), 'START' (top right), and 'RESET' (bottom right).

Setup and Basic Operation

Setting Digital Time and Date

1. Press the **MODE** button repeatedly until the digital time display starts flashing, indicating time setting mode.
2. Use the **RESET** button to cycle through the settings (seconds, hours, minutes, month, date, day).
3. Use the **START** button to adjust the selected value.
4. Once all settings are correct, press the **MODE** button to exit the setting mode.

Setting Analog Time

The analog hands are typically synchronized with the digital time. If they are out of sync, refer to the troubleshooting section or contact support.

Using the Backlight

Press the **LIGHT** button (top left) to illuminate the digital display for a few seconds, allowing visibility in low-light conditions.



The watch display illuminated by the backlight for clear visibility in the dark.

Operating Functions

Alarm Function

1. Press the **MODE** button until 'AL' (Alarm) appears on the digital display.
2. Press **RESET** to select hours or minutes.
3. Use **START** to adjust the alarm time.
4. Press **MODE** to confirm and exit.
5. To turn the alarm ON/OFF, press **START** while in alarm mode. An alarm icon will appear when activated.



The watch display showing the alarm function, ensuring you never miss an important moment.

Stopwatch Function

1. Press the **MODE** button until 'ST' (Stopwatch) appears.
2. Press **START** to begin timing.

3. Press **START** again to pause/resume timing.
4. Press **RESET** to clear the stopwatch to zero.
5. Press **MODE** to return to time display.



The watch displaying the stopwatch function, ideal for tracking athletic performance or other timed activities.

Dual Time Display

The watch supports displaying a second time zone. This feature is useful for travelers or those who need to keep track of time in different regions.

1. Press the **MODE** button until 'DT' (Dual Time) appears.
2. Press **RESET** to select hours or minutes.
3. Use **START** to adjust the dual time.
4. Press **MODE** to confirm and exit.



The watch face showing the dual time display, allowing you to monitor two different time zones simultaneously.

Date, Day, Month, Year Display

The watch automatically displays the current date, day, month, and year once set. This information is visible in the standard timekeeping mode.



The watch displaying the current date, day, month, and year, providing comprehensive time information at a glance.

Maintenance and Care

Water Resistance

Your Carlington CT3388 watch is water-resistant up to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water. However, it is **not recommended** for swimming, diving, or prolonged water activities. Do not operate buttons while the watch is wet or submerged.



The watch shown in a water environment, illustrating its water-resistant capability for everyday use.

Shock Resistance

The watch features a shock-resistant construction designed to endure accidental impacts and rough handling during active use. While durable, avoid unnecessary harsh impacts to prolong the watch's lifespan.

Cleaning

Wipe the watch case and strap regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying thoroughly. Avoid using chemical cleaners or solvents.

Battery Replacement

When the display dims or functions become erratic, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.

Troubleshooting

- **Digital display is blank or dim:** The battery may be low. Replace the battery.
- **Analog hands do not match digital time:** This watch typically synchronizes analog and digital time. If they are out of sync, try resetting the watch (if a reset button is available, usually a small recessed button requiring a pin) or consult a professional.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, check manual for specific model features). If wet, dry thoroughly before operating buttons. If the issue persists, the internal mechanism may require inspection.
- **Water inside the watch:** Despite being water-resistant, extreme conditions or improper handling (e.g., pressing buttons underwater) can lead to water ingress. Immediately take the watch to a service center to prevent further damage.

Specifications



Visual representation of the Carlington CT3388 watch dimensions, including case diameter and thickness.

Feature	Detail
Model Number	CT 3388

Feature	Detail
Display Type	Analog-Digital
Movement Type	Quartz
Case Diameter	55 Millimetres
Case Thickness	18 Millimetres
Band Material	Resin
Band Length	240 Millimetres
Band Width	18 Millimetres
Water Resistance Depth	30 Metres (3 ATM)
Item Weight	80 g
Special Features	Alarm, Back Light, Stopwatch, Time Display, Calendar
Country of Origin	Hong Kong

Warranty Information

Your Carlington CT3388 watch comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects only. Please note that straps, batteries, bracelets, and the dial are not included under this warranty.
For any warranty claims, please retain your proof of purchase.

Customer Support

If you have any questions, require assistance, or need to make a warranty claim, please contact Carlington customer support:

- **Phone/WhatsApp:** +91-7044 1111 16 (Monday to Saturday, 11 AM to 6 PM)
- **Email:** support@carlington.in

Please provide your model number (CT 3388) and date of purchase when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF5G61LT

More documents and user manuals: **https://manuals.plus/**