



Manuals.plus /

› Upstreman /

› Upstreman 4.5 Cu.Ft Mini Fridge User Manual

Upstreman CR45

Upstreman 4.5 Cu.Ft Mini Fridge User Manual

Model: CR45
Brand: Upstreman

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new Upstreman Mini Fridge. Retain this manual for future reference.

- Ensure the refrigerator is unplugged before cleaning or performing any maintenance.
- Allow adequate ventilation space around the appliance for proper heat dissipation.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep children away from the appliance and do not allow them to play with it.
- This appliance is designed for household use only.

2. PRODUCT OVERVIEW

The Upstreman 4.5 Cu.Ft Mini Fridge combines a retro design with modern efficiency, making it suitable for various spaces such as bedrooms, offices, dorms, and apartments. Its compact size and quiet operation ensure minimal disruption.



Figure 2.1: Front view of the Upstreman 4.5 Cu.Ft Mini Fridge in Red.

Key Features:

- **Retro Design:** Features classic chrome handles and a vibrant red color.
- **Compact Capacity:** 4.5 Cu.Ft (127.4L) total capacity, with 4 Cu.Ft for fresh food and 0.5 Cu.Ft for the freezer compartment.
- **Quiet Operation:** Operates at a low noise level of 38 dB.
- **Energy Efficient:** Energy Star certified, with an estimated energy cost of 0.62 kWh per day.
- **Adjustable Temperature:** Offers 6 temperature settings for optimal cooling.
- **Convenient Features:** Includes a side bottle opener and adjustable glass shelves.



SIDE BOTTLE OPENER

6 TEMPERATURE SETTINGS



RETRO STYLE HANDLE

Figure 2.2: Detailed view of the side bottle opener, temperature settings, and retro handle.

3. SETUP

3.1 Unpacking and Placement

Carefully remove all packaging materials. Place the refrigerator on a flat, stable surface. Ensure there is sufficient space around the unit for proper ventilation (at least 2 inches on sides and back).

COMPACT SIZE



Figure 3.1: Dimensions of the mini fridge: 20.86" (D) x 20.59" (W) x 32.48" (H).

3.2 Installing Handle and Bottle Opener

The retro handle and side bottle opener are typically shipped detached to prevent damage. Attach them using the provided screws. The handle slides into place, and the bottle opener requires two screws for secure mounting.

3.3 Door Reversibility

The door hinges are reversible, allowing you to change the door swing direction to best suit your space. Refer to the detailed instructions in the separate door reversal guide (if included) or contact customer support for assistance.

3.4 Initial Power-On

After placement and assembly, plug the refrigerator into a dedicated power outlet. Allow the unit to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle. This ensures optimal cooling performance.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator features an adjustable thermostat with 6 settings, typically ranging from 0 (off) to 5 or 6 (coldest). The freezer temperature ranges from 24.8°F to 42.8°F, and the fridge temperature ranges from 35.6°F to 44.6°F. Adjust the dial to your desired cooling level. Setting '3' is often recommended for general use.



Figure 4.1: The temperature control dial inside the refrigerator.



Figure 4.2: Adjusting the temperature dial to the desired setting.

4.2 Internal Storage

The refrigerator is equipped with adjustable glass shelves and door racks for versatile storage. The door features a unique soda rack designed to auto-refill cans as they are removed. A crisper drawer is located at the bottom for fruits and vegetables.

ostreman 4.5 CU.FT RETRO FRIDGE

Chillin' with Retro Fridge



Figure 4.3: Interior layout of the mini fridge with glass shelves and door storage.



Figure 4.4: The adjustable glass shelves can be repositioned to accommodate different item heights.

4.3 Ice Cube Tray

An ice cube tray is included for making ice in the freezer compartment. Note that the freezer compartment is not suitable for long-term storage of ice cream or items requiring deep freezing.



Figure 4.5: The included ice cube tray fits perfectly in the freezer section.

5. MAINTENANCE

5.1 Manual Defrost

This refrigerator features a manual defrost system. When frost accumulates to a thickness of about 1/4 inch (6mm), the freezer compartment should be defrosted. To defrost, unplug the unit, remove all contents, and allow the frost to melt naturally. Place a towel or shallow pan to catch melted water. Do not use sharp objects to remove ice.

5.2 Cleaning

Clean the interior and exterior of the refrigerator regularly with a mild detergent and warm water. Wipe dry with a soft cloth. Avoid abrasive cleaners or solvents. Clean the door gasket to ensure a tight seal.

6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "0".	Ensure plug is secure; reset circuit breaker; turn temperature control to a higher setting.
Temperature is not cold enough.	Temperature control set too low; door opened too frequently; large amount of warm food added; poor ventilation.	Adjust temperature control to a colder setting; minimize door openings; allow warm food to cool before placing in fridge; ensure proper clearance around unit.
Excessive frost buildup.	Door not closed properly; high humidity; frequent door openings.	Check door seal and ensure it closes completely; reduce frequency of door openings; perform manual defrost.
Unusual noises.	Unit not level; objects vibrating against the unit.	Adjust leveling legs; ensure nothing is touching the back or sides of the refrigerator.

7. SPECIFICATIONS

Feature	Detail
Brand	Upstreman
Model Info	CR45
Item Weight	56.7 pounds
Product Dimensions	20.86"D x 20.59"W x 32.48"H
Capacity	4.5 Cubic Feet
Refrigerator Fresh Food Capacity	4 Cubic Feet
Freezer Capacity	0.5 Cubic Feet
Installation Type	Freestanding
Form Factor	Compact
Special Features	Adjustable Shelves, Compact
Color	Red
Voltage	115 Volts
Racks	3
Crispers/Drawers	1
Defrost System	Manual
Door Hinges	Reversible
Shelf Type	Glass
Number Of Doors	1
Certification	Energy Star
Included Components	Refrigerator
Date First Available	August 9, 2023

8. WARRANTY AND SUPPORT

Upstreman offers a one-year quality and service warranty for this product, ensuring satisfaction. For any inquiries, technical assistance, or warranty claims, please contact Upstreman customer support through their official channels.

Please refer to the official Upstreman website or your purchase documentation for the most up-to-date contact information and detailed warranty terms.