

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ALLIMITY](#) /

› [ALLIMITY CRMC-A907JBEZ Replacement Remote Control for Sharp A/C Air Conditioners User Manual](#)

ALLIMITY CRMC-A907JBEZ

ALLIMITY CRMC-A907JBEZ Replacement Remote Control User Manual

For Sharp A/C Air Conditioners

1. PRODUCT OVERVIEW

The ALLIMITY CRMC-A907JBEZ is a replacement remote control designed for use with various Sharp A/C air conditioner models. This remote provides essential functions for controlling your air conditioning unit, offering a direct replacement without the need for complex programming.



Image 1.1: Front angled view of the CRMC-A907JBEZ remote control, highlighting the display screen and primary function buttons.

This remote control is compatible with Sharp A/C models that originally used the CRMC-A907JBEZ or CRMCA907JBEZ remote.

2. SETUP: BATTERY INSTALLATION

Before using the remote control, batteries must be installed. This remote requires two (2) AAA 1.5V alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off in the direction of the arrow.
3. Insert two AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 2.1: Rear view of the remote control with the battery cover open, illustrating the correct orientation for AAA battery insertion.

Note:

- Do not mix old and new batteries.

- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.

3. OPERATING INSTRUCTIONS

This section details the functions of the buttons on your ALLIMITY CRMC-A907JBEZ remote control.





Image 3.1: Front view of the CRMC-A907JBEZ remote control, indicating the layout of all control buttons.

POWER (Red Button): Turns the air conditioner unit ON or OFF.

MODE: Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto. The current mode is typically displayed on the remote's screen.

TEMP. (Up/Down Arrows): Adjusts the desired temperature setting. Press the up arrow to increase temperature, and the down arrow to decrease it.

FAN: Controls the fan speed (e.g., Low, Medium, High, Auto).

TIMER: Used to set the ON/OFF timer for the air conditioner. Refer to your air conditioner's main manual for specific timer programming details.

Comfort: Activates a specific comfort mode, which may adjust temperature and fan speed for optimal comfort.

JET: Initiates a rapid cooling or heating function for quick temperature changes.

SWING: Controls the louver swing function, directing airflow.

CANCEL: Cancels a set timer or other active function.

RESET: Resets certain settings or functions. This button may be recessed and require a pointed object (like a pen tip) to press.

Important:

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

4. MAINTENANCE

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's range decreases or if the display becomes dim. Always replace both batteries simultaneously with new AAA 1.5V alkaline batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent

leakage and potential damage. Store the remote in a cool, dry place away from direct sunlight.

5. TROUBLESHOOTING

If you experience issues with your remote control, refer to the following common troubleshooting steps:

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new AAA 1.5V alkaline batteries.
- Ensure there are no obstructions between the remote control and the air conditioner unit.
- Verify that the remote is pointed directly at the air conditioner's infrared receiver.

- **Limited range or intermittent operation:**

- This often indicates low battery power. Replace the batteries.
- Ensure the remote's infrared emitter (at the top) is clean and unobstructed.

- **Air conditioner not responding to specific functions:**

- Some advanced functions may require specific settings on the air conditioner unit itself. Consult your air conditioner's original user manual.
- Ensure the remote is compatible with your specific Sharp A/C model.

If issues persist after following these steps, contact customer support for further assistance.

6. SPECIFICATIONS

Feature	Detail
Model Number	CRMC-A907JBEZ
Brand	ALLIMITY
Compatibility	Sharp A/C Air Conditioners (CRMC-A907JBEZ, CRMCA907JBEZ)
Power Supply	2 x AAA 1.5V Batteries (not included)
Dimensions	6.5 x 1.38 x 0.72 inches (16.5 x 3.5 x 1.8 cm)
Item Weight	1.59 ounces (45 grams)
Special Feature	No Programming Required

7. WARRANTY AND SUPPORT

This ALLIMITY replacement remote control is designed for reliable performance. For any questions regarding compatibility, setup, or operation, please refer to the troubleshooting section or contact your retailer or ALLIMITY customer support.

Please retain your purchase receipt for any warranty claims. Specific warranty terms may vary by retailer and region.

