

OUTON CJD-CT-WT-03

OUTON Deluxe Shelf Floor Lamp (Model CJD-CT-WT-03) User Manual

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your OUTON Deluxe Shelf Floor Lamp, Model CJD-CT-WT-03. This multifunctional floor lamp features integrated storage shelves, a convenient drawer, a 3-color temperature LED light, and a charging station with USB-C, USB-A, and AC power outlets. Please read this manual thoroughly before use to ensure proper function and safety.

2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly.
- Do not connect the lamp to power until fully assembled.
- Use only the specified bulb type (E26, 9W LED) to prevent overheating or damage.
- Place the lamp on a stable, level surface to prevent tipping.
- Keep the power cord away from heat sources, sharp edges, and heavy traffic areas.
- Do not exceed the maximum weight capacity of the shelves (30 lbs).
- Unplug the lamp from the power outlet before cleaning or replacing the bulb.
- This product is for indoor use only and is not water resistant.

3. PACKAGE CONTENTS

Verify that all parts are included in your package:

- Lamp Frame Components (Wood)
- Lampshade (White Line Texture)
- 9W LED Bulb (E26 Base)
- Charging Station Module (with 1 Type-C, 1 USB-A, 2 AC Outlets)
- Drawer with Knob

- Hardware Pack (Screws, Allen Wrench)
- Plastic Cord Clips
- User Manual (this document)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your OUTON Deluxe Shelf Floor Lamp. Assembly typically takes approximately 10 minutes.




Figure 4.1: Overview of the assembly process.

1. **Assemble the Lamp Pole with Board:** Connect the wooden lamp pole sections and attach the main shelf board. Ensure all connections are secure.



Figure 4.2: Attaching lamp pole sections.

2. **Assemble the Drawer:** Construct the drawer and attach the knob. Insert the assembled drawer into its designated slot on the lamp frame.



Figure 4.3: Assembling the drawer.

3. **Assemble the Charging Station:** Secure the charging station module into its slot on the lamp frame.

Ensure it is firmly in place.



Figure 4.4: Installing the charging station.

- 4. Assemble Additional Boards:** Attach any remaining shelf boards to the lamp frame as per the included diagram.



Figure 4.5: Attaching additional shelf boards.

- 5. Assemble the Bulb:** Carefully screw the provided 9W LED bulb into the E26 base socket.



Figure 4.6: Installing the LED bulb.

- 6. Assemble the Lampshade:** Position the lampshade around the bulb and secure it to the top frame of the lamp.



Figure 4.7: Securing the lampshade.

- 7. Cable Management:** Use the provided plastic clips to neatly tuck the power cord along the lamp

frame, ensuring a tidy appearance and preventing tripping hazards.

5. OPERATING INSTRUCTIONS

5.1. Lighting Control

The lamp features a pull chain switch to control the light and cycle through three color temperatures:

- **First Pull:** Warm White (2700K) - Creates a cozy atmosphere.
- **Second Pull:** Natural White (4000K) - Ideal for reading or general illumination.
- **Third Pull:** Daylight (5000K) - Bright light for detailed work.
- **Fourth Pull:** Turns the light off.



Figure 5.1: Three adjustable color temperatures.

5.2. Charging Station

The integrated charging station provides convenient power for your devices:

- **2 AC Outlets:** For standard electrical devices.
- **1 Type-C Fast Charging Port:** For compatible devices requiring fast charging.

- **1 USB-A Port (5V/2A):** For standard USB charging.

Simply plug your devices into the appropriate ports. The charging station is always active when the lamp is plugged into a wall outlet.



Figure 5.2: Integrated 4-in-1 charging station.

5.3. Storage Drawer and Shelves

Utilize the large sliding drawer for storing small items like remote controls, charging cables, or glasses. The three open shelves provide space for displaying decorative items, books, or small plants.

Multiple Spaces for Storage & Display

Large sliding drawer with knob



Figure 5.3: Storage shelves and drawer.

6. MAINTENANCE

6.1. Cleaning

Before cleaning, ensure the lamp is unplugged from the power outlet. Wipe the wooden frame and shelves with a soft, dry cloth. For the lampshade, use a soft, slightly damp cloth if necessary, and allow it to air dry completely before reconnecting power.

6.2. Bulb Replacement

The lamp uses a standard E26 base LED bulb. The included 9W LED bulb has a lifespan of over 50,000 hours. When replacement is needed, ensure the lamp is unplugged. Unscrew the old bulb and screw in a new E26 LED bulb (maximum 60W equivalent incandescent). Do not use incandescent bulbs that exceed 60W equivalent.



Figure 6.1: Compatible E26 bulb types.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	<ol style="list-style-type: none"> 1. Power cord not fully plugged in. 2. Bulb is loose or faulty. 3. Wall outlet is not functioning. 	<ol style="list-style-type: none"> 1. Ensure the power cord is securely plugged into a working outlet. 2. Tighten the bulb or replace it with a new one. 3. Test the outlet with another device.
Charging ports are not working.	<ol style="list-style-type: none"> 1. Lamp is not powered. 2. Device charging cable is faulty. 3. Device is not compatible with the port. 	<ol style="list-style-type: none"> 1. Ensure the lamp is plugged in and receiving power. 2. Try a different charging cable. 3. Verify device compatibility with USB-C, USB-A (5V/2A), or AC outlets.
Lamp is wobbly after assembly.	Screws are not fully tightened.	Carefully re-tighten all assembly screws. Ensure the lamp is on a flat, stable surface.
Drawer sticks or does not slide smoothly.	Drawer rails are misaligned or obstructed.	Check the drawer rails for any obstructions. Ensure the drawer was assembled correctly and is not overtightened.

8. SPECIFICATIONS

Feature	Detail
Model Number	CJD-CT-WT-03
Product Dimensions	10.25"D x 10.25"W x 63.7"H
Item Weight	10 Pounds
Material	Wood
Finish Type	Walnut Painted
Light Source Type	LED

Feature	Detail
Bulb Base	E26
Wattage	9 watts (LED)
Brightness	810 Lumens
Color Temperature	Warm White (2700K), Natural White (4000K), Daylight (5000K)
Switch Type	Pull Chain
Charging Ports	1x Type-C, 1x USB-A (5V/2A), 2x AC Outlets
Maximum Shelf Weight	30 lbs
Power Source	Corded Electric (120 Volts AC)
Indoor/Outdoor Usage	Indoor



Figure 8.1: Product dimensions and features.

9. WARRANTY AND CUSTOMER SUPPORT

OUTON provides a **2-year quality support warranty** for this product. If you encounter any issues or have questions, please contact our customer service team. We are committed to providing satisfaction with our products and services.

Customer Service: Available 24/7. Please refer to your purchase documentation for specific contact details or visit the official OUTON website.