



Manuals.plus /

› ApoloMedia /

› ApoloMedia NJP1561P 15.6-inch Windows 11 Laptop Instruction Manual

## ApoloMedia NJP1561P

# ApoloMedia NJP1561P 15.6-inch Windows 11 Laptop Instruction Manual

Model: NJP1561P | Brand: ApoloMedia

## INTRODUCTION

---

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your ApoloMedia NJP1561P 15.6-inch Windows 11 Laptop. Please read thoroughly to ensure optimal performance and longevity of your device.

## PACKAGE CONTENTS

---

Upon opening the package, verify that all items are present:

- ApoloMedia NJP1561P Laptop
- Power Adapter
- User Manual (this document)



Figure 1: ApoloMedia NJP1561P Laptop with its sleek design.

## SETUP

---

### 1. Initial Power-Up and Charging

1. Unpack the laptop and power adapter from the box.
2. Connect the power adapter to the laptop's charging port (DC IN) and then to a power outlet.
3. Press the power button (usually located on the top right of the keyboard) to turn on the laptop.
4. Allow the battery to fully charge before the first use.

### 2. Windows 11 Initial Configuration

Follow the on-screen prompts to complete the Windows 11 setup process. This includes selecting your region, connecting to a Wi-Fi network, and setting up your user account.

Your browser does not support the video tag.

**Video 1:** An overview of the ApoloMedia NJP1561P laptop, including unboxing and initial setup steps.

### 3. Port Identification

Familiarize yourself with the various ports and indicators on your laptop:

- **Left Side:** USB 3.2 Gen1 Type-A, 3.5mm Charger Jack, Mini HDMI Port, Type-C Port (for data transmission, not charging).
- **Right Side:** USB 3.2 Gen1 Type-A, 3.5mm Combo Jack (Headphone/Microphone), TF Card Slot.

Your browser does not support the video tag.

**Video 2:** Detailed view of the ApoloMedia NJP1561P laptop's ports and keyboard layout.

# Connect More Convenient



Figure 2: Illustration of the various connectivity ports on the ApoloMedia NJP1561P laptop.

## OPERATING INSTRUCTIONS

### 1. Basic Usage

- **Keyboard:** The laptop features a full-size QWERTY keyboard with a numeric keypad for efficient typing.
- **Touchpad:** The large, ultra-smooth touchpad supports multi-touch gestures for navigation.
- **Display:** The 15.6-inch Full HD (1920x1080) IPS display offers a wide 175° viewing angle for clear visuals.

# 15.6" Full HD IPS Screen



1920\*1080



6mm micro-edge



175° open angle



Figure 3: The 15.6-inch Full HD IPS display of the ApoloMedia NJP1561P laptop.

# Full Size Keyboard



Figure 4: Close-up of the full-size keyboard and ultra-smooth touchpad on the ApolloMedia NJP1561P laptop.

## 2. Connectivity

- **Wi-Fi:** Supports 2.4GHz and 5.8GHz Wi-Fi for stable internet connection.
- **Bluetooth:** Integrated Bluetooth 4.2 allows connection to wireless peripherals.

## 3. Battery Life

The laptop is equipped with a 5000mAh lithium-ion battery, providing approximately 5-6 hours of usage depending on workload and settings. For optimal battery health, avoid completely draining the battery frequently.

# Durable Battery, Longer battery life




Figure 5: Visual representation of the ApolloMedia NJP1561P laptop's battery capacity and endurance.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior. Avoid harsh chemicals.
- **Software Updates:** Regularly check for and install Windows updates to ensure system security and performance.
- **Storage Management:** Periodically clean up unnecessary files and applications to maintain optimal storage space and speed.
- **Ventilation:** Ensure the laptop's ventilation grilles (located on the bottom) are not obstructed to prevent overheating.

# Intel Quad-Core Processor



Quad-Core Processor Up to 2.8 GHz



Intel® UHD Graphics




Figure 6: Diagram highlighting the Intel Quad-Core Processor and Intel UHD Graphics within the ApolloMedia NJP1561P laptop.

## TROUBLESHOOTING

- **Laptop Not Powering On:** Ensure the power adapter is securely connected and the power outlet is functional. If the battery is completely drained, it may take a few minutes for the laptop to respond after plugging it in.
- **Slow Performance:** Check for background applications consuming resources. Restarting the laptop can often resolve temporary slowdowns. Ensure sufficient free storage space.
- **Wi-Fi Connectivity Issues:** Verify that Wi-Fi is enabled in Windows settings. Restart your router and the laptop.
- **System Reset:** If persistent software issues occur, you may consider a system reset. Navigate to Windows Settings > System > Recovery to find reset options. Back up important data before proceeding.

## SPECIFICATIONS

Feature	Detail
Model Name	ApoloMedia NJP1561P
Operating System	Windows 11 Home
Processor	Intel Celeron N5095 (up to 2.8 GHz, 4 Cores)
RAM	12 GB DDR4 SDRAM
Storage	512 GB SSD (Expandable up to 1TB)
Display Size	15.6 Inches
Screen Resolution	1920 x 1080 pixels (Full HD IPS)
Graphics	Integrated Intel UHD Graphics
Wireless Connectivity	Wi-Fi (2.4/5.8GHz), Bluetooth 4.2
Ports	USB 3.2 Gen1 Type-A (x2), Mini HDMI, Type-C (data only), 3.5mm Combo Jack, TF Card Slot, DC IN
Battery	5000mAh Lithium-Ion (5-6 hours endurance)
Item Weight	3 pounds (approx. 1.36 kg)
Dimensions (LxWxH)	13.9 x 8.89 x 0.79 inches

## WARRANTY AND SUPPORT

---

For detailed warranty information and technical support, please refer to the documentation included with your purchase or visit the official ApoloMedia website. You can also visit the [ApoloMedia Store on Amazon](#) for additional resources.