

- Manuals.plus /
- > Lamshaw /
 - > Lamshaw 22mm Leather Silicone Smartwatch Band Instruction Manual for IDW13, IDW16, IDW19 Smartwatches

Lamshaw IDW13, IDW16, IDW19

Lamshaw 22mm Leather Silicone Smartwatch Band Instruction Manual

Models: IDW13, IDW16, IDW19 Compatible Smartwatches

INTRODUCTION

This manual provides essential instructions for the proper installation, use, and maintenance of your Lamshaw 22mm Leather Silicone Smartwatch Band. Please read this manual thoroughly to ensure optimal performance and longevity of your product. This band is designed for compatibility with IDW13, IDW16, and IDW19 series smartwatches.



Image 1: Lamshaw 22mm Leather Silicone Smartwatch Bands (Brown and Black)

PRODUCT OVERVIEW

The Lamshaw smartwatch band combines the classic aesthetic of leather with the comfort and durability of silicone. It is designed for a secure and comfortable fit for daily wear.

- **Material:** Outer layer of genuine leather, inner layer of silicone for comfort and breathability.
- **Design:** Classic color with tone-on-tone stitching, featuring a robust metal buckle.
- **Compatibility:** Specifically designed for IDW13, IDW16, and IDW19 series smartwatches.



Top-notch Metal Material

Impervious to corrosion while
elevating the whole look of
your watch



Image 2: Detail of the band's construction, showing the inner silicone and outer leather layers.

CLASSIC LOOK

An inner layer of
silicone with an outer
layer of real leather



Image 3: Detail of the durable metal buckle.

SETUP AND INSTALLATION

Follow these steps to correctly attach or remove the smartwatch band:

1. **Correct Installation:** Align the spring bar with the hole on the watch casing. Push the spring bar inwards from the front of the watch towards the backside until it clicks into place. Ensure both ends of the spring bar are securely seated in the watch lugs.
2. **Incorrect Installation (Avoid):** Do not attempt to push the spring bar from the back of the watch towards the front. This method will not allow the band to attach correctly and may damage the watch or band.
3. **Removal:** To remove the band, locate the small lever on the spring bar. Pull the lever inwards to retract the spring bar, then gently detach the band from the watch casing.

EASY INSTALL ON/OFF

CORRECT : Align the pin at the hole of the watch, push the spring bar in from the front of watch to backside of watch.



FALSE : Align the pin at the hole of the watch, pls DONT push the spring bar in from the back of watch to the front of watch, you cant get it in in that way.



Any problem, please feel free contact us, our email address is lamshaw@163.com . We will help you solve the problem. Thanks.

Image 4: Visual guide for correct band installation and common errors to avoid.

MAINTENANCE

To maintain the quality and appearance of your smartwatch band, follow these guidelines:

- **Cleaning:** Wipe the leather surface with a soft, dry cloth. For the silicone underside, a damp cloth can be used. Avoid harsh chemicals or abrasive cleaners.
- **Water Exposure:** While the silicone is water-resistant, prolonged exposure to water can affect the leather. Avoid submerging the band in water. If it gets wet, dry it thoroughly with a soft cloth.

- **Storage:** Store the band in a cool, dry place away from direct sunlight to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your Lamshaw smartwatch band, please consider the following:

- **Band Not Attaching Securely:** Ensure the spring bar is correctly aligned and fully seated in the watch lugs as described in the "Setup and Installation" section. Verify that the spring bar is not bent or damaged.
- **Discomfort or Skin Irritation:** Ensure the band is not too tight. If irritation persists, clean the band thoroughly and consult a healthcare professional if necessary.
- **Defective Items:** If you receive a defective item or experience quality-related issues within 30 days of purchase, please contact our customer support for a replacement or refund.

SPECIFICATIONS

Feature	Detail
Material	Leather (outer), Silicone (inner)
Band Width	22mm
Total Length	220mm
Adjustable Wrist Circumference	Minimum: 5.5 inches (140mm), Maximum: 8.7 inches (220mm)
Metal Type	No Metal Type (referring to the band material itself, buckle is metal)
Compatibility	IDW13, IDW16, IDW19 Smartwatches



Image 5: Wrist circumference measurement guide.

WARRANTY AND SUPPORT

Lamshaw offers a 30-day warranty from the date of purchase for all quality-related issues. This includes replacements or refunds for defective items.

For any inquiries, support, or to report a defective item, please contact us directly:

Email: lamshaw@163.com

We are committed to assisting you and resolving any concerns promptly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CF9K86DV>

More documents and user manuals: <https://manuals.plus/>