

Topyond Foldable BBQ Grill

Topyond Foldable BBQ Grill User Manual

Model: Foldable BBQ Grill

Brand: Topyond

1. INTRODUCTION AND PRODUCT OVERVIEW

The Topyond Foldable BBQ Grill is a portable and heat-resistant charcoal grill designed for outdoor cooking. Constructed from high-quality stainless steel, it offers excellent durability and heat resistance, making it suitable for various outdoor activities such as camping, picnics, and patio use. Its compact and foldable design ensures easy transportation and storage, providing a convenient solution for grilling on the go. The grill features an efficient ventilation system to promote even charcoal burning and consistent heat distribution.

Key Features:

- **Compact and Portable Design:** Easily folds for convenient storage and transportation, ideal for outdoor enthusiasts.
- **High-Quality Heat Resistant Construction:** Made from premium stainless steel, resistant to rust and corrosion, ensuring safe and efficient grilling.
- **Efficient Ventilation System:** Features ventilation holes for optimal airflow, promoting even charcoal burning and minimizing flare-ups.
- **Easy to Set Up and Clean:** Quick assembly and hassle-free cleaning with removable parts and a smooth stainless steel surface.
- **Versatile Grilling Experience:** Ample space for cooking various foods, from meats to vegetables.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and undamaged. The standard package includes:

- 1 x Set of Folding BBQ Grill (consisting of main body, grill net, and support legs)

- 1 x Storage Bag



Figure 2.1: The Topyond Foldable BBQ Grill shown with its accompanying black storage bag. The grill is made of stainless steel and features a rectangular grill net.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Topyond Foldable BBQ Grill:

1. **Unfold the Grill Body:** Carefully unfold the main body of the grill. The side panels will extend to form the base and support structure.
2. **Secure the Support Legs:** Ensure the support legs are fully extended and locked into their designated positions. The grill should stand stably on a flat, non-combustible surface.
3. **Place the Grill Net:** Position the stainless steel grill net securely on top of the grill body. Ensure it sits flush and does not wobble.



Figure 3.1: The Topyond Foldable BBQ Grill fully assembled and ready for use, shown with two foil containers placed on the grill net.

Important: Always set up the grill on a stable, heat-resistant surface away from flammable materials, children, and pets. Do not use indoors or in enclosed spaces.

4. OPERATING INSTRUCTIONS

To achieve optimal grilling results and ensure safety, follow these operating guidelines:

1. **Add Charcoal:** Place a suitable amount of charcoal briquettes or lump charcoal into the bottom of the grill body. Do not overfill.
2. **Ignite Charcoal:** Use a charcoal chimney starter or appropriate fire starters to ignite the charcoal. Avoid using gasoline or other highly volatile liquids. Allow the charcoal to ash over and glow red before placing food on the grill.
3. **Control Heat:** The grill's ventilation holes are designed to provide optimal airflow. Adjust the amount of charcoal and monitor the airflow to control the cooking temperature.
4. **Place Food:** Once the grill is at the desired temperature, carefully place food on the grill net.

5. **Monitor Cooking:** Turn food as needed to ensure even cooking. The grill net can also be used to support pots or pans for boiling water or frying food.
6. **Extinguish Charcoal:** After cooking, allow the charcoal to burn out completely or carefully extinguish it with water. Ensure all embers are out before moving or storing the grill.



The grill net can be used to grill a variety of foods
Stand can be used for stock pots, frying pans, boiling
water or frying food

Figure 4.1: Various foods, including skewers and chicken wings, being cooked on the Topyond Foldable BBQ Grill over hot charcoal.



Figure 4.2: Sausages grilling on the Topyond Foldable BBQ Grill, demonstrating its use for various food types.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life of your Topyond Foldable BBQ Grill:

- **Cleaning:** After each use, allow the grill to cool completely. Remove the grill net and empty any ash. The manufacturer recommends **Hand Wash** for cleaning. Use warm soapy water and a non-abrasive brush or sponge to clean the grill net and body. Rinse thoroughly and dry immediately to prevent water spots and rust.
- **Storage:** Ensure the grill is completely clean and dry before folding it for storage. Store it in the provided storage bag in a dry, cool place, away from direct sunlight and moisture.
- **Inspection:** Periodically inspect the grill for any signs of wear, damage, or loose parts. Address any issues promptly to ensure safe operation.





Figure 5.1: The black drawstring storage bag provided with the Topyond Foldable BBQ Grill, designed for easy transport and protection.

6. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your charcoal grill:

- **Charcoal Not Igniting Easily:**

Ensure charcoal is dry. Use a charcoal chimney starter for more efficient ignition. Do not stack charcoal too densely, allow for airflow.

- **Uneven Heat Distribution:**

Check if charcoal is spread evenly. Ensure ventilation holes are clear and not blocked by ash. Adjust charcoal placement as needed.

- **Excessive Smoke:**

This can occur if there's too much fat dripping onto the coals. Trim excess fat from meats. Ensure proper airflow to allow charcoal to burn cleanly.

- **Grill Wobbles After Setup:**

Ensure the grill is placed on a flat, stable surface. Verify that all support legs are fully extended and locked into position.

7. SPECIFICATIONS

Attribute	Detail
Item Type	Folding BBQ Grill
Main Material	Stainless Steel
Colour	Silver
Grill Net Size	Approx. 20.2 x 15.3cm / 8.0 x 6.0in
Suitable for	Outdoor Barbecue
Care Instructions	Hand Wash
ASIN	B0CF9NXLSN
Manufacturer	Topyond
Date First Available	August 10, 2023

Grill Net Size: Approx. 20.2 x 15.3cm / 8.0 x 6.0in



Figure 7.1: Image illustrating the approximate dimensions of the grill net: 20.2 x 15.3 cm (8.0 x 6.0 inches).

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Topyond Foldable BBQ Grill, please refer to the seller's contact information on the platform where the product was purchased. Keep your purchase receipt as proof of purchase for any warranty claims.

Topyond is committed to providing quality products. For more information about Topyond products, you may visit the official Topyond store on Amazon: [Topyond Store](#).

© 2023 Topyond. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.