

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Braun](#) /
- › [Braun Series 8 8567cc Electric Razor User Manual](#)

## Braun 8567cc

# Braun Series 8 8567cc Electric Razor

## USER MANUAL

Model: 8567cc | Brand: Braun

### Introduction

Welcome to the Braun Series 8 8567cc Electric Razor user manual. This guide provides essential information for the safe and effective use, maintenance, and care of your new electric shaver. Designed for a close and gentle shave, even on dense beards, the Series 8 features advanced technology and premium accessories to enhance your grooming routine. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: Braun Series 8 8567cc Electric Razor with included accessories.

## Key Features

- **40-Degree Swiveling Head:** Adapts gently to facial contours for closeness and skin comfort.
- **4 Sonic-Powered Compact Shaving Elements:** Delivers a close and gentle shave, even under the chin and nose.
- **ProTrimmer:** Integrated precision beard trimmer for accurate sideburn shaping and capturing fine hairs.
- **Sonic Technology:** Uses 10,000 micro-vibrations to help capture more hair and glide smoothly over the skin.
- **AutoSense Technology:** Reads and adapts to your beard density, providing extra power where needed.
- **5-in-1 SmartCare Center:** Automatically charges, cleans, lubricates, and dries the shaver at the touch of a button.
- **100% Waterproof:** Suitable for wet and dry use, with foam, gel, or in the shower.
- **Powerful Li-Ion Battery:** Provides 60 minutes of runtime with a 5-minute quick charge option.
- **Durable Design:** Made in Germany with titanium-coated elements for corrosion resistance.




Figure 2: Experience an upgraded shave with the Braun Series 8.





Figure 3: The flexible head ensures a close and gentle shave.




Figure 4: Four synchronized shaving elements for efficient hair capture.



## Ultimate precision

This electric shaver for men is equipped with a **ProTrimmer** for more accurate sideburn shaping and to capture fine hairs.

Figure 5: The integrated ProTrimmer for precise styling.



## Premium accessories

5-in-1 SmartCare Center automatically **charges and cleans, lubricates, and dries** at the touch of a button.

Figure 6: The SmartCare Center simplifies maintenance.

Your browser does not support the video tag.

Video 1: Official Braun Series 8 Shaver & Precision Long Hair Trimmer overview. This video demonstrates the shaver's key features, including its superior closeness, skin comfort, Sonic Technology, Ultra Adaptive Head, Precision ProTrimmer, and the 5-in-1 SmartCare Center. It also highlights its durability and wet/dry capabilities.

## Safety Information

Always hold the shaver away from your face while charging. Do not submerge the shaver in water. Clean the shaver regularly and allow it to dry completely before storing. Be cautious when using the trimmer on your face. Keep the shaver out of reach of children and pets. Always unplug the shaver before cleaning or storing. Do not use the shaver if the cord is damaged or if it is not working properly. Always follow the instructions in the user manual for safe and proper use.

## Setup

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts listed in the product contents are present.
2. **Initial Charge:** Before first use, fully charge the shaver. Connect the shaver to the SmartCare Center or directly to the power outlet using the provided power cord. A full charge takes approximately 1 hour and provides up to 60 minutes of shaving time. The display will indicate charging progress.
3. **SmartCare Center Setup (if applicable):** Place the SmartCare Center on a flat, stable surface. Insert a

cleaning cartridge into the base of the SmartCare Center until it clicks into place.

## Operating Instructions

1. **Shaving Preparation:** For dry shaving, ensure your face is clean and dry. For wet shaving, apply shaving foam or gel to your face.
2. **Power On:** Press the On/Off button to start the shaver.
3. **Shaving Technique:** Hold the shaver at a right angle (90°) to your skin. Stretch your skin with your free hand to ensure hairs stand upright. Shave against the direction of hair growth using short, firm strokes. Do not press too hard, as this can reduce the effectiveness and cause skin irritation.
4. **Using the ProTrimmer:** Slide the ProTrimmer up from the back of the shaver. Use it for precise shaping of sideburns, mustache, or beard lines.
5. **Power Off:** Press the On/Off button to turn off the shaver.

## Maintenance

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your Braun Series 8 electric razor.

### Daily Cleaning (Manual)

1. **After Each Use:** Rinse the shaver head under hot running water with the shaver switched on. You can use liquid soap for a more thorough clean.
2. **Drying:** Shake off excess water and allow the shaver to air dry completely before storing or placing it back in the SmartCare Center.

### Automatic Cleaning (SmartCare Center)

1. **Placement:** After shaving, place the shaver head-down into the SmartCare Center. Ensure the shaver is dry before placing it in the center.
2. **Start Cleaning:** Press the button on the SmartCare Center to initiate the cleaning cycle. The center will automatically clean, lubricate, and dry the shaver.
3. **Cartridge Replacement:** Replace the cleaning cartridge when the indicator light on the SmartCare Center signals it is empty (approximately every 2 months with daily use).

### Replacement Parts

- **Shaving Head (Cassette):** Replace the shaving head (Braun 83M replacement head) approximately every 18 months to maintain optimal cutting performance.
- **Cleaning Cartridge:** Replace the cleaning cartridge for the SmartCare Center every 2 months.



Figure 7: Recommended replacement intervals for shaver components.

## Troubleshooting

If you encounter issues with your Braun Series 8 electric razor, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes for a quick shave, or fully for 1 hour.
Poor shaving performance.	Shaving head is worn or dirty.	Clean the shaving head thoroughly. If performance does not improve, replace the shaving head (Braun 83M).
Skin irritation after shaving.	Pressing too hard, or skin not accustomed to electric shaving.	Shave with light pressure. Allow 2-3 weeks for your skin to adapt to a new shaver. Consider wet shaving with foam/gel.
SmartCare Center not cleaning.	Cleaning cartridge is empty or not inserted correctly.	Replace the cleaning cartridge. Ensure it is clicked firmly into place.

## Specifications

Feature	Detail
Model Name	Series 8 (8567cc)
Power Source	Battery Powered (Li-Ion)
Special Feature	Waterproof, Wet & Dry Use
Recommended Use	Beard Shaving
Manufacturer	Procter & Gamble
Product Dimensions	6.18 x 6.18 x 9.92 inches
Item Weight	2.09 Pounds
Battery Type	1 Lithium Ion battery (included)

Feature	Detail
Runtime	60 minutes
Wattage	5 watts

## Warranty and Support

The Braun Series 8 8567cc Electric Razor comes with a **2-year warranty**. For detailed terms and conditions, please refer to the official Braun website or the warranty card included with your product. For further assistance, troubleshooting, or to purchase replacement parts, please visit the official Braun support page or contact their customer service. You can find more information at [www.braun.com](http://www.braun.com).