

[Manuals.plus](#) /

> [Kid Trax](#) /

> Kid Trax 6V Rideamals Blue's Clues Snack Time Interactive Ride-On Toy (Model KT1612WM) Instruction Manual

Kid Trax KT1612WM

Kid Trax 6V Rideamals Blue's Clues Snack Time Interactive Ride-On Toy Instruction Manual

MODEL: KT1612WM

1. Safety Information

WARNING: Adult Assembly Required.

- This product contains small parts. Sharp edges and points may be present during assembly.
- Continuous adult supervision is required during use.
- Never use near motor vehicles, streets, swimming pools, hills, steps, or sloped driveways.
- Always wear shoes, a helmet, and pads when operating the ride-on toy.
- Allow only one rider at a time.
- If batteries are required: batteries must be handled by an adult. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

2. Product Overview

The Kid Trax 6V Rideamals Blue's Clues Snack Time Interactive Ride-On Toy is designed for children aged 18-30 months, supporting a maximum weight of 44 lbs. This interactive toy features Blue from Nickelodeon's Blue's Clues, offering a riding experience with engaging sounds and snack play.



Image: The Kid Trax 6V Rideamals Blue's Clues Snack Time Interactive Ride-On Toy, featuring Blue, with a child interacting with it.

Key Features:

- **Interactive Play:** Ride, pet, or share snacks with Blue. Includes 3 food toys (carrot, strawberry, cookie).
- **Easy Operation:** Simple push-button control for forward motion, reaching speeds up to 1.5 MPH.
- **Sound Effects:** Features 20 different interactive sounds.
- **Convenient Storage:** Built-in under-seat storage for the included snack toys.
- **Durable Tires:** Power Trax rubber traction strip tires provide a steady and smooth ride.
- **Rechargeable Battery:** Powered by a 6-Volt rechargeable battery for extended playtime.

3. Setup

3.1 Assembly

Adult assembly is required. Please refer to the separate assembly guide included in the product packaging for detailed instructions. Ensure all parts are securely fastened before initial use.

3.2 Battery Installation and Initial Charging

The ride-on toy includes a 6-Volt rechargeable battery. Before first use, the battery must be fully charged. Locate the battery compartment and connect the battery as per the assembly instructions. Plug the charger into a standard wall outlet and connect it to the toy's charging port. Allow the battery to charge for the recommended duration specified in the assembly guide (typically 8-12 hours for the first charge). Do not overcharge.



Image: A child riding the Blue's Clues toy, with icons indicating a 6V battery and charger, push-button drive system, and 1.5 mph max speed.

4. Operating Instructions

4.1 Riding the Toy

To operate the ride-on toy, ensure the child is seated comfortably and securely. The toy is designed for one rider only. Press the simple push-button control to move the toy forward. The maximum speed is 1.5 MPH, suitable for toddlers.



Image: A child riding the Blue's Clues ride-on toy outdoors, with an overlay indicating "One Rider", "18-30 Months", and "44 lb Max Weight".

4.2 Interactive Features

The toy features 20 unique sounds that activate during play. Children can also interact with Blue by "feeding" the included snack toys (carrot, strawberry, cookie) to Blue's mouth. These snacks can be stored in the compartment located under Blue's spot.



Image: A child feeding a toy carrot to the Blue's Clues ride-on toy, with an overlay showing the three included play snacks.



Image: Two children interacting with the Blue's Clues ride-on toy, one petting Blue and the other looking at the storage compartment under Blue's spot.




Image: A child interacting with the Blue's Clues ride-on toy, with an overlay indicating "20 Sounds" and "Feed & Care for Me!".

4.3 Official Product Video

Your browser does not support the video tag.

Video: An official product video from Kid Trax showcasing the 6V Rideamals Blue's Clues toy in action, highlighting its interactive features, ease of use, and the fun children can have with it.

5. Maintenance

5.1 Battery Care

To maximize battery life, always recharge the 6-Volt battery after each use. Do not allow the battery to fully discharge. Store the toy with a fully charged battery if it will not be used for an extended period. Refer to the battery care section in the assembly guide for detailed instructions and safety precautions.

5.2 Cleaning

Wipe the toy clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the toy's finish or electronic components.

5.3 Tire Maintenance

The Power Trax rubber traction strip tires are designed for durability. Periodically inspect the tires for wear and tear. Ensure they are free from debris that could affect performance.

6. Troubleshooting

If the toy is not functioning as expected, please review the following common issues:

- **Toy does not move:** Check if the battery is fully charged and properly connected. Ensure the push-button control is being pressed correctly.
- **No sounds:** Verify that the battery is charged. If the issue persists, contact customer support.
- **Reduced speed or short playtime:** This may indicate a low battery charge or an aging battery. Ensure the battery is fully charged before each use.

For further assistance, please refer to the complete troubleshooting section in the product's original manual or contact Kid Trax customer support.

7. Specifications

Feature	Detail
Product Dimensions	25.35 x 18.86 x 16.51 inches
Item Weight	15 pounds
Item Model Number	KT1612WM
Manufacturer Recommended Age	18-30 months (Product description states 18-30 months, specifications state 36 months - 7 years. Following product description for consistency with target audience.)
Maximum Weight Capacity	44 lbs
Battery	6-Volt Rechargeable
Max Speed	1.5 MPH
Interactive Sounds	20 unique sounds
Included Accessories	3 food toys (carrot, strawberry, cookie), 6V Battery, Charger

8. Warranty and Support

For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official Kid Trax website. For customer support, technical assistance, or to inquire about replacement parts, please contact Kid Trax directly through their official channels.