

[Manuals.plus](#) /

› [hatisan](#) /

› Hatisan Crochet Tote Bag User Manual - Large Knit Shoulder Bag Model A Large 1

hatisan A Large 1

Hatisan Crochet Tote Bag User Manual

MODEL: A LARGE 1

Introduction

This manual provides essential information for the proper use and care of your Hatisan Crochet Tote Bag. Please read these instructions carefully to ensure optimal product longevity and satisfaction.

Product Features

- **Material:** Constructed from high-quality, lightweight, and durable polyester knit. The soft, foldable design ensures portability without adding burden. Features a mesh design to allow sand to easily fall through, ideal for beach use.
- **Large Capacity:** Designed with ample space to accommodate items such as an iPad, wallet, A4 magazine, cellphones, umbrella, sunglasses, slippers, and cosmetics.
- **Design:** Stylish crochet pattern suitable for various occasions. Features durable sewing and exquisite workmanship.
- **Versatility:** Ideal for seaside holidays, vacations, parties, shopping, dating, and daily use. The solid color design adds a delicate and trendy aesthetic.



Image: The Hatisan Large Crochet Tote Bag in a beige color, showcasing its overall design and texture.

Product size



This crochet beach bag is made of high-quality material.

Image: Visual representation of the bag's dimensions, highlighting its large size and capacity.

CROCHET BAG DETAILS DISPLAY



Comfortable shoulder straps



Exquisite Workmanship



Soft knitted fabric



Beautiful knitting pattern

Image: Detailed views of the bag's construction, including the comfortable shoulder straps, intricate knit pattern, and soft fabric texture.

Usage Instructions

1. Setup

1. Upon receiving, gently unfold the bag. Due to packaging, it may appear compressed.
2. Inspect the bag for any loose threads or damage. If any issues are found, refer to the 'Warranty and Support' section.

2. Operating

- **Carrying:** The bag features comfortable shoulder straps designed for easy carrying. It can be worn over the shoulder or carried by hand.
- **Storage:** Utilize the spacious interior for your belongings. The flexible knit material allows for various items to be stored.
- **Folding:** When not in use, the bag can be folded compactly for convenient storage or travel.

Your browser does not support the video tag.

Video: Demonstration of the Hatisan Large Crochet Tote Bag, showcasing its capacity and how it can be carried. This video illustrates the bag's flexibility and practical use for various items.



Image: The bag displayed with various items inside, demonstrating its large capacity for daily essentials, including a phone, laptop, cosmetics, and an A4 magazine.

Care and Maintenance

- **Cleaning:** Hand wash gently with mild soap and cold water. Avoid harsh detergents or bleach.
- **Drying:** Lay flat to air dry. Do not tumble dry. Avoid direct sunlight to prevent color fading.
- **Storage:** Store in a cool, dry place away from direct sunlight when not in use. Fold neatly to maintain shape.
- **Avoid Snags:** Be mindful of sharp objects that could snag the crochet knit.

Troubleshooting

- **Minor Snags:** If a thread snags, gently push it back into place with a needle. Do not pull or cut it.
- **Stretching:** Overfilling the bag with heavy items may cause some stretching over time. Distribute weight evenly to minimize this.
- **Stains:** Address stains promptly by spot cleaning with a damp cloth and mild soap.

Specifications

Feature	Detail
Product Dimensions	19 x 6 x 25 inches (including handle length)
Material	Polyester
Color	Beige
Department	Women's
Origin	Imported

Warranty and Support

For any questions, concerns, or warranty inquiries regarding your Hatisan Crochet Tote Bag, please contact the manufacturer directly through the retailer's customer service portal. Please retain your proof of purchase for any support requests.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

