Soundcore A3136

Soundcore Glow Mini Portable Speaker User Manual

Model: A3136

Brand: Soundcore

Introduction

Thank you for choosing the Soundcore Glow Mini Portable Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The Soundcore Glow Mini offers 360-degree sound, a dynamic light show, and robust IP67 waterproof and dustproof protection, making it ideal for various environments from home to outdoor adventures.

What's in the Box

- soundcore Glow Mini Portable Speaker
- 60cm USB-C to USB-C Cable
- Quick Start Guide
- Warranty Card
- Safety Sheet

Product Overview & Features



The Soundcore Glow Mini Portable Speaker, showcasing its vibrant light effects and compact design.

360-Degree Dynamic Sound



This portable speaker features an 8W speaker with a single passive radiator, delivering immersive 360-degree dynamic sound in a compact form factor.

Full-Body Lighting & Beat-Synced Light Show




The 360-degree light show synchronizes with your music, enhancing any party atmosphere. Choose from five multicolor light modes and a single-color ambient light mode via the Soundcore app.

IP67 Waterproof and Dustproof Protection



Enjoy worry-free listening with IP67 protection. The Glow Mini is fully waterproof and dustproof, even floating in water, making it perfect for poolside or beach use.




Its dustproof rating ensures that a little dust won't interrupt your enjoyment.

Long Battery Life



Listen for up to 12 hours on a single charge. Note: Battery life may be reduced when using the light effects.

PartyCast 2.0 Technology




With PartyCast 2.0, you can connect over 100 Soundcore speakers simultaneously for synchronized sound and lighting, creating an enhanced party atmosphere.

Customizable EQ and Light Effects via Soundcore App



Personalize your listening experience and light show by customizing the EQ and light effects through the dedicated Soundcore app.

Pocket-Sized and Portable



Measuring just 76mm around and featuring a built-in strap, the Glow Mini is easy to carry and attach to your backpack for music on the go.

Setup

Charging Your Speaker

Before first use, fully charge your Soundcore Glow Mini. Connect the provided USB-C to USB-C cable to the charging port on the speaker and to a compatible USB power adapter (not included). The charging time is approximately 3 hours.

Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button until the light indicator flashes blue.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Soundcore Glow Mini" in the list of available Bluetooth devices and select it to pair.
4. Once connected, the light indicator will turn solid blue, and you will hear an audible confirmation.

Operating Your Speaker

Button Functions

Button	Function
Power Button	Press and hold to power on/off. Short press to play/pause music or answer/end calls.
Volume +	Increase volume.
Volume -	Decrease volume.
Bluetooth Button	Press to enter Bluetooth pairing mode.

Button	Function
Light Mode Button	Cycle through different light modes.
PartyCast Button	Initiate or join PartyCast mode to link multiple speakers.

Soundcore App

Download the Soundcore app from your device's app store to unlock the full potential of your Glow Mini speaker. The app allows you to:

- Customize the equalizer (EQ) settings for a tailored audio experience.
- Select and personalize various light effects and colors.
- Update firmware for improved performance and new features.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the surface of the speaker. Do not use any corrosive cleaners or chemicals.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Water Resistance:** While the speaker is IP67 waterproof, ensure the charging port cover is securely closed before exposing it to water. After exposure to water, dry the speaker thoroughly before charging.

Troubleshooting

Cannot Pair with Device

- Ensure the speaker is in Bluetooth pairing mode (flashing blue light).
- Make sure Bluetooth is enabled on your device and it is within range (up to 30 meters).
- Forget "Soundcore Glow Mini" from your device's Bluetooth list and try pairing again.
- Restart both the speaker and your device.

No Sound

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is successfully paired and connected to your device.
- Try playing audio from a different application or source.

Poor Sound Quality

- Move the speaker closer to your device to reduce interference.
- Avoid placing the speaker near obstacles or other electronic devices that may cause interference.

- Adjust the EQ settings in the Soundcore app.

Speaker Not Charging

- Ensure the charging cable is securely connected to both the speaker and the power source.
- Try a different USB-C cable or power adapter.
- Check the charging port for any debris or damage.

Specifications

Feature	Detail
Model Name	A3136
Speaker Type	Portable Speaker
Connectivity Technology	Bluetooth
Bluetooth Range	30 Meters
Speaker Maximum Output Power	8 Watts
Battery Life	12 Hours
Charging Time	3 Hours
Water Resistance Level	IP67 (Waterproof and Dustproof)
Product Dimensions	2.99"D x 2.99"W x 3.66"H
Item Weight	9.9 ounces (280 Grams)
Included Components	soundcore Glow Mini, 60cm C-C cable, Quick Start Guide, Safety Sheet, Warranty Card

Warranty and Support

Your Soundcore Glow Mini Portable Speaker comes with a limited warranty. Please refer to the included Warranty Card for detailed terms and conditions.
For further support, frequently asked questions, or to explore other Soundcore products, please visit the official Soundcore store:

Visit the Soundcore Store

You can also download the full User Manual in PDF format for more comprehensive information.Download User Manual (PDF)

© 2024 Soundcore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question