

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Xinbeiya](#) /

› [Xinbeiya Rechargeable Game Handheld Cube User Manual](#)

Xinbeiya B0CFDW7GNB

Xinbeiya Rechargeable Game Handheld Cube User Manual

Model: B0CFDW7GNB

PRODUCT OVERVIEW

The Xinbeiya Rechargeable Game Handheld Cube is an interactive electronic game device designed to challenge brain and memory skills through 15 engaging games. It features a compact, portable design with a score display screen and adjustable volume levels, making it suitable for various environments.



Image: The Xinbeiya Rechargeable Game Handheld Cube, a black cube with colorful light-up squares and a digital display on top.

15**Puzzle Games For All Ages**

Single Mode
9 Games

PK Mode
6 Games



*Colorful Flash Lights
and Dynamic Music*

RECHARGEABLE**CHARGING CABLE
INCLUDED**

Image: An illustration highlighting the 15 puzzle games, single and PK modes, colorful flash lights, dynamic music, and rechargeable feature of the cube.

WHAT'S IN THE Box

- 1 x Xinbeiya Rechargeable Game Handheld Cube
- 1 x USB Charging Cable

SETUP

Charging the Device

The Game Handheld Cube comes with a built-in rechargeable Lithium Polymer battery. Before first use, or when the battery indicator on the display shows low power, charge the device using the provided USB cable.

1. Locate the charging port on the device, typically covered by a dustproof cover.
2. Connect the small end of the USB charging cable to the cube's charging port.

3. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The display will indicate charging status. A full charge typically takes approximately 2-3 hours and provides up to 5 hours of game time.



Image: The game cube showing its dimensions (2.75 inches on each side) and indicating the USB charging port with a dustproof cover.

Powering On/Off

Press and hold the power button (usually indicated by a universal power symbol) located on the top panel of the cube to turn the device on or off.

OPERATING INSTRUCTIONS

Navigating Game Modes

The cube offers 15 different games across various categories. Use the buttons on the cube's faces to select and

interact with games. The top display shows current and highest scores.




Image: Two children observing the game cube, which displays scores for a competitive 'PK' mode, highlighting the interactive score screen.

Adjusting Volume

The cube features 4 adjustable volume levels: Loud, Medium, Low, and Mute. Press the volume button (speaker icon) on the top panel to cycle through these settings until your desired volume is reached.

Game Categories and Examples

The cube includes games designed to enhance speed, memory, and creativity.

- **Speed Games:** Focus on quick reactions and concentration.

- *Comet Hunt:* Prevent a green comet from colliding with Earth.
- *Alien Track:* Track a blue escaping alien's green route.
- *Shoot Lurker:* Eliminate all green lurkers in the universe.



Challenge Your Speed



Comet Hunt

Prevent the green comet from colliding with Earth.



Alien Track

Track the blue escaping alien's green route.



Shoot Lurker

Eliminate all the green lurkers in Universe.



Image: A young boy holding the game cube, illustrating the speed game challenges like Comet Hunt, Alien Track, and Shoot Lurker.

- **Memory Games:** Challenge and improve memory skills.

- *Space Rescue:* Rescue astronauts by following their distress signal.
- *Radar Location:* Remove buried mines on our planet.
- *Cosmos Command:* Follow the commandant's color code.



Challenge Your Memory



Space Rescue

Rescue your astronauts by following their distress signal.



Radar Location

Remove the buried mines on our planet.



Cosmos Command

Follow the commandant's color code.



Image: A young girl holding the game cube, demonstrating the memory game challenges such as Space Rescue, Radar Location, and Cosmos Command.

- **Creativity Games:** Encourage imaginative play.

- *Create Star Show:* Customize colors to flash with dynamic music.
- *Planet Rock:* Compose your own tunes using the cube.



Challenge Your Creativity



Planet Rock

Compose your favorite music.



Create Star Show

Create unique music star show of your own.



Image: Two young boys interacting with the game cube, highlighting the creativity games like Create Star Show and Planet Rock, which involve music and light customization.

MAINTENANCE

Cleaning

To clean the cube, gently wipe its surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.

Storage

Store the device in a cool, dry place away from direct sunlight and extreme temperatures. When storing for extended periods, ensure the battery is partially charged (around 50%) to prolong its lifespan.

TROUBLESHOOTING

- **Device does not power on:**

- Ensure the battery is fully charged. Connect the cube to a power source using the USB cable and allow it

to charge for at least 30 minutes before attempting to power on again.

- Press and hold the power button for a few seconds to ensure it registers.

- **Buttons are unresponsive:**

- Restart the device by powering it off and then on again.
- Ensure the cube is clean and free from debris that might obstruct button presses.

- **Sound issues (no sound or distorted sound):**

- Check the volume setting by pressing the volume button to cycle through the levels (Loud, Medium, Low, Mute). Ensure it is not set to Mute.

- **Display is blank or flickering:**

- Recharge the device. A low battery can affect display performance.
- Restart the device.

SPECIFICATIONS

Feature	Detail
Product Dimensions	2.8 x 2.8 x 2.8 inches
Item Weight	7.3 ounces
Battery Type	1 Lithium Polymer (included)
Recommended Age	6 - 14 years
Manufacturer	Xinbeiya
Game Time (approx.)	5 hours (on full charge)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Xinbeiya website. Keep your purchase receipt as proof of purchase for any warranty claims.