

[Manuals.plus](#) /

› [Giecy](#) /

› Giecy Gaming Mouse Pad XXL 800x300mm Instruction Manual

## Giecy RMP208/209

# Giecy Gaming Mouse Pad XXL 800x300mm Instruction Manual

## INTRODUCTION

This instruction manual provides essential information for the proper use and care of your Giecy Gaming Mouse Pad XXL 800x300mm. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.



Image: The Giecy Gaming Mouse Pad XXL 800x300mm featuring a vibrant flame design.

## PRODUCT FEATURES

- **Spacious Gaming and Work Surface:** This mouse pad measures 80 cm x 30 cm, providing ample space for both your keyboard and mouse, enhancing your gaming setup and office productivity.

# LARGER SIZE

Suitable for a variety of occasions Protective layer



Image: The mouse pad illustrating its large dimensions of 80cm by 30cm.

- **Atmospheric and Durable Design:** Features a minimalist design with smooth, stitched edges for a unique aesthetic. Advanced printing technology ensures vibrant, long-lasting colors, making it an attractive addition to any desk.




Image: A user engaged in gaming, utilizing the Giecy Gaming Mouse Pad XXL as part of their desk setup.

- **Ultra-Smooth Surface for Precise Control:** The optimized surface material allows for consistent and precise mouse movements, crucial for both gaming and detailed work.

# ULTRA SMOOTH SURFACE

Smooth surface and accurate mouse movement  
improve the gaming experience



Image: A close-up view of the mouse pad's ultra-smooth surface, demonstrating smooth mouse movement.

- **Non-Slip Rubber Base:** Equipped with a natural rubber base that firmly adheres to your desk, preventing unwanted movement and ensuring stability during intense use.



Image: The underside of the mouse pad, highlighting its non-slip rubber base for secure placement.

- **Washable and Easy to Maintain:** Designed to be washable and fast-drying, making it easy to clean and maintain its appearance and performance over time.

# WASHABLE & DURABLE

Prevent accidental damage from spilled liquid  
washable and fast drying



Anti-slip rubber



Machine washable



Easy to clean

Image: The mouse pad being cleaned with a cloth, demonstrating its washable feature.

## SETUP

1. **Unpack:** Carefully remove the mouse pad from its packaging.
2. **Unroll:** Unroll the mouse pad on a clean, flat desk surface. If the pad has minor creases from packaging, these will typically flatten out with use or by gently rolling it in the opposite direction.
3. **Position:** Ensure the non-slip rubber base is in full contact with the desk surface to prevent sliding.
4. **Arrange:** Place your keyboard and mouse on the pad in your preferred configuration.

## OPERATING INSTRUCTIONS

The Giecy Gaming Mouse Pad is designed for straightforward use. Simply place your mouse on the pad and enjoy the smooth, consistent tracking surface.

- The ultra-smooth surface ensures precise and consistent mouse movement, which is beneficial for both gaming and general computer tasks.
- Utilize the large surface area for wide mouse sweeps during gaming or for comfortable navigation during detailed work.

## MAINTENANCE

- **Cleaning:** The mouse pad is washable. For best results, hand wash with mild soap and cold water. Avoid harsh detergents or bleach. Gently scrub the surface if needed.
- **Drying:** After washing, air dry the mouse pad completely before reuse. Do not tumble dry or expose to direct heat.
- **Storage:** When not in use, roll the mouse pad with the design facing outwards to help prevent creasing and maintain its flat shape.

## TROUBLESHOOTING

| Issue                       | Possible Cause                    | Solution                                                                                                              |
|-----------------------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Mouse pad not lying flat    | Creases from packaging            | Gently roll the pad in the opposite direction or place heavy, flat objects on it overnight to flatten.                |
| Mouse not tracking smoothly | Dirty mouse sensor or pad surface | Ensure the mouse sensor is clean. If the issue persists, clean the mouse pad surface as per maintenance instructions. |
| Mouse pad slipping on desk  | Desk surface is not clean or dry  | Ensure the desk surface is clean and dry. The non-slip rubber base requires direct contact for optimal grip.          |

## SPECIFICATIONS

| Feature                    | Detail                                 |
|----------------------------|----------------------------------------|
| Brand                      | Giecy                                  |
| Model Number               | RMP208/209                             |
| Color                      | 01-Flamme                              |
| Special Feature            | Non-slip                               |
| Recommended Uses           | Office, Gaming                         |
| Material                   | Rubber                                 |
| Product Dimensions (L x W) | 80L x 30W centimeters (800L x 300l mm) |
| Theme                      | Flame                                  |
| Shape                      | Rectangular                            |
| Number of Units            | 1.0 unit                               |
| Country of Origin          | China                                  |

## WARRANTY AND SUPPORT

For warranty information or product support, please contact Giecy customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question