

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZARMST](#) /

› [ZARMST 128GB Flash Drive for iPhone Instruction Manual](#)

## ZARMST ZARMST-PhotoStick-128GB

# ZARMST 128GB Flash Drive for iPhone Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the ZARMST 128GB Flash Drive, designed for seamless data transfer and storage expansion across various devices including iPhones, iPads, and PCs. Please read this manual carefully to ensure proper use and to maximize the benefits of your new flash drive.

## PRODUCT OVERVIEW

---

The ZARMST Flash Drive is a versatile external storage solution featuring multiple connectivity options and advanced functionalities. It is designed to free up space on your mobile devices and facilitate high-speed data transfer.

### Key Features:

- **Storage Expansion:** Provides 128GB of additional storage capacity for photos, videos, and other files.
- **Multi-Port Design:** Equipped with iOS (Lightning), USB 3.0, Type-C, and Micro USB connectors for broad compatibility.
- **Security Features:** Includes fingerprint and password protection for enhanced data security.
- **Multifunctional App:** The EASYFLASH PRO app allows for easy file management, viewing, access, and backup of photos, videos, and contacts.
- **High-Speed Transmission:** Offers transfer rates up to 80MB/s write and 40MB/s read.

# Multi-Ports Flash Drive

Transfer photos/videos/files between multiple devices freely and easily



IOS Port



USB



Micro USB



Type C  
iPhone 15series and above



Image: The ZARMST Flash Drive demonstrating its multi-port design, connecting to different devices.



Image: The flash drive connected to an iPhone, highlighting its function as a photo stick.

## SETUP

To begin using your ZARMST Flash Drive, follow these steps:

1. **Download the EASYFLASH PRO App:** For iOS devices (iPhone/iPad), download the "EASYFLASH PRO" app from the App Store. This app is essential for managing files on your iOS device.
2. **Connect to Your Device:**
  - **For iPhone/iPad:** Slide the connector to reveal the Lightning port and insert it into your device's charging port. The app should prompt you to open it.
  - **For Android Devices:** Use the appropriate Type-C or Micro USB connector and insert it into your Android device.
  - **For PC/Laptop:** Slide the connector to reveal the USB 3.0 port and insert it into an available USB port on your computer.
3. **Initial Recognition:** Your device should recognize the flash drive automatically. For iOS, ensure the EASYFLASH PRO app is open. For PCs, the drive will appear as a removable disk.

Video: A demonstration of connecting the ZARMST Flash Drive to an iPhone and using the associated app for file management.

## OPERATING INSTRUCTIONS

### File Transfer:

1. **From Device to Flash Drive:** Open the EASYFLASH PRO app (for iOS) or access the drive via your file manager (for Android/PC). Select the files (photos, videos, documents) you wish to transfer and choose the option to copy or move them to the flash drive.
2. **From Flash Drive to Device:** Similarly, navigate to the files on the flash drive, select them, and choose to copy or move them to your device's internal storage.

### File Management:

The EASYFLASH PRO app allows you to:

- View and access all stored photos, videos, and documents.

- Backup your address book.
- Organize files into folders.

## Security Features:

Utilize the built-in fingerprint (Touch ID) and password protection features within the EASYFLASH PRO app to secure your sensitive data on the flash drive. This prevents unauthorized access to your files.



Image: The app interface displaying file management and security options.

## Social Media Sharing:

The app enables direct sharing of photos and videos from the flash drive to social media platforms like Instagram and Twitter with a single click.

## MAINTENANCE

To ensure the longevity and optimal performance of your ZARMST Flash Drive, please observe the following maintenance guidelines:

- **Handle with Care:** Avoid dropping the device or subjecting it to strong impacts, which can damage internal components.
- **Protect Connectors:** Always ensure the connectors are retracted or covered when not in use to prevent dust and physical damage.
- **Avoid Extreme Conditions:** Do not expose the flash drive to extreme temperatures, humidity, or direct sunlight.
- **Safe Removal:** Always safely eject the flash drive from your computer or mobile device before physically removing it to prevent data corruption.

## TROUBLESHOOTING

### Lower Displayed Capacity:

It is common to see a slightly lower capacity than the advertised value (e.g., 121GB instead of 128GB). This is due to the difference in how storage brands (1GB = 1,000MB) and computer operating systems (1GB = 1,024MB) calculate gigabytes. This is normal and does not indicate a defect.

## Device Not Recognized:

- Ensure the flash drive is fully inserted into the correct port.
- For iOS devices, verify that the EASYFLASH PRO app is installed and open.
- Try connecting the flash drive to a different port or device to rule out a port-specific issue.
- Restart your device and try again.

## Slow Transfer Speeds:

- Ensure you are using a USB 3.0 port on your computer for optimal speeds.
- Large numbers of small files may transfer slower than fewer large files.
- Close other applications running in the background that might be consuming system resources.

## SPECIFICATIONS

Feature	Detail
Brand	ZARMST
Model Name	Photo Stick
Item Model Number	ZARMST-PhotoStick-128GB
Memory Storage Capacity	128 GB
Flash Memory Type	USB
Read Speed	80 Megabytes Per Second
Write Speed	40 Megabytes Per Second
Connectivity Technology	USB
Hardware Connectivity Technology	Lightning, USB Type A
Hardware Interface	USB
Special Feature	Compact, Lightweight
Item Weight	1.13 ounces
Package Dimensions	4.53 x 3.74 x 0.67 inches

## WARRANTY AND SUPPORT

ZARMST prioritizes customer satisfaction. If you encounter any issues with your flash drive, our dedicated customer service team is available to assist you in finding a quick solution. We aim to resolve any problems within 24 hours.

For additional protection, 2-year and 3-year Photo and Data Recovery Plans are available for purchase separately. These plans offer peace of mind for your valuable data.

For support, please refer to the contact information provided with your product packaging or visit the official ZARMST store on Amazon.

