



[Manuals.plus](#) /

› [Fixwal](#) /

› [Fixwal End Tables with Charging Station User Manual](#)

Fixwal Fixwal8111111502

Fixwal End Tables with Charging Station User Manual

Model: Fixwal8111111502

INTRODUCTION

Thank you for purchasing the Fixwal End Tables with Charging Station. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new furniture. Please read this manual thoroughly before beginning assembly or use.



Image: Two Fixwal end tables, showcasing their design and functionality with a lamp, books, and a charging phone.

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the product on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Do not exceed the maximum weight recommendation of **50 pounds (22.68 kg)** for the tabletop.
- Keep the charging station away from water or excessive moisture.
- Only use the charging station for devices within its specified voltage and current limits (120V/12A AC outlets, 5V/2A USB ports).
- Regularly check all connections and fasteners to ensure they remain tight and secure.
- This product is designed for indoor use only.
- Potential safety warnings may include instructions for safe assembly, proper installation to prevent tipping, and caution about the weight limit to ensure stability.

PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact

customer support.

Fewer Parts

Easy Setup



Hardware Pack





Image: All parts for assembly, including the tabletop, charging unit, metal frame, and hardware.

- Tabletop (Engineered Wood)
- Charging Station (2 AC Outlets, 2 USB Ports)
- Metal Frame Components
- Bottom Mesh Shelf
- Adjustable Foot Pads
- Hardware Pack (Screws, Allen Wrench, etc.)
- Assembly Manual (this document)

SETUP AND ASSEMBLY

Assembly is straightforward and typically takes about 30 minutes for one person. All necessary assembly tools are included.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the table components

or your floor.

2. **Identify Parts:** Lay out all components and hardware, comparing them with the package contents list and the assembly diagram (refer to the image in the Package Contents section).
3. **Assemble the Frame:** Attach the metal frame components together using the provided screws and Allen wrench. Ensure all connections are snug but do not overtighten initially.
4. **Install Bottom Shelf:** Secure the mesh bottom shelf to the lower part of the metal frame.
5. **Attach Tabletop:** Carefully place the engineered wood tabletop onto the assembled frame. Align the pre-drilled holes and secure the tabletop with the appropriate screws.
6. **Install Charging Station:** Insert the charging station unit into the designated slot on the tabletop. Secure it if fasteners are provided.
7. **Attach Foot Pads:** Screw the adjustable foot pads into the bottom of the table legs. Adjust them as needed to ensure the table is stable and level on your floor.
8. **Final Tightening:** Once all parts are assembled, gently tighten all screws to ensure the table is sturdy.



Image: Dimensional diagram of the end table, useful for planning placement.

The compact design (15.35" W x 11.81" D x 21.26" H) makes this table suitable for small spaces, apartments, and dorms.

OPERATING INSTRUCTIONS

Your Fixwal End Table is equipped with a convenient charging station to power your electronic devices.



Image: Detail of the integrated charging station with AC and USB ports.

- **Power Connection:** Plug the 4.92 feet (59.1 inches) long power cord from the charging station into a standard wall outlet.
- **AC Outlets:** Use the two standard AC outlets (120V/12A) to power devices such as lamps, laptops, or other small appliances.
- **USB Ports:** Use the two USB ports (5V/2A) to charge smartphones, tablets, and other USB-powered devices.
- **Device Placement:** Place your devices on the tabletop or the bottom mesh shelf. The bottom shelf offers additional storage space (approximately 14.5" x 15" x 21.8 cubic feet) for books, baskets, or other items.



Image: End table in a bedroom setting, demonstrating its use as a nightstand with charging capabilities.

MAINTENANCE

Proper care will extend the life and appearance of your end table.

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the engineered wood or powder-coated steel finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage, as the table is not stain resistant.
- **Stability Check:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Foot Pads:** Ensure the adjustable foot pads are properly positioned to protect your floor and maintain stability.
- **Charging Station:** Keep the charging ports free of dust and debris. Do not attempt to disassemble the charging unit.

TROUBLESHOOTING

If you encounter any issues with your Fixwal End Table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly/unstable.	Screws are loose; uneven floor; foot pads not adjusted.	Tighten all assembly screws. Adjust the adjustable foot pads to level the table on uneven surfaces.
Charging station not working.	Power cord not plugged in; wall outlet issue; device cable faulty; overloaded circuit.	Ensure the power cord is securely plugged into a working wall outlet. Test the outlet with another device. Try a different charging cable for your device. Ensure total power draw does not exceed the charging station's limits.
Parts missing or damaged upon arrival.	Manufacturing defect or shipping damage.	Do not proceed with assembly. Contact customer support immediately with your purchase details.

SPECIFICATIONS

Feature	Detail
Brand	Fixwal
Model Name	Fixwal8111111502
Product Dimensions (D x W x H)	11.81" x 15.35" x 21.26" (29.99 cm x 39.00 cm x 54.00 cm)
Maximum Weight Recommendation	50 Pounds (22.68 kg)
Color	Light Walnut Grey
Material Type	Engineered Wood (Top), Metal (Base)
Charging Station	2 Standard AC Outlets (120V/12A), 2 USB Ports (5V/2A)
Power Cord Length	4.92 Feet (59.1 inches / 1.5 meters)
Number of Items	2 (Set of 2 End Tables)
Assembly Required	Yes (Includes all assembly tools)
Recommended Assembly People	1
Indoor/Outdoor Usage	Indoor
Stain Resistant	No

WARRANTY INFORMATION

Specific warranty details for this product are not provided in this manual. Please refer to your purchase documentation or contact the retailer for information regarding warranty coverage.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Fixwal End Tables, please contact the seller or retailer from whom

you purchased the product. Please have your purchase receipt and model number (Fixwal811111502) ready when contacting support.