

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer 06325 20W Fast Charging Car Charger and Type-C Cable User Manual

Energizer 06325

Energizer 06325 20W Fast Charging Car Charger and Type-C Cable User Manual

Model: 06325

1. INTRODUCTION

Thank you for choosing the Energizer 06325 20W Fast Charging Car Charger and Type-C Cable. This manual provides essential information for the safe and efficient use of your product. Please read these instructions carefully before use and retain them for future reference.

2. PRODUCT OVERVIEW

The Energizer 06325 is a compact and powerful car charger designed to provide fast charging for your USB-C compatible devices. It includes a dedicated USB-C port and comes with a matching Type-C to Type-C cable for immediate use.



This image displays the Energizer 20W Fast Charging Car Charger, a compact black device designed to plug into a vehicle's 12V power outlet. It features a single USB-C port with a blue LED indicator ring. Alongside the charger, a black USB-C to USB-C cable is shown, illustrating the complete charging solution.

Package Contents:

- 1 x Energizer 20W Fast Charging Car Charger
- 1 x Type-C to Type-C Cable (3 feet)

3. SETUP

1. **Locate Vehicle Power Outlet:** Identify the 12V DC power outlet (cigarette lighter socket) in your vehicle.
2. **Insert Car Charger:** Firmly insert the Energizer car charger into the 12V power outlet. Ensure it is securely seated. A blue LED indicator ring around the USB-C port will illuminate, indicating the charger is receiving power.
3. **Connect Cable:** Plug one end of the provided Type-C cable into the USB-C port on the car charger.
4. **Connect Device:** Plug the other end of the Type-C cable into your compatible USB-C device (e.g., smartphone, tablet).

4. OPERATING INSTRUCTIONS

Once properly set up, the Energizer car charger will automatically begin charging your connected device. The charger supports fast charging for compatible devices, delivering up to 20 watts of power.

- **Fast Charging:** For optimal fast charging performance, ensure your device and cable are compatible with USB Power Delivery (PD) or other fast charging protocols supported by the charger.
- **LED Indicator:** The blue LED light indicates that the charger is powered and ready to charge. It does not change color or blink to indicate charging status of the connected device.
- **Disconnecting:** To stop charging, simply unplug your device from the cable, or unplug the cable from the charger. When not in use, it is recommended to remove the car charger from the vehicle's power outlet.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the charger and cable. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger and cable in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the charger and cable for any signs of damage, such as frayed wires or cracked casings. Discontinue use if damage is found.

6. TROUBLESHOOTING

- **Device not charging:**
 - Ensure the car charger is firmly seated in the vehicle's 12V power outlet and the blue LED is illuminated.
 - Check that the cable is securely connected to both the charger and your device.
 - Verify that your vehicle's 12V power outlet is functional (e.g., by testing with another device).
 - Try using a different USB-C cable to rule out a faulty cable.
- **Slow charging:**
 - Ensure your device supports fast charging and is compatible with the charger's 20W output.
 - Close any power-intensive applications running in the background on your device.
 - Verify the cable used is capable of supporting fast charging speeds.

7. SPECIFICATIONS

Model Number	06325
Brand	Energizer
Power Source	Vehicle 12V DC Outlet
Wattage	20 watts
Amperage	1.67 Amps
Total USB Ports	1 (USB Type C)
Special Feature	Fast Charging
Included Components	20 watt fast charging car charger, Type C cable
Cable Length	3 feet

Color	Black
-------	-------

8. SAFETY INFORMATION

- Do not expose the product to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the product to severe impacts.
- Do not attempt to disassemble, repair, or modify the charger or cable. This will void the warranty and may cause damage or injury.
- Keep out of reach of children.
- Ensure proper ventilation around the charger during use.
- Only use the charger in a 12V DC vehicle power outlet.

9. WARRANTY AND SUPPORT

Energizer products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Energizer website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CFFCVJFT>

More documents and user manuals: <https://manuals.plus/>