Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hyundai Elantra Hybrid

2023 Hyundai Elantra Hybrid Owners Manual

Comprehensive guide for your Elantra Hybrid vehicle.

Introduction

This manual provides essential information regarding the operation, maintenance, and safety of your 2023 Hyundai Elantra Hybrid. Please read it thoroughly to ensure safe and efficient use of your vehicle. Keep this manual in your vehicle for future reference.

Setup and Initial Familiarization

Before operating your Elantra Hybrid, familiarize yourself with its key features and controls.

Vehicle Entry and Seating

- **Key Fob Operation:** Use the key fob to lock/unlock doors and open the trunk. Refer to the "Security System" section for detailed instructions.
- **Seat Adjustment:** Adjust the driver's seat for optimal comfort and control. Ensure proper distance from the steering wheel and pedals.
- **Mirror Adjustment:** Adjust side mirrors and the rearview mirror for clear visibility.

Dashboard Overview

Locate the instrument cluster, infotainment system, climate controls, and other essential buttons. Understand the meaning of various indicator lights.

Operating Your Elantra Hybrid

This section covers the fundamental aspects of driving and utilizing your vehicle's features.

Starting and Stopping the Engine

1. Ensure the vehicle is in Park (P).
2. Press the brake pedal firmly.
3. Press the "ENGINE START/STOP" button. The vehicle will enter "READY" mode (indicated by a green light on the instrument cluster).
4. To stop, shift to Park (P) and press the "ENGINE START/STOP" button again.

Driving Modes

Your Elantra Hybrid offers various driving modes to optimize performance and fuel efficiency. Consult your instrument cluster for current mode indication.

- **ECO Mode:** Prioritizes fuel efficiency.
- **SPORT Mode:** Enhances throttle response and steering feel.
- **SMART Mode:** Automatically adjusts driving characteristics based on driving style.

Infotainment System

The infotainment system provides navigation, audio, and connectivity features. Refer to the dedicated infotainment manual for detailed operation.

Maintenance and Care

Regular maintenance is crucial for the longevity and performance of your Elantra Hybrid.

Scheduled Maintenance

Adhere to the recommended service schedule outlined in your warranty and maintenance booklet. This typically includes:

- Oil and filter changes
- Tire rotation and inspection
- Brake system inspection
- Fluid level checks (coolant, brake fluid, washer fluid)
- Hybrid system checks

Tire Care

Maintain correct tire pressure as specified on the driver's side door jamb. Regularly inspect tires for wear and damage.

Cleaning Your Vehicle

Use appropriate cleaning products for both interior and exterior surfaces to preserve the vehicle's finish and materials.

Troubleshooting Common Issues

This section addresses common problems you might encounter and provides basic solutions.

Warning Lights

- **Check Engine Light:** If illuminated, it indicates a potential issue with the engine or emissions system. Consult a qualified service technician.
- **Hybrid System Warning Light:** Indicates a problem with the hybrid powertrain. Seek immediate professional assistance.
- **Low Tire Pressure Warning:** Check and adjust tire pressure to recommended levels.

Vehicle Not Starting

- Ensure the brake pedal is fully depressed.
- Check the 12V auxiliary battery for charge.
- Verify the key fob is inside the vehicle.

For more complex issues, it is recommended to contact an authorized Hyundai service center.

Specifications

Key technical specifications for the 2023 Hyundai Elantra Hybrid.

Feature	Specification
Engine Type	1.6L GDI 4-cylinder Hybrid
Total System Horsepower	139 hp
Transmission	6-speed EcoShift® Dual Clutch Transmission (DCT)
Fuel Economy (Combined)	Approx. 50-54 MPG (varies by trim)
Fuel Tank Capacity	11.0 gallons (approx.)
Seating Capacity	5 passengers

Note: Specifications may vary based on trim level and regional market. Refer to your vehicle's specific documentation for exact details.

Warranty and Support

Your 2023 Hyundai Elantra Hybrid is backed by a comprehensive warranty program.

Warranty Information

- **New Vehicle Limited Warranty:** Typically 5 years/60,000 miles.
- **Powertrain Limited Warranty:** Typically 10 years/100,000 miles.
- **Hybrid System Components Warranty:** Specific coverage for hybrid battery and related components, often 10 years/100,000 miles or more.

Please refer to your separate Warranty and Maintenance Booklet for complete terms, conditions, and limitations.

Customer Support

For assistance, questions, or to schedule service, please contact your authorized Hyundai dealer or Hyundai Customer Care.

- **Hyundai USA Customer Care:** Visit HyundaiUSA.com/contact-us
- **Roadside Assistance:** Information typically found in your owner's manual or warranty booklet.

© 2023 Hyundai Motor America. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFG48BY3

More documents and user manuals: **https://manuals.plus/**