

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GoSports](#) /

› [GoSports 54 Inch Air Hockey Arcade Table User Manual - Model AIRHOCKEY-54-OAK](#)

GoSports AIRHOCKEY-54-OAK

GoSports 54 Inch Air Hockey Arcade Table User Manual

Model: AIRHOCKEY-54-OAK | Brand: GoSports

1. INTRODUCTION

Thank you for choosing the GoSports 54 Inch Air Hockey Arcade Table. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new air hockey table. Please read this manual thoroughly before use and retain it for future reference.

1.1 Package Contents

Verify that all components listed below are present in your package. If any items are missing or damaged, please contact GoSports customer support.

- GoSports 54 Inch Air Hockey Table
- 2 Pushers
- 3 Pucks
- AC Adapter (for motor and scoreboard)
- Electronic Scoreboard
- Assembly Hardware
- Instruction Manual



Image 1.1: The GoSports 54 Inch Air Hockey Arcade Table with included accessories.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Keep small parts away from children to avoid choking hazards.
- Ensure the table is placed on a level, stable surface to prevent tipping.
- Only use the provided AC adapter.
- Do not expose the table to excessive moisture or direct sunlight.
- Adult supervision is recommended for younger players.
- Do not attempt to modify or disassemble the AC motor or electronic components.
- Keep hands and fingers clear of moving parts during operation.

3. SETUP AND ASSEMBLY

The GoSports 54 Inch Air Hockey Table comes largely pre-assembled. Follow these steps to complete the setup:

3.1 Attaching the Legs

1. Carefully unbox the air hockey table and place the main table body upside down on a soft, protected surface to prevent scratches.

2. Identify the four leg pieces and the corresponding attachment points on the underside of the table.
3. Align each leg with its designated corner and secure it using the provided hardware (screws, washers, nuts) as per the included assembly diagram. Ensure all connections are tight.
4. Attach the leg levelers to the bottom of each leg. Adjust them later to ensure the table is perfectly level.

3.2 Attaching the Goals

5. Locate the two goal assemblies.
6. Attach each goal to its respective end of the table using the provided screws.

3.3 Connecting the AC Adapter

7. Once the table is fully assembled and upright, locate the AC adapter port, typically on the underside or side of the table.
8. Plug the AC adapter into the port and then into a standard electrical outlet. This powers the air blower and the electronic scoreboard.



Image 3.1: Illustration of the table's underside, indicating leg assembly points.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- After connecting the AC adapter, the air blower will automatically activate, creating a cushion of air for smooth puck movement.
- The electronic scoreboard will also power on.
- To turn off the table, simply unplug the AC adapter from the wall outlet.

4.2 Using the Electronic Scoreboard

The electronic scoreboard tracks scores for two players. It typically features:

- **ON/OFF/RESET Button:** Press to turn the scoreboard on or off. Hold to reset scores to zero.
- **Score Sensors:** Located in each goal, these sensors automatically detect when a puck enters and update the score.
- **Battery Compartment:** The scoreboard may require AAA batteries for its display, even if the main air blower is AC powered. (Check product specifications for battery requirements).



Image 4.1: The electronic scoreboard with score tracking for two players.

4.3 Gameplay

1. Each player stands at one end of the table, holding a pusher.
2. Place a puck in the center of the playing surface.
3. Players use their pushers to strike the puck, attempting to score by sending it into the opponent's goal.
4. The air blower ensures the puck glides smoothly across the surface.
5. The electronic scoreboard will automatically track goals.
6. The game typically ends when one player reaches a predetermined score (e.g., 7 goals).



Image 4.2: The AC powered air blower creates a smooth playing surface for the puck.

5. MAINTENANCE

Proper maintenance will extend the life of your air hockey table:

- **Cleaning:** Regularly wipe the playing surface with a soft, damp cloth. Avoid abrasive cleaners or solvents. Ensure the surface is dry before playing.
- **Dusting:** Dust the air holes on the playing surface periodically to ensure optimal airflow. A soft brush or compressed air can be used carefully.
- **Storage:** When not in use, store the table in a dry, cool place away from direct sunlight and extreme temperatures.
- **Puck and Pusher Care:** Keep pucks and pushers clean. Replace worn or damaged items as needed.
- **Leg Levelers:** Periodically check and adjust the leg levelers to maintain a perfectly level playing surface.

6. TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Puck does not glide smoothly.	Air holes are blocked by dust or debris. AC adapter not properly connected.	Clean air holes with a soft brush or compressed air. Ensure AC adapter is securely plugged into the table and wall outlet.
Electronic scoreboard is not working.	AC adapter not connected. Scoreboard batteries are dead (if applicable). Scoreboard is off.	Check AC adapter connection. Replace AAA batteries in the scoreboard. Press the ON/OFF button on the scoreboard.

Problem	Possible Cause	Solution
Table is wobbly or uneven.	Legs are not securely tightened. Leg levelers are not adjusted.	Tighten all leg assembly hardware. Adjust the leg levelers until the table is stable and level.

7. SPECIFICATIONS

Feature	Detail
Model Number	AIRHOCKEY-54-OAK
Product Dimensions (L x W x H)	137.2 cm x 68.6 cm x 78.7 cm (54 in x 27 in x 31 in)
Item Weight	17.2 kg (38 lbs)
Material	Engineered Wood
Power Source	AC Motor (for air blower)
Scoreboard	Electronic LED (AAA batteries not included for display)
Included Accessories	2 Pushers, 3 Pucks, AC Adapter
Assembly Required	Yes (Legs and goals)

8. WARRANTY AND CUSTOMER SUPPORT

GoSports products are manufactured with quality and durability in mind. For specific warranty details, please refer to the warranty card included with your product or visit the official GoSports website.

8.1 Contact Information

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact GoSports customer support:







Website: www.gosports.com

Email: support@gosports.com

Phone: Refer to the GoSports website for regional contact numbers.

© 2025 GoSports. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - AIRHOCKEY-54-OAK

	<p>GoSports 54" Foosball Table Assembly Instructions and User Guide</p> <p>Detailed assembly instructions, parts list, and gameplay guide for the GoSports 54" Foosball Table. Learn how to set up and play this premium game, including customer service information and warranty details.</p>
	<p>GoSports Croquet Set - Rules and How to Play</p> <p>Learn how to play the GoSports Croquet Set with these easy-to-follow instructions. Includes setup, gameplay, scoring, and important safety tips.</p>
	<p>GoSports Toppling Tower Game Instructions</p> <p>Learn how to set up and play the GoSports Toppling Tower game with these instructions. Includes standard rules, fun optional rules, and important warnings.</p>
	<p>GoSports 12' x 9' Sports Barrier Net Assembly Instructions</p> <p>Step-by-step guide for assembling the GoSports 12' x 9' Sports Barrier Net, including important safety warnings and customer service information.</p>
	<p>GoSports Bocce Ball Game Rules and Instructions</p> <p>Official rules for playing GoSports Bocce Ball, covering both Free Play and Courted Bocce. Learn the game objective, scoring, and important safety guidelines.</p>
	<p>GoSports Red Zone Challenge: Assembly and Game Instructions</p> <p>Detailed instructions for assembling and playing the GoSports Red Zone Challenge, an outdoor target game. Includes a list of components, step-by-step assembly guide, game setup, standard rules, scoring, alternate game modes, and customer service contact information.</p>