Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JADEMALL Xiaomi Pad 6/6 Pro

JADEMALL Bluetooth Keyboard with Trackpad for Xiaomi Pad 6/6 Pro 11-inch Tablet

User Instruction Manual

Introduction

This manual provides detailed instructions for the JADEMALL Bluetooth Keyboard with Trackpad, designed specifically for the Xiaomi Pad 6 and Xiaomi Pad 6 Pro 11-inch tablets. This 2-in-1 accessory combines a protective case with a detachable, backlit Bluetooth keyboard, enhancing your tablet's functionality for work, study, and entertainment.

Compatibility

This keyboard case is exclusively designed for the **Xiaomi Pad 6** and **Xiaomi Pad 6 Pro 2023 11-inch** models. It is not compatible with any other tablet models, including the Xiaomi Pad 5/5 Pro. Please verify your tablet model before use.




Image: Visual guide confirming compatibility with Xiaomi Pad 6/6 Pro (left) and incompatibility with Xiaomi Pad 5/5 Pro (right).

What's in the Box

- 1 x JADEMALL Protective Case for Xiaomi Pad 6/6 Pro
- 1 x Bluetooth Trackpad Keyboard
- 1 x USB Charging Cable for Keyboard
- 1 x Instruction Manual (this document)

Setup

Bluetooth Connection

Follow these steps to connect your keyboard to your Xiaomi Pad 6/6 Pro:

1. Ensure the keyboard is charged. Locate the power switch on the keyboard and turn it**ON**.
2. On your Xiaomi Pad 6/6 Pro, go to**Settings** > **Bluetooth** and turn **ON** Bluetooth.

3. On the keyboard, press the **Fn + C** keys simultaneously. The Bluetooth indicator light on the keyboard will begin to flash blue, indicating it is in pairing mode.
4. On your tablet, in the Bluetooth device list, select "**Bluetooth 5.0 Keyboard**" (or similar name). The tablet will connect to the keyboard. The blue indicator light on the keyboard will turn off once connected.

For subsequent uses, once the keyboard and tablet have been paired, they should automatically connect within a few seconds when both devices' Bluetooth functions are active and the keyboard is powered on.



Image: Illustration of the wireless Bluetooth keyboard, its magnetic integration, and compatibility with various operating systems.

Operating Instructions

Using the Trackpad

The integrated trackpad allows for precise navigation and control of your tablet, similar to a laptop mouse. Standard gestures such as tapping, scrolling, and pinch-to-zoom are supported, depending on your tablet's operating system and application support.

Adjusting Backlight

The keyboard features 7-color backlighting with 3 adjustable brightness levels. Use the dedicated backlight keys (often indicated by a light bulb icon or Fn + specific keys) to cycle through colors and adjust brightness to suit your environment.



Image: The keyboard displaying its 7-color backlight feature, enhancing visibility in low-light conditions.

Adjustable Viewing Angles

The protective case is designed with integrated anti-slip grooves, allowing you to set your tablet at 3 different stable viewing angles. This flexibility is ideal for various activities such as typing, watching videos, or making presentations.




Image: Diagram illustrating how to adjust the tablet to multiple viewing angles using the case's design.

Automatic Sleep/Wake Function

The case supports an automatic sleep/wake function. Opening the case will automatically wake your Xiaomi Pad 6/6 Pro, and closing it will put the tablet to sleep, helping to conserve battery life.

Integrated Pen Holder

The case includes a dedicated slot for your stylus (S Pen or similar), ensuring it is securely stored and easily accessible.



Image: Close-up view highlighting the integrated pen holder, USB charging port, and the keyboard's rechargeable lithium battery.

Maintenance

Cleaning

To clean the case and keyboard, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the surfaces. Ensure the keyboard is powered off and disconnected from the tablet before cleaning.

Charging the Keyboard

The keyboard has a built-in rechargeable lithium polymer battery. When the battery is low, connect the provided USB charging cable to the keyboard's charging port and to a standard USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged.

Troubleshooting

- **Keyboard not connecting via Bluetooth:**
  - Ensure the keyboard is powered on and fully charged.
  - Make sure Bluetooth is enabled on your Xiaomi Pad 6/6 Pro.
  - Press Fn + C on the keyboard to enter pairing mode (blue light flashing).
  - Forget the device in your tablet's Bluetooth settings and attempt to re-pair.
  - Restart both the keyboard and your tablet.
- **Trackpad or keys not responding:**
  - Check if the keyboard is properly connected via Bluetooth.
  - Ensure the keyboard battery is not critically low.
  - Restart the keyboard and tablet.
- **Backlight not working:**
  - Ensure the keyboard is powered on and connected.
  - Press the backlight adjustment keys to cycle through colors and brightness levels.

Specifications

Model Number	Xiaomi Pad 6/6 Pro
Connectivity Technology	Bluetooth
Keyboard Layout	QWERTY
Number of Keys	78
Special Feature	Backlit (7 colors, 3 brightness levels), Integrated Trackpad
Power Source	Rechargeable Lithium Polymer Battery
Material	Synthetic Leather (case), ABS (keyboard)
Compatible OS	Android (Minimum Android 13.0 required)
Package Dimensions	28.5 x 21.5 x 3.4 cm
Weight	790 g

Warranty and Support

JADEMALL is committed to providing quality products and customer satisfaction. If you encounter any issues with your keyboard case, please contact the seller or JADEMALL customer support directly for assistance. Please refer to your purchase documentation for specific warranty terms and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFHGVVVB

More documents and user manuals: **https://manuals.plus/**