

[manuals.plus](#) /

› [charmast](#) /

› [Charmast Small Portable Charger 5000mAh User Manual](#)

charmast CMP

Charmast Small Portable Charger 5000mAh User Manual

Model: CMP

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Charmast Small Portable Charger 5000mAh. Please read these instructions carefully before using the product and retain them for future reference.



Image 1.1: The Charmast portable charger connected directly to an iPhone, illustrating its compact form factor and integrated connector.

2. PRODUCT OVERVIEW

The Charmast Small Portable Charger is a compact 5000mAh power bank designed for on-the-go charging. It features 20W Power Delivery (PD) for fast charging compatible devices.

Key Features:

- **High-Speed Charging:** 20W PD output for rapid device charging.
- **Ultra-Compact Design:** Weighs approximately 0.2 pounds (3.2 ounces) with dimensions of 3.03" x 1.38" x 0.96".
- **Fast Recharging:** Supports 18W PD input for quick recharging of the power bank itself.
- **5000mAh Capacity:** Provides sufficient power for partial to full charges of various smartphones and

small devices.

- **Partial Cellphone Case Friendly:** Designed to work with phone cases less than 4mm thick.



Image 2.1: The compact size of the Charmast portable charger, shown with its dimensions (77mm x 35mm) and compared to a lipstick for scale.

For iPhone Connector

Not Applicable * iPhone 16 Pro Max/iPhone 16 Pro/iPhone 16 Plus/
iPhone 16/iPhone 15 Pro Max/iPhone 15 Pro/iPhone 15 Plus/iPhone 15



iPhone 14 Pro Max/iPhone
14 Pro/iPhone 14 Plus/iPhone 14



iPhone 13 Pro Max/iPhone
13 Pro/iPhone 13 Plus/iPhone 13



iPhone 12 Pro Max/iPhone
12 Pro/iPhone 12 Plus/iPhone 12



iPhone 11 Pro Max/iPhone
11 Pro/iPhone 11 Plus/iPhone 11



iPhone XS/iPhone XR/
iPhone X/iPhone 8, 7, 6, SE



AirPods 3/AirPods Pro 3
AirPods 2/AirPods Pro 2

Image 2.2: Compatibility information for the portable charger, detailing supported iPhone models and AirPods generations.
Note that iPhone 15 and 16 series are not compatible.

3. SETUP

3.1 Initial Charging of the Power Bank

Before first use, fully charge your Charmast portable charger. Use the included USB A to USB C cable and a compatible power adapter (not included).

1. Connect the USB-C end of the cable to the USB-C input port on the side of the power bank.
2. Connect the USB-A end of the cable to a 5V-2A or 9V-2A power adapter.
3. Charging time will be approximately 1.5 hours with a 9V-2A fast charger or 3 hours with a 5V-2A

normal charger.

4. The LED indicators on the power bank will illuminate to show the charging status. All four LEDs will be solid when fully charged.



Image 3.1: The portable charger being recharged from a wall adapter. It highlights the difference in charging times between a 9V-2A fast charger (1.5 hours) and a 5V-2A normal charger (3 hours).

4. OPERATING INSTRUCTIONS

4.1 Charging Your Device

1. Ensure the portable charger is adequately charged.
2. Align the integrated connector of the power bank with your iPhone's charging port.

3. Gently push the power bank onto your iPhone until it is securely connected.
4. Press the power button on the side of the portable charger once to activate charging. The LED indicators will show the remaining battery level.
5. Your iPhone will begin charging. The power bank supports 20W PD fast charging for compatible devices.

Charge Your Phone 3X Faster*

20W PD Fast Charging



Image 4.1: Demonstrates the fast charging capability of the portable charger, showing an iPhone being charged. A comparison graphic highlights that 20W PD charging can achieve 50% battery in 30 minutes, significantly faster than a standard 5V/1A charger.



Image 4.2: A user talking on their iPhone while it is connected to the portable charger, demonstrating the convenience of using the device during charging.

4.2 Checking Battery Level

Press the power button once to view the current battery level indicated by the LED lights:

- 4 LEDs: 75-100% charged
- 3 LEDs: 50-75% charged
- 2 LEDs: 25-50% charged
- 1 LED: 0-25% charged (recharge soon)

Wake up, Ready to Go

Wake up with a fully charged power bank and device



Press me once to
activate this function.

Image 4.3: Illustrates pressing the power button on the portable charger to initiate charging or check the battery status.

4.3 Case Compatibility

The charger is designed to be compatible with phone cases less than 4mm thick. Cases thicker than 4mm, such as some rugged or battery cases, may prevent a secure connection.

Partial Cellphone Case Friendly



Image 4.4: Visual guide on phone case compatibility, showing that cases thinner than 4mm are supported, while thicker cases (e.g., Otter Box) may not allow proper connection.

5. MAINTENANCE

5.1 Cleaning

To clean the portable charger, use a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface.

5.2 Storage

When storing the device for an extended period, ensure it is fully charged. Recharge the device every 2 months during storage to maintain battery health. Store in a cool, dry place away from direct sunlight and

extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Charmast portable charger, please refer to the following guide:

Problem	Solution
Product stopped working after being stored for a while.	Fully charge the device before storing it, and recharge it every 2 months during storage. Charge the device for at least 3 hours before using it again. If the issue persists, contact technical support.
Charging stops at 1 or 2 LED lights (doesn't fully charge).	Drain the battery completely (until it turns off), then recharge it. If the issue persists, contact technical support.
Product doesn't charge my phone.	Charge the device for at least 3 hours before attempting to use it. Ensure your phone case is less than 4mm thick. If the issue persists, contact technical support.

Troubleshooting Guide

1. Product Stopped Working After Being Stored for a While

Solution:

Fully charge the device before storing it, and recharge it every 2 months during storage. Charge the device for at least 3 hours before using it again. If the issue persists, contact our Technical Support via Amazon.
2. Charging Stops at 1 or 2 LED Lights (Doesn't Fully Charge)

Solution:

Drain the battery completely (until it turns off), then recharge it. If the issue persists, contact our Technical Support via Amazon.
3. Product Doesn't Charge My Phone

Solution:

Charge the device for at least 3 hours before attempting to use it. If the issue persists, contact our Technical Support via Amazon.

Image 6.1: A visual representation of common troubleshooting steps for the portable charger.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	1.38 x 3.03 x 0.97 inches
Item Weight	3.2 ounces
Model Number	CMP
Battery Capacity	5000 Milliamp Hours
Connector Type	Compatible with iPhone (Lightning)

Feature	Detail
Special Features	1.5 hours Fast Recharging, Built-In Connector, Fast Charging, Lipstick Size, Travel Essential
Color	Black
Manufacturer	Dong guan Utopia-Originality Technology Co., Ltd
Date First Available	August 12, 2023




8. WHAT'S IN THE BOX




- Charmast Small Portable Charger (5000mAh) x 1
- USB A to USB C cable x 1
- User Manual x 1

9. WARRANTY AND SUPPORT


Charmast provides 24-month support and 7-day/24-hour friendly customer service. If you have any problems, please contact us through your Amazon order page, and we will endeavor to resolve them within 24 hours.

Related Documents - CMP

	<p>CMP PXSS2K-HC Cable Gland Installation Instructions and Technical Data</p> <p>Comprehensive installation guide and technical specifications for the CMP PXSS2K-HC cable gland, designed for unarmoured, braided, and extra hard cord usage cables in explosive atmospheres. Includes ATEX, UKEX, IECEx, and CSA certifications, installation steps, and selection tables.</p>
	<p>Brilliant Wonders LED Lighted Waterfall Installation Instructions</p> <p>Installation instructions for the CMP 25677 Series Brilliant Wonders LED Lighted Waterfall. This guide covers product overview, packing list, safety precautions, mechanical installation, plumbing, and parts list for the LED waterfall.</p>
	<p>CMP Deck Jet with Adjustable Flow Nozzle Installation and Product Manual</p> <p>Comprehensive installation instructions and product manual for the CMP Deck Jet with Adjustable Flow Nozzle, including specifications, installation steps, winterization, troubleshooting, and FAQs.</p>

	<p>Brilliant Wonders LED Waterfalls Installation Guide - CMP</p> <p>Detailed installation instructions for the CMP Brilliant Wonders LED Waterfalls (25677 Series), covering product overview, safety precautions, mechanical and electrical installation, plumbing, and frequently asked questions.</p>
	<p>CMP Fire Pots and Fire Tables Installation Instructions - Manual Gas Valve</p> <p>Comprehensive installation instructions for CMP Fire Pots and Fire Tables with manual gas valves. Covers safety, location, clearances, venting, gas line, valve installation, operation, maintenance, and troubleshooting.</p>
	<p>Brilliant Wonders 1.5 inch LED Light Installation Instructions & Product Manual</p> <p>Comprehensive installation and product manual for the CMP Brilliant Wonders 1.5 inch LED Light, detailing safety warnings, installation steps, wiring, operation modes, and available accessories. Includes product specifications and operational guidance for J-Style, H-Style, and P-Style variants.</p>

Documents - charmast – CMP



[Charmast 5000mAh Portable Charger CMP User Manual | Specs & Guide](#)

Comprehensive user manual for the Charmast 5000mAh Portable Charger CMP. Find specifications, getting started instructions, maintenance tips, troubleshooting guide, FAQs, and safety warnings.

lang:en score:37 filesize: 2.41 M page_count: 1 document date: 2025-08-01