

Manuals.plus /

› OSALADI /

› OSALADI Induction Cooker Adapter Plate User Manual

OSALADI U6T15100949M44DZNRXYL

# OSALADI Induction Cooker Adapter Plate User Manual

## PRODUCT OVERVIEW

---

The OSALADI Induction Cooker Adapter Plate is a robust and practical accessory designed to integrate induction cookers or gas stoves into hot pot tables. Made from durable stainless steel, this fitting ensures stability and longevity. It is an ideal solution for repairing existing hot pot tables or setting up new ones, providing a secure and functional cooking surface.



Image 1: The OSALADI Induction Cooker Adapter Plate, showcasing its sleek stainless steel design and integrated lid.

## Key Features

- **Durable Construction:** Made from high-quality stainless steel, ensuring strength, wear resistance, and a long service life.
- **Versatile Compatibility:** Suitable for use with both induction cookers and gas stoves, making it a flexible addition to any hot pot setup.
- **Easy Installation:** Designed for straightforward operation, installation, and disassembly, facilitating quick repairs or

setups.

- **Practical Design:** The sinking pot ring and cover kit are specifically designed for hot pot table repair holes, offering a convenient and practical solution.
- **Wide Application:** Ideal for various settings, including home use, restaurants, and commercial hot pot establishments.

## SPECIFICATIONS

---

Attribute	Detail
Material	Stainless Steel
Color	Silver
Finish Type	Chrome
Size (Current Model)	20.5x20.5cm (8.1in x 8.1in)
Product Dimensions (Approx.)	0.79"D x 12.52"W x 0.79"H (Overall)
Item Weight	9.3 ounces (0.58 Pounds)
Model Number	U6T15100949M44DZNRXYL
Package Includes	1 x steel ring, 1 x lid




Image 2: Detailed dimensions of the adapter plate and its components, showing the 8.1 inch (20.5 cm) diameter of the lid and the 9.4 inch (23.8 cm) diameter of the ring, with a height of 2.6 inches (6.5 cm).

## SETUP

---

The OSALADI Induction Cooker Adapter Plate is designed for integration into a hot pot table. Its primary function is to provide a stable and secure recessed area for your induction cooker or gas stove. Follow these general steps for setup:

1. **Prepare the Table Opening:** Ensure your hot pot table has a circular opening that matches the outer diameter of the adapter plate's steel ring (approximately 23.8 cm or 9.4 inches). The design is intended for 'sinking' into the table.
2. **Insert the Steel Ring:** Carefully place the steel ring component into the prepared opening in your hot pot table. It should fit snugly to create a stable base.
3. **Place the Lid:** The included lid can be placed on top of the steel ring when the cooker is not in use, or to cover the opening if desired.
4. **Position Your Cooker:** Once the steel ring is securely in place, you can position your induction cooker or gas stove within the recessed area provided by the adapter plate.



Image 3: The adapter plate seamlessly integrated into a hot pot table, ready for a cooking appliance.

## OPERATING INSTRUCTIONS

---

The OSALADI Induction Cooker Adapter Plate itself does not require operation. Its function is to provide a stable and integrated platform for your cooking appliance. Once installed, operate your induction cooker or gas stove as per its own manufacturer's instructions.

- Ensure the adapter plate is securely seated in the table opening before placing any cooking appliance on it.
- Place your induction cooker or gas stove centrally within the adapter plate's ring for optimal stability.
- Always follow the safety guidelines provided with your specific cooking appliance.



Image 4: An example of the adapter plate in use during a hot pot meal, demonstrating its practical application.

## CARE AND MAINTENANCE

---

To ensure the longevity and appearance of your OSALADI Induction Cooker Adapter Plate, follow these simple care and maintenance guidelines:

- **Cleaning:** Wipe the stainless steel surface with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could scratch the finish.
- **Drying:** After cleaning, dry the plate thoroughly to prevent water spots and maintain its luster.
- **Storage:** If removing the plate for storage, ensure it is clean and dry. Store in a place where it will not be scratched or dented.
- **Inspection:** Periodically inspect the plate for any signs of wear or damage. While highly durable, proper care will extend its life.

## TROUBLESHOOTING

---

The OSALADI Induction Cooker Adapter Plate is a passive component and typically does not experience operational issues. Most concerns would relate to its fit or appearance.

- **Loose Fit in Table:** If the adapter plate feels loose in the table opening, ensure the opening size matches the product's dimensions. A professional installer may be needed for custom table modifications.
- **Scratches/Dents:** While made of durable stainless steel, heavy impact or abrasive cleaning can cause cosmetic damage. Refer to the 'Care and Maintenance' section to prevent this.
- **Rust Spots:** Stainless steel is highly resistant to rust, but prolonged exposure to harsh chemicals or certain types of water can cause surface discoloration. Clean promptly and thoroughly dry the surface.

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage, product support, or to address any specific concerns not covered in this manual, please contact OSALADI customer service. Refer to your purchase documentation or the OSALADI official website for contact details. Please have your model number (U6T15100949M44DZNRXYL) and purchase date ready when contacting support.