

[Manuals.plus](#) /

› [TAGRY](#) /

› TAGRY Bluetooth Earbuds User Manual

TAGRY X07-001

TAGRY Bluetooth Earbuds User Manual

Model: X07-001

Brand: TAGRY

INTRODUCTION

This manual provides detailed instructions for the proper use, maintenance, and troubleshooting of your TAGRY Bluetooth Earbuds (Model: X07-001). Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



The TAGRY Bluetooth Earbuds with their compact charging case.

What's Included

The TAGRY Bluetooth Earbuds package typically includes the following items:

- TAGRY Wireless Headphones (Earbuds)
- Charging Case
- USB-C Charging Cable
- User Manual (this document)
- Multiple Sizes of Eartips (S, M, L)



All components included in the TAGRY Earbuds package.

PRODUCT OVERVIEW

The TAGRY Bluetooth Earbuds are designed for comfort and performance, featuring an ergonomic earhook design and intuitive controls.

Earbud Components:

- **Earhook:** Provides a secure and comfortable fit, ideal for sports and active use.
- **Eartips:** Soft silicone tips that fit inside the ear canal, available in multiple sizes for a personalized fit.
- **Multi-function Button:** Located on each earbud for controlling playback, calls, and voice assistant.
- **Charging Contacts:** Pins on the earbuds that connect with the charging case.

Charging Case Features:

- **Digital LED Display:** Shows the remaining battery percentage of the charging case and individual earbuds.
- **USB-C Port:** For charging the case.


Ergonomic Design for Sports



Earhook



Eartips



Ergonomic earhook design and included eartips for a secure and comfortable fit.

CHARGING THE EARBUDS AND CASE

To ensure optimal performance, fully charge the earbuds and charging case before first use.

1. Place the earbuds into the charging case. Ensure the charging contacts align correctly.
2. Close the charging case lid. The digital LED display on the case will illuminate, showing the battery status of both the case and the earbuds.
3. Connect the USB-C charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).

4. The LED display will show charging progress. Once fully charged, the display will indicate 100% for the case and full bars for the earbuds.

The charging case provides up to 80 hours of additional playtime for the earbuds, with 8 hours on a single charge.

Digital LED Battery Display



Battery for
Charging Case



Battery for
Earbuds

Digital LED display on the charging case indicates battery levels for the case and each earbud.

BLUETOOTH PAIRING

Follow these steps to pair your TAGRY Bluetooth Earbuds with your device:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, PC), enable Bluetooth.
3. Search for "X07" in the list of available Bluetooth devices.
4. Select "X07" to connect. Once connected, a voice prompt will confirm successful pairing.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case.

One Button Control

1x: One tap

2x: Double tap

3x: Triple tap

2s: Long press 2s



One-step auto pairing process with a smartphone.

WEARING THE EARBUDS

For the best audio experience and secure fit, follow these instructions:

1. **Choose suitable eartips:** Select the eartip size (S, M, L) that provides a snug and comfortable seal in your ear canal.
2. **Put the earbuds into your ear:** Gently insert the earbud into your ear, ensuring the eartip is properly seated.
3. **Adjust earbuds to fit you best:** Rotate and adjust the earhook around your ear until the earbud feels secure and comfortable. The flexible earhook ensures stability during movement.




Visual guide for selecting eartips and properly wearing the earbuds.

CONTROLS

Each earbud features a multi-function button for easy control of your audio and calls:

- **1x Tap (Either Earbud):** Play/Pause music, Answer/End call.
- **2x Tap (Left Earbud):** Previous track.
- **2x Tap (Right Earbud):** Next track.
- **3x Tap (Either Earbud):** Activate Voice Assistant (Siri, Google Assistant).
- **Long Press 2s (Left Earbud):** Volume Down.
- **Long Press 2s (Right Earbud):** Volume Up.
- **Press and Hold 2s (During Call):** Reject call.

One-Step Auto Pairing



Detailed overview of earbud touch controls.

WATER RESISTANCE (IPX7)

The TAGRY Bluetooth Earbuds feature an IPX7 waterproof rating, making them resistant to sweat and rain. This allows for worry-free use during workouts, running, and other outdoor activities.

Note: The charging case is not waterproof. Do not expose the charging case to water.



The IPX7 rating ensures the earbuds can withstand splashes and sweat.

SPECIFICATIONS

Feature	Detail
Brand	TAGRY
Model Name	Earbuds (X07-001)
Connectivity Technology	Wireless (Bluetooth 5.3)
Playtime	Up to 80 hours with charging case (8 hours single charge)
Water Resistance	IPX7 Waterproof
Microphone	Yes
Control Type	Voice Control, Remote (Multi-function Button)
Ear Placement	Over Ear
Noise Control	Passive Noise Cancellation
Product Dimensions	4.12 x 1.26 x 2.75 inches
Item Weight	5.9 ounces

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your TAGRY Bluetooth Earbuds, follow these care guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. For eartips, remove them and clean with mild soap and water, then dry thoroughly before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these may

damage the product.

- **Water Exposure:** While the earbuds are IPX7 waterproof, avoid prolonged submersion. Ensure earbuds are dry before placing them back into the charging case to prevent damage to the case.

TROUBLESHOOTING

If you encounter any issues with your TAGRY Bluetooth Earbuds, please refer to the following common solutions:

- **No Sound/Connection Issues:**

- Ensure earbuds are charged.
- Verify Bluetooth is enabled on your device and "X07" is selected.
- Try unpairing and re-pairing the earbuds.
- Restart your device.

- **One Earbud Not Working:**

- Place both earbuds back into the charging case, close the lid, and then open it again.
- Ensure both earbuds are charged.

- **Charging Issues:**

- Check the USB-C cable and power adapter for damage.
- Ensure charging contacts on earbuds and case are clean and free of debris.

For more detailed troubleshooting steps, please consult the official [Troubleshooting Guide \(PDF\)](#).

WARRANTY AND SUPPORT

TAGRY products come with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the official TAGRY website or contact their customer service directly. You can also find additional information in the comprehensive [User Manual \(PDF\)](#) provided with your product. For further assistance, visit the [TAGRY Store on Amazon](#).