

[Manuals.plus](#) /

> [USonline911](#) /

> USonline911 Replacement Shaver Blades Cutter for Panasonic Models ES8066, ES8067, ES8068, ES8951, ES762, ES765, ES766, ES881, ES882, ES883, ES881SS - Instruction Manual

## USonline911 ES8066, ES8067, ES8068, ES8951, ES762, ES765, ES766, ES881, ES882, ES883, ES881SS

# USonline911 Replacement Shaver Blades Cutter Instruction Manual

For Panasonic Models ES8066, ES8067, ES8068, ES8951, ES762, ES765, ES766, ES881, ES882, ES883, ES881SS

## INTRODUCTION


---

This manual provides essential information for the installation, use, and maintenance of your USonline911 Replacement Shaver Blades Cutter. These blades are designed as an aftermarket replacement for various Panasonic shaver models, ensuring continued optimal shaving performance. Please read this manual thoroughly before installation and use.

## PRODUCT FEATURES

---

- **Durable Construction:** Made of metal material, ensuring sturdiness and longevity.
- **Smooth Shave:** Designed with a smooth surface and exquisite workmanship for a comfortable and effective shave.
- **Easy Installation:** Engineered for straightforward replacement, allowing users to easily maintain their shaver.
- **Optimal Performance:** Recommended replacement every 18 months to maintain superior cutting performance, as shaver parts naturally wear out over time.
- **Quantity:** Package includes 2 shaver blade cutters.



Sharper blades

Made of high quality steel and exquisite workmanship, it can make the blade have a longer service life

Image: Two replacement shaver blades, emphasizing their sharp cutting edges for efficient shaving.

## COMPATIBILITY

---

These replacement shaver blades are compatible with the following Panasonic Shaver Foil and Shaver Models. Please verify your shaver's model number before purchasing and installing.

### Compatible Panasonic Shaver Foil Models:

- WES9077P
- WES9075P
- WES9070
- WES9077
- WES9079
- WES9075

### Compatible Panasonic Shaver Models:

- ES7002, ES7003, ES7006, ES7007, ES7008

- ES7015, ES7016, ES7017, ES7018
- ES7022, ES7024, ES7025, ES7026, ES7027
- ES7801
- ES8016, ES8017, ES8018, ES8019
- ES8023, ES8024, ES8025, ES8026
- ES8033, ES8035, ES8036
- ES8065, ES8066, ES8067, ES8068
- ES8951
- ES762, ES765, ES766
- ES881, ES882, ES883, ES881SS

**For PANASONIC ES762 ES765 ES766 ES882 ES8951 WES9077P WES9075P**



Image: Replacement blades shown with a compatible Panasonic shaver, indicating the correct fit for models like ES762, ES765, ES766, ES882, ES8951, WES9077P, WES9075P.

## INSTALLATION INSTRUCTIONS

Follow these general steps to replace your shaver blades. Specific instructions may vary slightly depending on your Panasonic shaver model. Always refer to your shaver's original manual for detailed guidance.

1. **Power Off:** Ensure your electric shaver is turned off and unplugged from any power source.
2. **Remove Outer Foil:** Gently press the release buttons (if present) or pull the outer foil frame upwards to detach it from the shaver body.
3. **Remove Old Inner Blades:** Carefully remove the old inner blades. These usually lift straight out or unclip. Dispose of them safely.
4. **Clean Shaver Head:** Clean any accumulated hair clippings or debris from the shaver head area using a small brush or by rinsing under water (if your shaver is waterproof). Ensure the area is dry before installing new blades.
5. **Install New Inner Blades:** Align the new USonline911 replacement inner blades with the drive shaft and gently press them into place until they click securely.
6. **Reattach Outer Foil:** Place the outer foil frame back onto the shaver body, ensuring it clicks into position.
7. **Test:** Turn on your shaver briefly to ensure the new blades are functioning correctly.

## Simple installation



Image: The replacement blades positioned for simple installation into a shaver head.

Regular cleaning of your shaver and replacement blades is crucial for maintaining hygiene and optimal cutting performance. Follow these steps for effective cleaning:

1. **Rinse Under Water:** After each shave, remove the outer foil and inner blades. Rinse both parts thoroughly under running water to wash away hair clippings and shaving cream residue.
2. **Use Soap (Optional):** For a deeper clean, apply a small amount of liquid hand soap to the outer foil and inner blades, then rinse again.
3. **Dry Thoroughly:** Shake off excess water and allow the outer foil and inner blades to air dry completely before reassembling them onto the shaver body.
4. **Lubrication:** Periodically apply a drop of shaver oil to the blades to ensure smooth operation and prolong their lifespan.



**Waterproof**

## Easy to Clean



Image: Replacement blades being cleaned under water, demonstrating their waterproof design for easy maintenance.

## TROUBLESHOOTING

If you experience issues with your replacement blades, consider the following:

- **Poor Shaving Performance:** Ensure the blades are correctly installed and securely seated. Verify that

your shaver model is listed in the compatibility section.

- **Irritation or Pulling:** This may indicate that the blades are dull or improperly installed. Replace blades if dullness is suspected. Ensure the shaver head is clean and free of debris.
- **Blades Not Fitting:** Double-check your shaver's exact model number against the compatibility list. If your model is not listed, these blades may not be suitable.
- **Noise:** Excessive noise might be due to improper installation or a need for lubrication. Reinstall the blades and apply shaver oil.

## SPECIFICATIONS

---

- **Product Type:** Shaver Blades Cutter Replacement
- **Material:** Metal
- **Quantity:** 2 pieces per package
- **Manufacturer:** USonline911
- **ASIN:** B0CFKY5XFR

## WARRANTY AND SUPPORT

---

This product is an aftermarket replacement. For warranty information regarding your Panasonic shaver, please refer to the original manufacturer's documentation. For support related to the USonline911 replacement blades, please contact the seller directly.

The provided Panasonic shaver manual (seen in the video below) indicates a limited warranty for Panasonic products (for U.S.A. only) and suggests registering online at [www.panasonic.com/register](http://www.panasonic.com/register) for benefits like safety notification, owner verification, efficient warranty service, and special offers.

For customer service related to Panasonic products, you can visit [shop.panasonic.com/support](http://shop.panasonic.com/support) or call 1-877-833-8855.

## RELATED VIDEO CONTENT

---

The following video provides an unboxing of a Panasonic Arc5 Electric Razor, which may offer context on the shaver models these blades are designed to replace. Please note this video is about the shaver itself, not specifically the replacement blades.

Your browser does not support the video tag.

Video: Unboxing of a Panasonic Arc5 Electric Razor (ES-LV65-s). This video demonstrates the contents of a Panasonic shaver package, including the shaver unit and its accompanying documentation.