

[Manuals.plus](#) /

› [vidaXL](#) /

› vidaXL Wall Cabinet Sonoma Grey 60x31x60 cm Plywood Instruction Manual

vidaXL 829954

vidaXL Wall Cabinet Sonoma Grey 60x31x60 cm Plywood Instruction Manual

Brand: vidaXL | Model: 829954

1. INTRODUCTION AND PRODUCT OVERVIEW

This wall-mounted cabinet is designed to be both a decorative and practical addition to your home decor. Crafted from high-quality plywood with a smooth surface, it offers robustness, stability, and resistance to moisture. It provides ample storage space for daily essentials, keeping them organized and within reach. The wall-mounting feature saves valuable floor space, and its top surface can be utilized to display photos, decorative items, or small plants, enhancing your living environment.



Image 1.1: The vidaXL Wall Cabinet in a typical home setting.

2. SAFETY INFORMATION

Important Safety Instructions:

- Please read and follow every step of the assembly and mounting instructions carefully.
- Use appropriate tools for assembly and mounting.
- Wear protective gloves and safety glasses during assembly and mounting to prevent injury.
- Do not mount the cabinet on a wall that cannot safely support its weight.
- If you are unsure about how to properly mount the cabinet, please consult a qualified professional.
- Screws and wall plugs for wall attachment are not included. Select appropriate hardware for your specific wall type.

3. PACKAGE CONTENTS

Before beginning assembly, please ensure all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (top, bottom, sides, back, doors)
- Internal shelves (2 pieces)
- Handles (2 pieces)
- Hinges and mounting plates
- Assembly hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

The vidaXL Wall Cabinet requires assembly. Please refer to the detailed, step-by-step assembly instructions included in your package for proper construction. The following provides a general overview and important considerations:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the diagrams in the instruction manual.
2. **Assemble the Cabinet Frame:** Follow the manual to connect the side panels, top, and bottom panels using the provided hardware. Ensure all connections are secure.
3. **Install Shelves:** Insert the shelf supports into the pre-drilled holes at your desired height and place the shelves.
4. **Attach Doors and Handles:** Mount the hinges to the doors and then attach the doors to the cabinet frame. Adjust hinges as needed for proper door alignment. Secure the handles to the doors.
5. **Prepare for Wall Mounting:** The cabinet is designed for wall mounting. Identify the mounting points on the back of the cabinet.
6. **Select Wall Hardware: Important:** Screws and wall plugs are NOT included. You must select appropriate hardware (screws and wall plugs) suitable for your specific wall type (e.g., concrete, plasterboard, wood stud). Consult a hardware specialist if unsure.
7. **Mount to Wall:** Mark the desired position on the wall, ensuring it is level. Drill pilot holes and insert wall plugs if necessary. Securely attach the cabinet to the wall using the chosen hardware. Ensure the cabinet is firmly fixed and stable before placing any items inside.




Image 4.1: Cabinet dimensions for planning installation.



Image 4.2: Detail of the wall mounting hardware on the back of the cabinet.

5. OPERATING INSTRUCTIONS (USAGE)

This wall cabinet is designed for general storage and display purposes in various rooms such as bathrooms, living rooms, or utility areas.

- **Opening and Closing Doors:** Gently pull the handles to open the cabinet doors. Push them firmly to close. Avoid slamming the doors to prevent damage to hinges and the cabinet structure.
- **Storage:** Utilize the internal shelves to store items such as toiletries, cleaning supplies, books, or decorative objects. Distribute weight evenly across the shelves.
- **Display Surface:** The top surface of the cabinet can be used to display lightweight decorative items, photos, or small potted plants. Ensure items are stable and do not overhang excessively.
- **Weight Capacity:** Do not overload the cabinet. Refer to the assembly manual for specific weight limits per shelf if provided. Overloading can compromise the cabinet's stability and wall mounting.



Image 5.1: Cabinet with doors open, illustrating internal storage space.

6. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your vidaXL Wall Cabinet.

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used, followed by wiping with a dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the plywood finish.
- **Check Fasteners:** Periodically inspect all screws, bolts, and wall mounting hardware to ensure they remain tight. Re-tighten if necessary, especially after initial assembly and during prolonged use.
- **Moisture Protection:** While the material is moisture-resistant, avoid prolonged exposure to excessive moisture or direct water contact to prevent swelling or damage.

7. TROUBLESHOOTING

If you encounter any issues with your wall cabinet, refer to the following common troubleshooting tips:

- **Cabinet feels wobbly or unstable:**
 - Ensure all assembly screws and fasteners are tightened securely.
 - Re-check the wall mounting. Verify that the wall plugs and screws used are appropriate for your wall type and are installed correctly. If in doubt, consult a professional.
- **Doors do not close properly or are misaligned:**
 - Check the hinges for correct alignment and tightness. Most hinges allow for minor adjustments using a screwdriver to align the doors horizontally, vertically, and in depth.
- **Surface damage (scratches, chips):**
 - For minor scratches, furniture touch-up pens or wax crayons matching the Sonoma Grey finish can be used.
 - For significant damage, consider contacting a furniture repair specialist or vidaXL customer service for advice.
- **Missing parts during assembly:**
 - Double-check the packaging and all contents against the parts list in the instruction manual. If parts are genuinely missing, contact vidaXL customer support with your product model number and purchase details.

8. SPECIFICATIONS

Brand	vidaXL
Model Number	829954
Color	Sonoma Grey
Material	Plywood (Legno multistrato / Legno compensato)
Dimensions (W x D x H)	60 cm x 31 cm x 60 cm (23.6" x 12.2" x 23.6")
Item Weight	15.6 kg
Number of Shelves	2
Mounting Type	Wall Mount
Assembly Required	Yes
Special Features	Dent resistant

9. WARRANTY AND SUPPORT

For specific warranty information, return policies, or technical support, please refer to the documentation provided with your purchase. You may also contact vidaXL customer service directly through their official website or the retailer from whom you purchased this product. Please have your model number (829954) and proof of purchase ready when contacting support.