

VEGA VHTH-32

VEGA 9-in-1 Pro Multi-Grooming Trimmer for Men (VHTH-32) Instruction Manual

Model: VHTH-32

1. PRODUCT OVERVIEW

The VEGA 9-in-1 Pro Multi-Grooming Trimmer (VHTH-32) is a versatile grooming tool designed for various trimming needs. It features stainless steel blades, a digital display, and washable components for easy maintenance.

1.1 Included Components

The package contains the following items:

- Trimmer Unit
- T-Blade with 2 combs (1-10mm & 11-20mm)
- Precision Blade with 2 combs (1-10mm & 11-20mm)
- Design Blade
- Nose Trimmer
- Body Shaver
- USB Type-C Charging Cable
- Cleaning Brush
- Lubricating Oil
- Storage Tray

Vega 9-in-1 Pro

Multi-Grooming Set



Image: All components of the VEGA 9-in-1 Pro Multi-Grooming Trimmer, including the main unit, various blade attachments, comb guides, nose trimmer, body shaver, charging cable, cleaning brush, oil, and storage tray.

1.2 Key Features

- **Stainless Steel Blades:** Durable and skin-friendly blades for precise grooming.
- **9-in-1 Grooming:** Includes T-Blade, Precision Blade, Design Blade, Nose Trimmer, Body Shaver, and 4 comb attachments.
- **Digital Display:** Shows battery status for convenient monitoring.
- **40 Length Settings:** Adjustable rotary knob for precise trimming from 1mm to 20mm.
- **150 Minutes Runtime:** Provides extended usage on a full charge.
- **USB Type-C Charging:** Offers convenient and universal charging.
- **Washable Blades:** Easy to clean under running water.

9 in 1 Pro-Multi Grooming Set



**Stainless Steel
Blades**



**5 Blades & 4 Combs
Attachment**



**150 Mins
Runtime**



**Digital
Display**



**40 Length
Setting**



Image: Overview of key features including stainless steel blades, 5 blades & 4 combs, 150 minutes runtime, digital display, and 40 length settings.

2. SETUP

2.1 Charging the Trimmer

1. Ensure the trimmer is switched off before charging.
2. Connect the USB Type-C charging cable to the trimmer's charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The digital display will indicate the charging status. A full charge takes approximately 3 hours and provides up to 150 minutes of runtime.



Image: Close-up of the trimmer's base showing the USB Type-C charging port and an illuminated battery indicator, highlighting its convenient charging capability.

2.2 Attaching and Detaching Blades/Combs

1. To attach a blade: Align the blade attachment with the trimmer head and press firmly until it clicks into place.
2. To detach a blade: Gently push the blade attachment upwards from the front of the trimmer head until it releases.
3. To attach a comb guide: Slide the desired comb guide onto the blade attachment until it locks securely.
4. To detach a comb guide: Gently pull the comb guide away from the blade attachment.

3. OPERATING INSTRUCTIONS

3.1 General Trimming

1. Ensure your skin and hair are clean and dry before trimming.
2. Select the appropriate blade and comb attachment for your desired grooming task.

3. Press the power button to turn on the trimmer.
4. Hold the trimmer at a comfortable angle and move it against the direction of hair growth for optimal results.
5. After use, turn off the trimmer and clean it as described in the Maintenance section.



Image: A man using the VEGA trimmer, illustrating its use for beard trimming with the Precision Blade, neck and edge detailing with the T-Blade, personalized styling with the Design Blade, nose hair trimming with the Nose Trimmer, and body grooming with the Body Shaver.

3.2 Using Specific Attachments

- **Precision Blade:** Ideal for styling and trimming short to long beards. Use with 1-10mm or 11-20mm comb guides for desired length.
- **T-Blade:** Accurately trim hair lines and edges on the face and neck for a clean finish. Use with 1-10mm or 11-20mm comb guides for hair trimming.
- **Design Blade:** For personalized styling and detailing, creating sharp lines and intricate designs.
- **Nose Trimmer:** Gently insert the trimmer into the nostril or ear canal to safely remove unwanted hair.
- **Body Shaver:** Safely groom hair on various body areas, including underarms and chest.

40 Length Settings

Easily Adjust the Rotary Knob for Precise Trimming (1-20mm)



Image: Five distinct blade attachments are shown: Precision Blade for beard styling, T-Blade for sharp lines, Body Shaver for body hair, Nose/Ear Trimmer for delicate areas, and Design Blade for intricate detailing.

3.3 Adjusting Length Settings

The trimmer features a rotary knob for precise length adjustments. Rotate the knob to select your desired trimming length from 1mm to 20mm. The selected length will be indicated on the knob.

Storage Tray

Neatly & safely organise
all attachments



Image: A close-up view of the trimmer's rotary knob, clearly showing the numerical length settings from 1 to 20, indicating precise adjustment capabilities.

3.4 Digital Display

The integrated digital display shows the current battery percentage, allowing you to monitor the power level and recharge as needed.



Image: A close-up of the trimmer's digital display, showing '100' and a full battery icon, indicating the battery status.

4. MAINTENANCE

4.1 Cleaning the Trimmer

1. Turn off the trimmer and detach the blade attachment.
2. Use the provided cleaning brush to remove any loose hairs from the blade and trimmer unit.
3. The blades are washable. Rinse the detached blade attachment under running water. Do not submerge the main trimmer unit in water.
4. Allow all parts to air dry completely before reattaching or storing.
5. Apply a small drop of lubricating oil (provided) to the blades periodically to maintain optimal performance.

Stainless Steel Blades

Precise and Safe
Grooming

Washable Blades

Easy and Effective
Cleaning



Image: A close-up view of the trimmer's stainless steel blades, emphasizing their precision and the ease of cleaning due to their washable design.

4.2 Storage

Store the trimmer and all its attachments in the provided storage tray in a cool, dry place, away from direct sunlight and moisture. This helps protect the components and keeps them organized.



Image: The VEGA trimmer unit and its various attachments are shown neatly arranged within the dedicated storage tray, demonstrating an organized storage solution.

5. TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Check the digital display for battery level.
- **Poor trimming performance:** Clean the blades thoroughly to remove any hair buildup. Apply lubricating oil to the blades. Ensure the correct blade and comb attachment are used for the hair type and length.
- **Blades pulling hair:** The blades may be dull or improperly attached. Ensure blades are clean and oiled. If the issue persists, contact customer support.
- **Charging issue:** Verify the USB cable and power adapter are working correctly. Ensure the charging port is clean and free of debris.

6. SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	VHTH-32
Blade Material	Stainless Steel
Power Source	USB Powered
Charging Time	3 Hours
Runtime	150 Minutes
Length Settings	40 (1-20mm)
Item Weight	179 g
Product Dimensions (LxWxH)	16.6 x 4.2 x 4.2 cm
Special Features	Charge Indicator Light, Detachable, Multigroomer, Self-Cleaning, Travel Size, USB Charging

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This VEGA product comes with a **2-year warranty** from the date of purchase. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal use conditions.

7.2 Customer Support



For any queries, assistance, or warranty claims, please contact VEGA customer care:





Customer Care: +91 08069496949

Importer: IMPORTED BY VEGA INDUSTRIES PRIVATE LIMITED, PLOT NO. 31, SECTOR-155, NOIDA-201310, U.P. (INDIA)

© 2023 VEGA. All rights reserved.

Related Documents - VHTH-32

	<p>VEGA VHTH-14 Rechargeable Beard Trimmer User Manual & Guide</p> <p>Comprehensive user manual for the VEGA VHTH-14 rechargeable beard trimmer. Learn about features, usage, cleaning, maintenance, safety, and warranty information provided by VEGA.</p>
	<p>Vega P1 Beard Trimmer User Manual</p> <p>User manual for the Vega P1 Beard Trimmer, providing instructions on usage, cleaning, maintenance, safety precautions, and warranty information.</p>

	<p>Vega T-680 Series UHF PRO-PLUS Wireless Microphone Owner's Manual</p> <p>Owner's manual for the Vega T-680 Series UHF PRO-PLUS Wireless Microphone, covering setup, operation, troubleshooting, and specifications.</p>
	<p>VEGA Salon Smooth Hair Straightener VHSH-42 User Manual</p> <p>Comprehensive user manual for the VEGA Salon Smooth Hair Straightener VHSH-42, covering maintenance, safety instructions, usage, and styling tips.</p>
	<p>VEGASON 61: Istruzioni d'uso per Sensore Ultrasonoro Foundation Fieldbus</p> <p>Guida completa alle istruzioni d'uso per il sensore ultrasonoro VEGASON 61 di VEGA con tecnologia Foundation Fieldbus. Copre installazione, funzionamento, manutenzione e risoluzione dei problemi.</p>
	<p>VEGAPULS 66 Radar Seviye Sensörü Kullanım Kılavuzu</p> <p>Bu kullanım kılavuzu, VEGA tarafından üretilen VEGAPULS 66 radar seviye sensörünün montajı, bağlantısı, devreye alınması, kullanımı ve bakımı hakkında detaylı bilgi sağlar. Sıvıların sürekli seviye ölçümü için tasarlanmış bu cihazın özelliklerini ve işletim talimatlarını içerir.</p>

Documents - VEGA – VHTH-32



[\[pdf\]](#) User Manual Instructions

VHTH 32 UM cdr Khursheed Alam The safety instructions explained in this User Manual helps you to use the VEGA Grooming Set safely and also prevent from injuring yourself or others C1NrDnxpHqL m media amazon images I |||

...

lang: **score:30** filesize: 4.57 M page_count: 1 document date: 2022-11-11