



[Manuals.plus](#) /

> [WEIZE](#) /

> WEIZE Kids Bike User Manual

WEIZE TW-DU008

WEIZE Kids Bike User Manual

Model: TW-DU008 | Brand: WEIZE

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your new WEIZE Kids Bike. Please read it thoroughly before first use to ensure the safety of the rider and the longevity of the bicycle. The WEIZE Kids Bike is designed for children aged 3-13 years, with various wheel sizes (16, 18, 20 inches) to accommodate different rider heights.



Image Description: A full view of the WEIZE Kids Bike in white, featuring red and black accents on the frame and chain guard. The bike has black tires, a red seat, and a bell on the handlebar.

SAFETY INFORMATION

Always prioritize safety. Ensure the rider wears a helmet and appropriate safety gear. Adult supervision is recommended, especially for younger riders. Regularly inspect the bike for loose parts, proper brake function, and tire pressure before each ride.

- Always wear a properly fitted helmet.
- Ensure all bolts and quick releases are securely tightened.
- Check tire pressure before each ride.
- Test both hand and coaster brakes for proper function.
- Ride in safe environments, away from traffic.
- Do not ride at night without proper lighting.

SETUP AND ASSEMBLY

Your WEIZE Kids Bike requires some assembly. While the bike comes with most components pre-assembled, final steps such as handlebar, pedal, and front wheel installation are typically required. A portable bike pump is included. Please note that other installation tools are not included.

Included Components:

- Bicycle Frame and partially assembled components
- Front Wheel
- Handlebar
- Pedals
- Seat Post and Saddle
- Portable Bike Pump
- Training Wheels (for some models, as shown in images)

Assembly Steps:

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Handlebar Installation:** Insert the handlebar stem into the fork tube and tighten the bolt securely. Ensure the handlebar is aligned with the front wheel.



Height- Adjustable Handlebar & Seat

Accompany kids to grow up




Image Description: A white WEIZE Kids Bike is shown with labels pointing to its "Durable Steel Frame," "Tool-Free Adjustable Seat Post," and "Adjustable Handlebar." This image highlights the bike's adjustability for growing children.

- 3. Front Wheel Installation:** Attach the front wheel to the fork. Ensure the wheel is centered and the quick release or axle nuts are tightened firmly.
- 4. Pedal Installation:** Identify the left (L) and right (R) pedals. The left pedal tightens counter-clockwise, and the right pedal tightens clockwise. Thread them carefully to avoid cross-threading.
- 5. Seat Post Adjustment:** Insert the seat post into the frame. Adjust the saddle height using the tool-free adjustable seat post to ensure the rider's feet can touch the ground.

EASY TO INSTALL

Kind reminder: Does not include installation tools.



WHEEL SIZE	16"	18"	20"
BIKE WEIGHT	14.1 kgs 31.1 lbs	15.1 kgs 33.3 lbs	15.8 kgs 34.8 lbs
SADDLE HEIGHT	52-62 cm 20.5-24.4 in	55-70 cm 21.7-27.5 in	61-75 cm 24.0-29.5 in
RIDER HEIGHT	96-121 cm 38-48 in	106-138 cm 42-52 in	121-160cm 48-62 in
RIDER AGE	4-6	5-10	6-12

Image Description: A white WEIZE Kids Bike is displayed next to a table detailing wheel size, bike weight, saddle height, rider height, and rider age for 16", 18", and 20" models. The image emphasizes the ease of installation and provides a helpful sizing guide.

- 6. Training Wheels (Optional):** If your model includes training wheels, attach them securely to the rear axle according to the instructions provided with the training wheels.



Image Description: A white WEIZE Kids Bike, equipped with training wheels, is parked on a city street. This image illustrates the bike's appearance with training wheels attached, suitable for beginner riders.

- 7. Pre-Ride Check:** Before the first ride, double-check all connections, brakes, and tire pressure.

OPERATING INSTRUCTIONS

The WEIZE Kids Bike features a dual brake system for enhanced safety and control, including both a hand brake and a coaster brake.

Braking System:

- **Hand Brake:** Located on the handlebar, this brake is designed for shorter distances for kids' small hands, providing immediate stopping power to the front wheel.

- **Coaster Brake:** Activated by pedaling backward, the coaster brake provides reliable stopping power to the rear wheel, allowing for intuitive stopping.

Dual Brake System



With fully enclosed chain guard for safety



Hand Brake
Shorter distance for kids' small hands



Coaster Brake
Pedal backwards to instantly stop

Image Description: This image showcases the WEIZE Kids Bike's dual brake system. It features the full bike with an inset showing a close-up of the hand brake lever and another inset illustrating the coaster brake mechanism at the rear wheel, emphasizing the fully enclosed chain guard for safety.

Adjustments for Growth:

The bike is designed to grow with your child. The handlebar and seat height are adjustable to ensure a comfortable and safe riding position as your child grows.

- **Handlebar Adjustment:** Loosen the stem bolt, adjust the handlebar to the desired height, and re-tighten securely.
- **Seat Adjustment:** Use the quick-release lever on the seat post to adjust the saddle height. Ensure the seat post is inserted past the minimum insertion line.

MAINTENANCE

Regular maintenance ensures the safety and extends the life of your WEIZE Kids Bike.

- **Tires:** Check tire pressure before each ride. Recommended pressure is usually indicated on the tire sidewall. Use the included portable bike pump.
- **Brakes:** Regularly check brake levers for proper tension and ensure brake pads make full contact with the rim. For coaster brakes, ensure smooth engagement.
- **Chain:** Keep the chain clean and lubricated. The bike features a fully enclosed chain guard for protection, but occasional cleaning and lubrication are still beneficial.



Image Description: A close-up view of the rear wheel and pedal area of the WEIZE Kids Bike, highlighting the fully enclosed chain guard. This guard helps protect the chain from dirt and debris and prevents clothing from getting caught.

- **Bolts and Nuts:** Periodically check all bolts and nuts for tightness, especially on the wheels, handlebars, and seat post.
- **Cleaning:** Clean the bike with mild soap and water. Avoid high-pressure washing, which can damage bearings.

TROUBLESHOOTING

Here are some common issues and their solutions:

- **Flat Tire:** Check for punctures. If found, repair or replace the inner tube. Inflate to recommended pressure.
- **Brakes Not Working Effectively:** Check brake cable tension (for hand brake) and adjust if too loose. Ensure brake pads are not worn and are properly aligned. For coaster brakes, ensure the mechanism is clean and free of debris.
- **Loose Handlebar/Seat:** Re-tighten the stem bolt for the handlebar or the quick-release lever for the seat post.
- **Squeaky Brakes:** Clean brake pads and rims. If noise persists, slight toe-in adjustment of brake pads might be needed (for hand brake).

SPECIFICATIONS

Detailed specifications for the WEIZE Kids Bike (Model TW-DU008):

Feature	Detail
Bike Type	Kids Bike
Model Name	TW-DU008
Brand	WEIZE
Age Range (Description)	3 - 13 Years
Minimum User Height	42 Inches
Color	White (Multiple color options available)
Suspension Type	Rigid
Special Feature	Lightweight
Included Components	Bicycle, Portable Bike Pump
Brake Style	Coaster, Hand Brake
Theme	Bike
Style	Classic
Power Source	Manual
Wheel Material	Carbon Steel
Seat Material Type	Carbon Steel
Assembly Required	Yes
Number of Handles	2
Skill Level	Beginner to Intermediate
Item Dimensions (LxWxH)	50 x 22 x 33.8 inches (for 20" model)
Package Weight	76 Pounds



Image Description: Diagram showing the dimensions of the 16-inch WEIZE Kids Bike, including overall length, height, handlebar width, and seat height range.



Image Description: Diagram showing the dimensions of the 18-inch WEIZE Kids Bike, including overall length, height, handlebar width, and seat height range.



Image Description: Diagram showing the dimensions of the 20-inch WEIZE Kids Bike, including overall length, height, handlebar width, and seat height range.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your WEIZE Kids Bike, please contact WEIZE customer support. Refer to the product packaging or the WEIZE official website for the most current contact information. You can also visit the [WEIZE Store on Amazon](#) for additional product information and support.

