

[Manuals.plus](#) /

> [PTHTECHUS](#) /

> PTHTECHUS Smart Watch for Kids Instruction Manual

## PTHTECHUS 4GS05

# PTHTECHUS Smart Watch for Kids

Model: 4GS05

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your PTHTECHUS Smart Watch for Kids. Please read this manual thoroughly before using the device to ensure proper functionality and a safe user experience.

## PACKAGE CONTENTS

---

Please verify that all items listed below are present in your package:

- 1 x PTHTECHUS Smart Watch
- 1 x Charging Cable
- 1 x User's Manual (this document)

## GETTING STARTED

---

### Charging the Watch

Before first use, fully charge the smart watch. Connect the provided charging cable to the watch's charging port and plug the other end into a standard USB power adapter (not included) or a computer's USB port. The watch typically requires approximately 3 hours for a full charge.

### Powering On/Off

- **To Power On:** Press and hold the power button located on the side of the watch until the screen illuminates.
- **To Power Off:** Press and hold the power button until a power-off option appears on the screen, then confirm to shut down.

### Basic Navigation

The PTHTECHUS Smart Watch features a 1.54-inch full-color LCD touchscreen for intuitive interaction. Swipe left or right to navigate between different applications and functions. Tap on an icon to open an application. Swipe down

from the top to access quick settings or notifications.



Image: The PTHTECHUS Smart Watch, showcasing its design and touchscreen interface.

## KEY FEATURES AND FUNCTIONS

---

### Camera and Video Recording

The watch is equipped with an HD camera for capturing photos and videos. Access the camera application from the main menu. You can apply 10 fun effect magic stickers to your photos. Captured media can be viewed directly on the watch.

# Record Happy Moment

 **Camera**

 **Video**



**10 fun stickers**



Image: Children interacting with the smart watch's camera feature, capturing moments and applying fun stickers.

## Music Player

The built-in music player allows for audio playback. Connect the watch to a computer via USB to transfer MP3 music files or audio stories to the watch's internal storage (500 MB capacity). The watch supports standard audio formats.

## Pedometer


A motion sensor tracks daily steps and estimates calories burned. This feature encourages physical activity and can be viewed in the Pedometer application.

## Educational Features

The watch includes learning flashcards and 8 audio books. Flashcards cover vocabulary for animals, colors, vegetables, and fruits. Audio books provide stories with pictures and sounds, suitable for bedtime or quiet time.



**8 audio books**



**MP3 music player**



**Learn Card**

Image: The smart watch's educational features, including audio books and learning cards for vocabulary development.

## Games and Parental Controls

The watch features 22 pre-installed puzzle games designed to stimulate imagination. A parental control function allows parents to set time limits for game play, helping to manage screen time.

# 22 Fun Games Parental Controls



Image: The smart watch displaying its game selection and parental control feature.

## Habit Tracking

A habit tracker feature helps children cultivate good daily routines. Users can set and monitor habits such as waking up, brushing teeth, eating meals, doing homework, and going to bed.


# Habit Tracking



Image: The habit tracking interface on the smart watch, showing various daily activities.

## Time Management Tools


- **Alarm Clock:** Set multiple alarms for reminders throughout the day.
- **Timer:** Use the countdown timer for various activities.
- **Calendar:** View the current date and plan activities.



**Timer**



**Alarm clock**



**Calculator**



**Pedometer**

Image: Icons representing the timer, alarm clock, calculator, and pedometer functions.

### **Additional Utilities**

The watch includes a flashlight, calculator, voice recorder, and customizable wallpapers to enhance usability and personalization.

# All in One kids Watch



Image: A comprehensive display of all available applications and features on the smart watch.

## MAINTENANCE AND CARE

---

### Cleaning

To clean the watch, gently wipe the screen and strap with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or aerosol sprays, as these can damage the watch's surface and internal components. The watch is not waterproof; avoid submerging it in water or exposing it to excessive moisture.

### Battery Information

The watch uses a Lithium Polymer battery. To prolong battery life, avoid extreme temperatures and store the watch in a cool, dry place when not in use. Do not attempt to replace the battery yourself; contact customer support if battery issues arise.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Watch does not power on.	Low battery; device frozen.	Charge the watch for at least 30 minutes. If still unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
Screen is unresponsive.	Software glitch; screen damage.	Restart the watch. Ensure the screen is clean and dry. If the issue persists, contact customer support.
Cannot transfer files to watch.	Incorrect USB connection; driver issue.	Ensure the USB cable is securely connected to both the watch and the computer. Try a different USB port or cable. Check if the watch is recognized as a storage device on your computer.
Battery drains quickly.	Frequent use of power-intensive features; background apps.	Reduce screen brightness. Close unused applications. Limit continuous video recording or game play. Ensure the watch is fully charged before use.

## PRODUCT SPECIFICATIONS

---

- **Model:** 4GS05 (A22-Black)
- **Display:** 1.54 Inches LCD, 240 x 240 resolution, Color Screen
- **Memory Storage Capacity:** 500 MB
- **Operating System:** Smartwatch OS
- **Battery Type:** Lithium Polymer (included)
- **Battery Capacity:** 500 Milliamp Hours
- **Charging Time:** Approximately 3 Hours
- **Battery Average Life:** Up to 3 days (usage dependent)
- **Connectivity:** USB
- **Human Interface Input:** Touchscreen
- **Product Dimensions:** 22 x 2 x 1 cm; 55 g
- **Special Features:** Alarm Clock, Calendaring, Camera, Music Player, Touchscreen, Pedometer, Games, Audio Books, Study Cards, Habit Tracker, Flashlight, Calculator, Voice Recorder

## WARRANTY AND SUPPORT

---

PTHTECHUS is committed to providing high-quality products and service. For any questions, technical support, or warranty inquiries, please refer to the contact information provided with your purchase or visit the official PTHTECHUS website. Please retain your proof of purchase for warranty claims.