

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [COSTWAY](#) /

› [COSTWAY Scandinavian Lounge Chair with Footrest Instruction Manual](#)

COSTWAY NP10119FR

COSTWAY Scandinavian Lounge Chair with Footrest

Model: NP10119FR

INTRODUCTION

This instruction manual provides important information for the safe assembly, operation, and maintenance of your COSTWAY Scandinavian Lounge Chair with Footrest. Please read this manual thoroughly before use and retain it for future reference.

This modern lounge chair and ottoman set is designed for comfortable leisure. Constructed from quality polyester fabric and robust metal tubes, this lounge chair is durable and stable. It features a soft pillow and armrests for optimal comfort. The ergonomic, extra-wide seat and additional ottoman allow for complete relaxation. Its X-shaped structure and anti-slip pads provide enhanced stability.



The COSTWAY lounge chair and ottoman in a modern living room setting, demonstrating its aesthetic appeal and comfortable design.



The COSTWAY lounge chair and ottoman placed on a balcony or patio, showcasing its versatility for different environments.

SAFETY WARNINGS

ATTENTION: Failure to follow these safety warnings may result in injury or damage to the product.

- Do not exceed the maximum weight capacity of **150 kg (330 lbs)** for the lounge chair.
- Do not exceed the maximum weight capacity of **50 kg (110 lbs)** for the ottoman.
- Ensure all assembly instructions are followed carefully and all components are securely fastened for optimal stability.
- Keep children and pets away from the product during assembly.
- Periodically check all bolts and connections to ensure they remain tight.
- Avoid standing on the chair or ottoman.

PACKAGE CONTENTS

Before assembly, please verify that all parts listed below are present in your package:

- 1 x Lounge Chair

- 1 x Ottoman
- 1 x Ottoman Cushion
- 1 x Instruction Manual

SETUP & ASSEMBLY

Follow these steps to assemble your COSTWAY Scandinavian Lounge Chair and Ottoman. No special tools are required for assembly.

1. **Connect the Support Tubes:** Assemble the metal frame components for both the chair and the ottoman. Ensure all connections are firm.
2. **Place the Cover:** Drape the fabric cover over the chair's metal frame, aligning it correctly.
3. **Attach the Buckles:** Secure any buckles or clips on the fabric cover to the frame as indicated.
4. **Fasten the Straps:** Use the high-resistance straps to securely fasten the fabric cover to the frame, ensuring a snug fit.
5. **Close the Zipper:** Zip up the main closure on the fabric cover.
6. **Fix with Velcro:** Use the Velcro fasteners to further secure the cover and ensure it is taut.
7. **Attach Ottoman Cushion:** Place the ottoman cushion on the ottoman frame and secure it using its ties or fasteners.

Installation Facile



1 Connecter les tubes de support



2 Mettre la housse



3 Attacher la boucle



4 Attacher les sangles



5 Fermer la fermeture éclair



6 Fixer à l'aide des fermetures velcro

Step-by-step assembly guide for the COSTWAY lounge chair, showing how to connect support tubes, attach the cover, secure buckles, fasten straps, close zippers, and fix velcro.

OPERATING INSTRUCTIONS

Your COSTWAY lounge chair and ottoman are designed for comfortable relaxation. Here's how to best utilize its features:

- **Ergonomic Design:** The chair is shaped to adapt to your body's curves, providing support for your neck, back, arms, legs, and feet when used with the ottoman.
- **Ottoman Use:** Position the ottoman in front of the chair to elevate your legs and feet, promoting full body relaxation. The ottoman is foldable for easy storage when not in use.
- **Side Pocket:** Utilize the convenient side pocket on the chair to store small items such as books, remote controls, or mobile phones, keeping them within easy reach.
- **Anti-slip Pads:** The chair and ottoman are equipped with anti-slip pads on their feet to ensure stability and protect your floors.

S'Adapter aux Courbes de Votre Corps pour un Confort Optimal

Soulagez votre stress et chassez la fatigue



A person comfortably seated in the COSTWAY lounge chair with the ottoman, highlighting the ergonomic support for the neck, back, arms, legs, and feet.



Close-up details of the COSTWAY lounge chair, showing the ergonomic head pillow, a practical side pocket for storage, and anti-slip foot pads.




Repose-pieds pliable avec coussin amovible



Sangles haute résistance et longue durée



Structure robuste en forme de X



Coussinets antidérapants

Detailed view of the ottoman's features, including its foldable design with a removable cushion, high-resistance straps, robust X-shaped structure, and anti-slip pads.

MAINTENANCE

Proper care and maintenance will extend the life of your lounge chair and ottoman.

- **Fabric Cover:** The removable fabric cover can be machine washed on a delicate cycle with cold water. Tumble dry on low heat.
- **Metal Components:** Hand clean the metal frame components with a damp cloth. Dry immediately to prevent rust.
- **General Cleaning:** For spills, blot immediately with a clean, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically inspect all parts for wear and tear. Tighten any loose screws or bolts.



Tissu Polyester de Haute Qualité



Confortable



Doux



Respirant



Élastique

Close-up view of the high-quality polyester fabric of the COSTWAY lounge chair, illustrating its comfortable, soft, breathable, and elastic properties.

TROUBLESHOOTING

If you encounter any issues with your lounge chair, refer to the following common problems and solutions:

- Instability:** If the chair or ottoman feels wobbly, check all assembly connections. Ensure all bolts are tightened securely and the anti-slip pads are properly seated on a flat surface.
- Fabric Sagging:** If the fabric cover appears loose, re-check the straps, zippers, and Velcro fasteners to ensure they are taut and properly secured to the frame.
- Noise:** If the chair makes noise during use, inspect the metal frame for any loose connections or parts that may be rubbing. Tighten as necessary.

For issues not covered here, please contact customer support.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	NP10119FR
Color	Beige
Materials	Polyester, Metal, Cotton
Lounge Chair Dimensions (L x D x H)	75 x 81 x 94.5 cm (29.5 x 31.9 x 37.2 inches)
Ottoman Dimensions (L x W x H)	42 x 42 x 48 cm (16.5 x 16.5 x 18.9 inches)
Chair Load Capacity	150 kg (330 lbs)
Ottoman Load Capacity	50 kg (110 lbs)
Seat Height	52 cm (20.5 inches)
Net Weight	10.5 kg (23.1 lbs)
Care Instructions	Machine wash delicate cycle with cold water, tumble dry low. Hand clean metal components and dry to prevent rust.



Detailed dimensions of the COSTWAY lounge chair and ottoman, including height, width, and depth measurements, along with weight capacities.

WARRANTY INFORMATION

COSTWAY products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact COSTWAY customer service. Have your model number (NP10119FR) and purchase information ready when contacting support.

For the most up-to-date contact information, please visit the official COSTWAY website or refer to your purchase receipt.

