



Manuals.plus /

› taopodo /

› taopodo Wireless Bluetooth Earbuds User Manual

taopodo S24

taopodo Wireless Bluetooth Earbuds

USER MANUAL

Introduction

Welcome to the user manual for your new taopodo Wireless Bluetooth Earbuds, Model S24. This guide provides comprehensive instructions on how to set up, operate, maintain, and troubleshoot your earbuds to ensure you get the best possible audio experience. Please read this manual carefully before using your device.

Product Overview

Your taopodo Wireless Bluetooth Earbuds are designed for superior sound quality and comfort, featuring Bluetooth 5.3 connectivity, HiFi stereo sound, and IP7 waterproofing. The package includes:

- Two taopodo Wireless Earbuds
- One Charging Case with LED Display
- One USB-C Charging Cable
- User Manual (this document)



Image: The taopodo Wireless Bluetooth Earbuds shown inside their charging case, which features a digital LED display indicating battery levels.

Long Battery Life

7 Hrs
Single Charge

40 Hrs
With Charging case



Image: An illustration highlighting the long battery life of the earbuds, indicating 7 hours on a single charge and up to 40 hours with the charging case. The charging case with its LED display is also visible.

Setup and First Use

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the case and a power source. The LED display on the case will show the charging status. A full charge provides up to 30 hours of total playtime.

2. Pairing with Your Device

1. Ensure Bluetooth is enabled on your smartphone, tablet, or other device.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "taopodo S24" (or similar name) from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds feature Bluetooth 5.3 for a stable and fast connection, with a transmission range of up to 15 meters.



Image: A visual representation of the upgraded Bluetooth 5.3 technology, illustrating its benefits such as more stable connection, lower power consumption, lower latency, and longer transmission range compared to older Bluetooth versions.

Operating Your Earbuds

Your taopodo earbuds feature intuitive touch controls for easy management of audio playback and calls.

Touch Control Functions:

| Action | Function |
|--------------------------------|-----------------------------------|
| Single Tap (Left/Right Earbud) | Play/Pause Music, Answer/End Call |
| Double Tap (Right Earbud) | Next Song |
| Double Tap (Left Earbud) | Previous Song |
| Triple Tap (Left/Right Earbud) | Activate Voice Assistant |
| Long Press (2 seconds) | Reject Call |

The earbuds are equipped with ENC (Environmental Noise Cancellation) microphones for clear calls, eliminating disruptive background noise.

ENC Noise Cancelling Mic For Clear Calls

Eliminate disruptive background noise to get clear calls



Noise: █

Voice: █

Image: A graphic illustrating the effectiveness of ENC (Environmental Noise Cancellation) technology in the earbuds, showing how it reduces background noise for clearer voice transmission during calls.

Maintenance and Care

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners or solvents.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Water Resistance (IP7)

Your earbuds are rated IP7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This makes them suitable for sports and workouts, protecting against sweat and rain. However, they are not designed for swimming or showering. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.

Troubleshooting

If you encounter any issues with your earbuds, please refer to the following common solutions:

- **No Sound:**

- Ensure earbuds are charged.
- Check volume levels on both earbuds and your connected device.
- Verify that the earbuds are properly paired with your device.

- **Pairing Issues:**

- Make sure Bluetooth is enabled on your device and the earbuds are in pairing mode.
- Forget "taopodo S24" from your device's Bluetooth list and try pairing again.
- Ensure no other devices are connected to the earbuds.
- Try resetting the earbuds (refer to device-specific reset instructions if available, otherwise a general power cycle).

- **Charging Issues:**

- Check if the USB-C cable is securely connected to both the case and the power source.
- Try a different charging cable or power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.

- **Earbuds Not Responding to Touch:**

- Ensure your fingers are clean and dry when touching the control area.
- Try placing the earbuds back in the case and taking them out again to reset.

Specifications

| Feature | Detail |
|------------------------|-------------------------------------|
| Model Number | S24 |
| Brand | taopodo |
| Connectivity | Bluetooth 5.3 |
| Earbud Type | In-Ear |
| Waterproof Rating | IP7 |
| Earbud Weight | 3.3g (each) |
| Total Playtime | Up to 30 hours (with charging case) |
| Single Charge Playtime | Up to 6 hours |
| Charging Port | USB-C |
| Sound Technology | HiFi Stereo, CVC8.0 Noise Reduction |
| Driver Size | 13mm |

HiFi Sound Quality

14.2 mm Drivers & Volume-optimized Active EQ keep audio clear and balanced



Hi-Fi Audio

Crystal Clear Call

Image: An illustration detailing the internal components responsible for HiFi sound quality, mentioning 14.2mm drivers and volume-optimized Active EQ for clear and balanced audio.

Ultra light and Ergonomically Designed

The earphones weight only 3.3g and can be worn on the ear stably and comfortably



Image: A depiction of the earbuds' ultra-light (3.3g) and ergonomic design, showing how they fit comfortably and stably in the ear.

Warranty and Support

Warranty Information

Your taopodo Wireless Bluetooth Earbuds are covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. Keep your purchase receipt as proof of purchase.

Customer Support

For further assistance, technical support, or warranty claims, please contact taopodo customer service. Contact details can typically be found on the product packaging, the official taopodo website, or through your retailer's support channels.

Note: Availability of spare parts and software updates is not guaranteed by the manufacturer.

