

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OMAIC](#) /

› [OMAIC OM479B Replacement Remote Control for Toshiba REGZA TVs \(2011-2025 Models\) Instruction Manual](#)

## OMAIC OM479B

# OMAIC OM479B Replacement Remote Control for Toshiba REGZA TVs (2011-2025 Models) Instruction Manual

Model: OM479B

## INTRODUCTION

This manual provides instructions for the OMAIC OM479B replacement remote control, designed for use with Toshiba REGZA LCD TVs manufactured between 2011 and 2025. This remote offers functionality similar to original Toshiba remotes without requiring complex setup.



Image: Front, side, and back views of the OMAIC OM479B replacement remote control.

## PRODUCT FEATURES

- **Direct Compatibility:** Designed to work with Toshiba REGZA LCD TVs from 2011 to 2025.
- **No Setup Required:** Ready to use immediately after inserting batteries.
- **Infrared Technology:** Operates via infrared signal.
- **Extended Operating Range:** Effective up to approximately 10 meters with a wide control angle of up

to 120 degrees.

- **Quick Response:** Features a fast response speed for button presses.
- **Dedicated Streaming Buttons:** Includes direct access buttons for popular streaming services like Netflix, YouTube, U-NEXT, Hulu, and Prime Video.



Image: Key features of the OMAIC remote control, highlighting infrared operation, comfortable silicone buttons, and an ergonomic design for easy grip.

## COMPATIBILITY

The OMAIC OM479B remote control is compatible with various Toshiba REGZA LCD TV models from 2011 to 2025. It is designed to replace original Toshiba remote models such as CT-90453, CT-90463, CT-90466, CT-90467, CT-90475, CT-90478, CT-90479, CT-90480, CT-90481, CT-90484, CT-90485, CT-90489, and CT-90491.

### Note:

- Some function buttons or shortcut buttons may not be fully operational depending on your specific TV model.
- This remote may not be compatible with Toshiba REGZA TV models manufactured before 2011.

### Supported TV Series:

- BM620X Series
- BZ710X Series
- C310X Series
- C340X Series
- G20X Series
- J10 Series
- J10X Series
- M500X Series
- M510X Series
- M520X Series
- M530X Series
- M540X Series
- V30 Series
- V31 Series

- X830 Series
- Z700X Series
- Z9X Series

## 複数のオリジナルリモコンの代わりに

対応するリモコン: Toshiba CT-90453 CT-90463 CT-90466 CT-90467 CT-90475 CT-90478  
CT-90479 CT-90480 CT-90481 CT-90484 CT-90485 CT-90489 CT-90491



Image: The OMAIC remote shown alongside several original Toshiba REGZA remote controls it is designed to replace, illustrating its broad compatibility.

## SETUP

The OMAIC OM479B remote control is designed for immediate use without any programming or complex setup procedures.

- Open the Battery Compartment:** Locate the battery cover on the back of the remote control and slide it open.
- Insert Batteries:** Insert two (2) AAA batteries into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside.
- Close the Battery Compartment:** Slide the battery cover back into place until it clicks securely.
- Ready for Use:** The remote control is now ready to operate your compatible Toshiba REGZA TV.

### Important Battery Information:

- Batteries are not included with this product.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.



Image: A diagram illustrating the battery compartment and the correct orientation for inserting two AAA batteries into the OMAIC remote control.

## OPERATING INSTRUCTIONS

The OMAIC OM479B remote control features a standard layout for easy navigation and control of your Toshiba REGZA TV.



Image: A detailed view of the OMAIC remote control's button layout, indicating functions such as input switching, channel/volume controls, navigation, and dedicated streaming service buttons.

### Key Button Functions:

Button	Function
(Power)	Turns the TV on or off.
(Input Select)	Switches between different input sources (HDMI, AV, etc.).
(0-12)	Direct channel selection.
(+/-)	Changes TV channels up or down.
(+/-)	Adjusts the volume level.
(Enter/OK)	Confirms selections in menus.
(Arrows)	Navigates through menus and options.
(Back)	Returns to the previous screen or menu.

Button	Function
<b>(Exit)</b>	Exits the current menu or application.
<b>Netflix, YouTube, U-NEXT, Hulu, Prime Video</b>	Direct access buttons for respective streaming applications.

For other specific functions, refer to your Toshiba REGZA TV's original user manual or on-screen menu for guidance, as some advanced features may vary or require the original remote.




Image: The OMAIC remote control highlighting its dedicated buttons for quick access to popular streaming services such as Netflix, YouTube, U-NEXT, Hulu, and Prime Video.

## MAINTENANCE

To ensure the longevity and optimal performance of your OMAIC OM479B remote control, follow these maintenance guidelines:

- Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- Avoid Liquids:** Do not expose the remote control to water or other liquids. If it gets wet, remove the batteries immediately and allow it to dry completely before reinserting them.
- Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- Dropping:** Avoid dropping the remote control, as this can damage internal components.

## TROUBLESHOOTING

If you encounter issues with your OMAIC OM479B remote control, refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Remote not responding.	<ul style="list-style-type: none"> <li><b>Batteries:</b> Check if batteries are inserted correctly. Replace with fresh AAA batteries.</li> <li><b>Line of Sight:</b> Ensure there is a clear line of sight between the remote's IR emitter and the TV's IR receiver. Obstructions can block the signal.</li> <li><b>Distance:</b> You might be too far from the TV. The effective range is approximately 10 meters.</li> </ul>
Some buttons do not work.	<ul style="list-style-type: none"> <li><b>TV Model Compatibility:</b> Some advanced or specific functions may not be supported by this universal replacement remote, depending on your TV model.</li> <li><b>Button Malfunction:</b> If only one or two buttons are unresponsive, they might be stuck or damaged. Try pressing them firmly.</li> </ul>
Remote works intermittently.	<ul style="list-style-type: none"> <li><b>Low Batteries:</b> Replace batteries with new ones.</li> <li><b>Interference:</b> Other electronic devices or strong light sources might interfere with the IR signal. Try moving away from potential interference.</li> </ul>
Remote does not control TV at all.	<ul style="list-style-type: none"> <li><b>TV Compatibility:</b> Double-check that your Toshiba REGZA TV model falls within the 2011-2025 range and is one of the supported series.</li> <li><b>Remote Damage:</b> If all other steps fail, the remote control might be damaged.</li> </ul>

If the problem persists after trying these steps, please contact OMAIC customer support for further assistance.

## SPECIFICATIONS

Feature	Detail
Brand	OMAIC
Model Number	OM479B
Color	Black
Connectivity Technology	Infrared (IR)
Compatible Devices	Toshiba REGZA LCD TVs (2011-2025 models)
Max Number of Supported Devices	1 (TV)
Special Features	Universal, No setup required
Product Dimensions	18 x 4 x 1.6 cm

Feature	Detail
Item Weight	60 g
Batteries Required	2 x AAA (not included)

## WARRANTY AND SUPPORT

OMAIC strives to provide high-quality products. If you have any questions or concerns regarding your OM479B remote control, please contact OMAIC customer support.

- Contacting Support:** You can typically find contact information for OMAIC through your purchase platform (e.g., Amazon's "Contact Seller" option in your order history).
- Returns:** Returns are handled according to the retailer's policy. If you wish to exchange the product, please contact OMAIC directly.
- Response Time:** OMAIC aims to respond to inquiries within 24 hours.



Image: A graphic detailing Frequently Asked Questions (FAQ) about returns and how to contact the seller for support.