

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Newbealer](#) /

> [Newbealer Dual Voltage Garment Steamer NB316A-dualB Instruction Manual](#)

Newbealer NB316A-dualB

Newbealer Dual Voltage Garment Steamer NB316A-dualB Instruction Manual

Model: NB316A-dualB | Brand: Newbealer

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Newbealer Dual Voltage Garment Steamer. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always use demineralized or distilled water to prevent mineral buildup and extend the life of your steamer.
- Ensure the correct voltage setting (120V for US/JP, 240V for EU/AU) is selected using the manual switch before plugging in the device. An audible alarm will sound if an incorrect voltage is detected.
- Do not immerse the steamer in water or other liquids.
- Keep the steamer away from children and pets.
- Do not touch the hot steam plate or steam nozzle during operation or immediately after use. Use the provided heat-resistant glove.
- Unplug the steamer from the power outlet when not in use, before filling or emptying the water tank, and before cleaning.
- The steamer features an auto-shutoff function that activates after 30 minutes of inactivity for safety.
- Use only attachments recommended by the manufacturer.



Image: Safety shield icon highlighting the steamer's safety features.

2. PACKAGE CONTENTS

Your Newbealer Dual Voltage Garment Steamer package includes the following items:

- 1x Newbealer Dual Voltage Garment Steamer
- 1x Fabric Brush attachment
- 1x Heat-Resistant Ironing Glove
- 1x Travel Pouch
- 1x User Manual



Image: All items included in the Newbealer steamer package: the steamer unit, fabric brush, heat-resistant glove, travel pouch, and user manual.

3. PRODUCT FEATURES AND COMPONENTS

The Newbealer Dual Voltage Garment Steamer is designed for efficient and convenient wrinkle removal with the following key features:

- **Dual Voltage (100-240V):** Manually switch between 120V (US/JP) and 240V (EU/AU) for worldwide use. The steamer includes an intelligent voltage recognition system with an alarm for incorrect settings.
- **Powerful Performance:** 1200W heating element provides strong, continuous steam output of 20g/min.
- **Fast Heat-up:** Reaches 302°F in approximately 20 seconds.
- **180ml Detachable Water Tank:** Provides up to 10 minutes of continuous steaming, sufficient for approximately 5 garments. The tank is transparent for easy water level monitoring.
- **360° No-Spill Technology:** Allows for both vertical and horizontal steaming without leakage.
- **Foldable Handle:** Enhances portability and compact storage for travel.
- **Auto-Shutoff:** Automatically turns off after 30 minutes of inactivity for safety.
- **Self-Cleaning Function:** Helps prevent scale buildup and prolongs the steamer's lifespan.



Honest About Weight. Built for Power.



Image: Detailed diagram illustrating the steamer's components, including the dual voltage switch, power and steam buttons, steam nozzle, detachable water tank, foldable handle, and fabric brush.

2 In 1 STEAMING & PRESSING

Great Look In Seconds



Before



After

Image: Infographic detailing the steamer's performance features: 1200W power, 20g/min steam output, automatic shut-off, 302°F temperature, 20-second heat-up, 10 minutes of continuous steam, and self-cleaning.

4. SETUP

1. **Attach Water Tank:** Gently pull out the detachable water tank from the main unit.
2. **Fill Water Tank:** Open the water tank cap and fill it with demineralized or distilled water. Do not overfill. Close the cap securely.
3. **Reattach Water Tank:** Push the filled water tank back into the main unit until it clicks securely into place.
4. **Select Voltage:** Locate the manual voltage switch (120V/240V) on the steamer. Use a small tool (like a key) to slide the switch to the correct voltage for your region. The steamer will alert you if an incorrect voltage is selected.
5. **Plug In:** Insert the power plug into a suitable electrical outlet.



Image: A visual guide showing the steps to prepare the steamer for use, including filling the water tank and selecting the correct voltage.



Image: A close-up view demonstrating the process of attaching the water tank to the steamer.



Image: A diagram showing the dual voltage switch and examples of voltage requirements in various countries.

5. OPERATING INSTRUCTIONS

1. **Power On & Preheating:** Press the power button. The indicator light will flash red, then turn blue when preheating is complete (approx. 20 seconds).
2. **Start Steaming:** Once the blue light is steady, press the steam button to activate continuous steam.
3. **Steaming Techniques:**
 - **Vertical Steaming:** Hang the garment and hold the fabric taut with one hand (using the heat-resistant glove). Move the steamer slowly up and down over the wrinkles.
 - **Horizontal Steaming/Pressing:** Lay the garment flat on a heat-resistant surface. The flat steam plate allows for light pressing to remove stubborn wrinkles.
4. **Using the Fabric Brush:** For thicker fabrics or to remove lint, attach the fabric brush to the steam plate. This helps improve steam penetration.
5. **Finish Steaming:** Release the steam button to stop steaming. Press the power button to turn off the steamer. Unplug the device from the outlet.

Portable Handheld Clothes Steamer



Safety protection: The steamer will automatically turn off after 30 minutes of operation (approximately 10 minutes of water usage)




Dual voltage switch
Simple to use for worldwide travel



Power button & steam button
Easy to use



Steam outlet nozzle
Remove creases quickly



180ml/6oz water tank
Detachable & visible



Foldable handle
Compact & portable



Fabric brush
Deep remove dust

Image: Before and after comparison of a shirt, showcasing the effectiveness of both vertical steaming and horizontal pressing techniques.



Image: The fabric brush attachment and heat-resistant glove, illustrating their role in garment care and user safety.

Official Product Videos:

Video: Newbealer Dual Voltage Steamer: Instant Steam Worldwide. This video demonstrates the steamer's quick and effective wrinkle removal capabilities across various fabrics and its dual voltage functionality for global use.

Video: How to Use Newbealer Dual Voltage Steamer? This instructional video provides a step-by-step guide on how to properly set up and operate the steamer for optimal results.

Video: Compact Dual Voltage Steamer, Quick Wrinkle Removal. This video highlights the compact design and rapid wrinkle removal performance of the steamer, ideal for quick touch-ups.

Video: Elevate Your Travel Experience with Foldable Steamer. This video showcases the steamer's foldable design and portability, emphasizing its convenience for business and leisure travel.

6. MAINTENANCE

- **Auto-Cleaning:** To activate the auto-clean mode, long-press the steam button for 3 seconds after preheating. This feature helps minimize limescale buildup.
- **Water Tank Care:** After each use, empty any remaining water from the tank. Allow the tank and steamer to cool completely before storing.
- **Storage:** Fold the handle for compact storage. Place the steamer and accessories in the provided travel pouch.

Perfect for Business Travel

Compact, Foldable and Portable



Image: A visual representation of the steamer's smart self-cleaning function, detailing how to activate it to prevent limescale buildup.

7. TROUBLESHOOTING

- **No Steam/Steamer Not Working:** Check if the steamer is properly plugged in. Ensure the water tank is filled and correctly attached. Verify that the voltage switch is set to the correct regional voltage (120V or 240V). If an incorrect voltage is selected, the steamer will beep and not operate.
- **Water Leakage:** Ensure the water tank is securely attached and the cap is tightly closed. Always use the steamer in the recommended vertical or horizontal positions.
- **Steam Output is Weak:** Ensure the water tank is sufficiently filled. Perform the auto-cleaning function to remove any mineral buildup that might be obstructing steam flow.

8. SPECIFICATIONS

Feature	Specification
Brand	Newbealer
Model Number	NB316A-dualB
Color	Brown (100-240V)
Product Dimensions	6.1"L x 3.5"W x 3.5"H
Item Weight	1.72 pounds (780 Grams)
Wattage	1200 watts
Voltage	100-240 Volts (AC)
Heat Time	20 Seconds
Water Tank Capacity	180 Milliliters
Product Benefits	Dual Voltage, Fabric Refreshening, Wrinkle Removal

9. WARRANTY AND SUPPORT

For any issues or support inquiries regarding your Newbealer Dual Voltage Garment Steamer, please contact us through Amazon. We are committed to ensuring your satisfaction with our products.